



# PSTX – Die fortschrittliche Baureihe

## Anleitung zur Wandmontage

### Mindestabstand vorn





### Mindestabstand seitlich



### Abmessungen in mm (in)



Softstarter, Typ	A	B	C	D
<b>PSTX</b>				
PSTX30 ... PSTX105	100 (3,937)	10 (0,393)	20 (0,787)	35 (1,378)
PSTX142 ... PSTX170	100 (3,937)	10 (0,393)	20 (0,787)	35 (1,378)
PSTX210 ... PSTX370	100 (3,937)	10 (0,393)	20 (0,787)	35 (1,378)
<b>PSTB</b>				
PSTB470	150 (5,905)	15 (0,59)	20 (0,787)	-
PSTB570 ... PSTB1050	150 (5,905)	15 (0,59)	20 (0,787)	-

### Maximaler Befestigungswinkel



## Abmessungen

### PSTB externe Tastatur (PSTEK)



Abmessungen in mm (in)

### PSTX abnehmbare Tastatur

