

Foreword

Thank you very much for purchasing PI8000/PI8100 Family Frequency Inverters. This family is designed based on the professional manufacture experience and sale of the product, and suitable for general-purpose machine, fan/pump drive, **medium** frequency drive and heavy load machine.

This product adopts the advanced sensorless vector control technology, combined with local frequency inverter application features to achieve high-performance V/F control (dead-time compensation + auto-torque upgrade + Slip Compensation) and high-performance non-sense vector control, and high-performance speed sensorless vector control.

This User's Manual includes PI8000/PI8100, the general purpose control and special purpose control. The general purpose control has F, G, M and H; The special purpose control has S, T and Z:

F: FLOW LOAD

G: GENERAL LOAD

M: MEIDDLE LOAD

H: HEAVY LOAD.

S: TEXDRIVE.

T: WINDLASS.

Z: JETDRIVE.

Please contact the local dealers or directly contact our company.

Please keep this user's manual in good condition, for it will be helpful to the repair, maintenance, and applications in the future.

CONTENTS

Section I.	Inspection & Safety Precautions.....	1
Section II.	Installation & Standby Circuit.....	3
Section III.	Operating Keyboard	13
Section IV.	Test Running.....	21
Section V	Parameter Function Table.....	23
5-1.	Functional parameter list.....	23
5-2.	Functional parameter specification.....	53
Section VI.	Fault Diagnosis & Solutions.....	128
Section VII	Standard Specifications	130
Section VIII.	Maintenance	145
Section IX.	Options	147
Section X	Quality Assurance.....	151
Appendix I.	RS485 Communication Protocol.....	152
Appendix II	Instruction of the Proportional Linkage Function	167
Appendix III.	RS485 PG Card Instruction	170
Appendix IV	Converter Water Supply Controller Instruction.....	172


Section I. Inspection & Safety Precautions

PI8000 frequency inverters have been tested and inspected before leaving the manufacturer. Before unpacking the product, please check if its package is damaged due to careless transportation, and if the specifications and type of the product complies with the order. Please contact the supplier of products if any problems are found.


1-1. Inspection after Unpacking

- ※ Inspect that the contents are complete (one unit of PI8000/8100 frequency inverter, one operation manual(with a copy of warranty card), one maintenance tips card).
- ※ Check the nameplate on the side of the frequency inverter to ensure that the product you have received is the right one you ordered.

1-1-1. Name plant Instruction 1



1-1-2. Model description 2:



1-2. Safety Precautions

- ※ Never connect the A.C. power supply to the output terminals (U, V, W) of the frequency

inverter.

- ※ Fix and lock the panel before supplying power so as to avoid the danger caused by the poor capacity or other components inside the inverter.
- ※ After the power supply is switched on, do not perform wiring or check, etc.
- ※ Don't touch the circuit boards or its parts or components in the inverter when it is powered, so as to avoid danger of electric shock.
- ※ If the power supply is switched off, do not touch the PCB or other parts inside the inverter within 5 minutes after the keyboard indicator lamp goes off, and you must check by using the instrument that the inverter has completely discharged all its capacity before you start to work inside the inverter. Otherwise, there will be the danger of electric shock.
- ※ The static electricity in human body will cause serious damage to the MOS field effect transistor in the inverter. Please keep your hands away from the PCB, IGBT and other internal parts before taking actions to prevent static electricity. Otherwise, faults may be caused.
- ※ In use, the earthing terminal (\perp) of the frequency inverter must be grounded to the earthing connections correctly and securely according to the national electrical safety specifications and other applicable standards.
- ※ Please don't shut off the unit by turning off the power supply. Turn off the power supply after the motor has stopped its operation.
- ※ Meet CE standard with EMI filter.

1-3. Application

- ※ Frequency inverter is generally applied to 3 phase AC asynchronism motors.
- ※ Frequency inverter is applied to the admittance occasion, the occasion where is not admittance may lead to fire, electric shock, explosion and so on.
- ※ If the inverter seizes up when it is applied to the equipment which may lead danger (e.g. lift tools of transportation, aviation system, safety equipment, etc), it should be managed carefully. Do inquire the factory when it happens.

Only the well-trained personnel are allowed to use this unit, and such personnel must read through the parts of this manual relating to the safety, installation, operation and maintenance before using the unit. The safe operation of this unit depends on correct transport, installation, operation and maintenance!


Section II. Installation & Standby Circuit

2-1. Conditions for Use

- 1) Ambient temperature $-10^{\circ}\text{C}\sim 40^{\circ}\text{C}$.
- 2) Avoid electromagnetic interference and keep the unit away from the interference source.
- 3) Prevent dropping water, steam, dust, powder, cotton fiber or fine metal powder from entering it.
- 4) Prevent oil, salt and corrosive gas from entering it.
- 5) Avoid vibration.
- 6) Avoid high temperature and moisture and avoid being wetted due to raining, with the humidity below 90%RH (not dewing).
- 7) Prohibit the use in the dangerous environment where inflammable or combustible or explosive gas, liquid or solid exists.

2-2. Installation

The frequency inverter must be installed by wall hooking in the indoor room with adequate ventilation, with enough space left between it and the adjacent objects or damper (walls) surrounding it, as shown in the below figure:




2-3. Wiring


The wiring of frequency inverter includes two parts: main circuit and control circuit. The user must ensure correct connections according to the following connection diagram.

2-3-1. PI8000 Diagram

1. Wiring diagram 11kW ~15kW and below (8N2)



2. Wiring diagram 18.5kW~355kW(8N3/8N4 /8N5 /8N6 /8N7 /8N8 /8N9 /8NA /8NB)




Section II

2-3-2. PI8100 Diagram

1. Wiring diagram 11kW and below (7N2 /7N3 /7N4)


Section II




2-4. Main Circuit Terminals(G Series)

2-4-1. PI8000 Main Circuit Terminals


1. 11~15kW(380V)Main Circuit Terminals



2. 18.5~37kW(380V)Main Circuit Terminals




3. 45~250kW(380V)Main Circuit Terminals




Note: DC+1/DC+2 Standard setting is short circuit; if it is with external reactance, please disconnect and then connect it.

4. 280~355kW(380V)Main Circuit Terminals



2-4-2. PI8100 Main Circuit Terminals

1. 7.5kW below(380V)Main Circuit Terminals



Note: The above kW categories are for G type inverter.

2-4-3. Terminal Function

Terminal	Description	Functions
R/L1	Power input for frequency inverter	Connected to 3-phase power (Single input connected to R, T)
S/L2		
T/L3		
⊕	Grounding point	Grounded to the earth
B1, B2	Connection point for braking resistance	Connect brake resistance
U/T1	3 Phase Output	Connected to 3-phase motor
V/T2		
W/T3		
DC+2, DC-	DC Bus output	Connect the brake brake unit.
DC+1, DC+2	DC reactance connection terminal.	Connect DC reactance (No short circuit).

2-5. Control Circuit Terminals

2-5-1. Control Circuit Terminals Description

Classify	Terminal	Description	Functions
Input signal	DI1	DI1 Input Terminal	Multi-functions input terminal.For details Please read o36~o46
	DI2	DI2 Input Terminal	


	DI3	DI3 Input Terminal	Enter a valid polarity can be controlled by o47 DI1~DI4 Drive model can be controlled by JP4 Above 11kW: DI5~DI8 Drive model can be controlled by PLC output terminal DI6 can as digital pulse input Below 11kW: DI5~DI6 Drive model can be controlled by PLC output terminal DI6 can as digital pulse input
	DI4	DI4 Input Terminal	
	DI5	DI5 Input Terminal	
	DI6	DI6 Input Terminal	
	DI7	DI7 Input Terminal	
	DI8	DI8 Input Terminal	
	PLC	PLC Control Terminal	
Assistant Power	24V	Power positive	The biggest output 24V/200mA, Can not connect COM with GND in any situation
	COM	Common terminal	
Output signal	SPA/COM	Output signal 1	Open Collector signal when the output action (24VDC/50mA) Common terminal COM, the output function can set by o21, o22 SPA, SPB provide hi-speed pulse output function. After setting functions by o61~o64, Frequency inverter will take effect again.
	SPB/COM	Output signal 2	
	TA1/TB1/TC1	Output signal 3	
	TA2/TB2/TC2	Output signal 4	
Analog input signal	+10V, GND	Analog power	+10V, 50mA
	AI1	Multifunction Analog input signal 1	JP5 cut/JP3 1-2: -10V~+10V JP5 cut/JP3 2-3: 0~10V JP5 connect: 0~20mA can be regulated o00/o01 Set the input voltage / current range o06/o07 Set the input signal corresponding to set value
	AI2	Multifunction Analog input signal 2	JP6cut: 0~10V JP6connect: 0~20mA can be regulated o02/o03can set input voltage/ current arrange o08/o09 Set the input signal corresponding to set value
	AI3	Multifunction Analog input signal 3	JP7cut: 0~10V JP7connect: 0~20mA can be regulated o04/o05can set input voltage/ current arrange o10/o11 Set the input signal corresponding to set value
	DA1	More function analog output 1	JP1 1-2: 0~20mA JP1 2-3: 0~10VDC o15 Set analog output analog functions o17/o18set the output signal arrange

	DA2	More function analog output 2	JP2 1-2: 0~20mA JP2 2-3: 0~10VDC o16 Set analog output analog functions o19/o20 set the output signal arrange
--	-----	-------------------------------	--

2-5-2. Control circuit terminal

1. 8KLCB Control circuit terminal


TA1 TC1 TB1 COM DI8 DI7 DI6 DI5 DI4 DI3 DI2 DI1 +10V DA1 GND



TA2 TC2 TB2 SPA SPB COM+24V PLC COM AI3 AI2 AI1 +10V DA2 GND

2. 8KSCB Control circuit terminal

TC1 TB1 COM SPA DI5 DI3 DI1 COM PLC +24V+10V GND



TA1 COM SPB DI6 DI4 DI2 AI3 AI2 AI1 DA1 DA2 GND

2-6. Connection Precautions

- ※ Don't install power factor capacitance or resistance-capacitance absorbing device between the output terminals U, V, W of the frequency inverter.
- ※ To disassemble or replace the motor, the input power supply must be turned off for the frequency inverter.
- ※ Do not drop Metal scrap foam or lint into the frequency inverter, otherwise the machine will be faulted.
- ※ The motor or power supply can be switched on/off only after the inverter stops its output.
- ※ In order to minimize the effect of electromagnetic interference, a surge absorbing device should be installed if used electromagnetic contactor and relay, etc. is near to the frequency inverter.
- ※ For external control of frequency inverter, a isolation device should be used for the control lines or screened cable should be used.
- ※ A screened cable should be used as the signal connection line for input command and must be routed separately as well, and it is better be installed far from the main circuit.
- ※ When the carrier frequency is less than 3kHz, the distance between the frequency inverter and motor must not be greater than 50 meters (maximum). When it is above 4kHz, this distance should be reduced. The cable for this connection had better be laid in metal conduit.
- ※ If the frequency inverter is equipped with peripheral devices (such as filter, reactor), first measure its insulation resistance to the earth with 1000V megohm meter, and ensure the resistance value is not below 4MΩ.

- ※ If the frequency inverter must be started frequently, don't switch off its power supply, and the operator must start or stop the inverter by using the COM/FWD of the control terminal or Keyboard or RS485, in order to avoid damage to the bridge rectifier.
- ※ Don't connect A.C. input power to the output terminals U, V, W of the frequency inverter.
- ※ In order to prevent unexpected accidents, earthing terminal E or \perp must be grounded to the earth securely (the grounding resistance should be below 100Ω). The cable size should be greater than half of below- mentioned corresponding cable size; otherwise current leakage will happen possibly.
- ※ For wiring of main circuit, please refer to national rule.
- ※ Capacity of the motor should be equal to or smaller than that of the inverter.
- ※ Specification of MCCB、 electric cable and contractor

Type	MCCB(A)	In/out Cable (Copper Core)mm ²	Rated Operational Current Of Contractor A(voltage:380V or 220V)
PI8100 R40G2	10A	1.5	10
PI8100 R75G2	16A	2.5	10
PI8100 1R5G2	20A	2.5	16
PI8100 2R2G2	32A	4	20
PI8100 004G2	40A	6	25
PI8100 5R5G2	63A	6	32
PI8000 7R5G2	100A	10	63
PI8000 011G2	125A	10	95
PI8000 015G2	160A	25	120
PI8000 018G2	160A	25	120
PI8000 022G2	200A	25	170
PI8000 030G2	200A	35	170
PI8000 037G2	250A	35	170
PI8000 045G2	250A	70	230
PI8000 055G2	315A	70	280
PI8000 R75G3	10A	1.5	10
PI8000 1R5G3	16A	1.5	10
PI8000 2R2G3	16A	2.5	10
PI8000 004G3	25A	2.5	16
PI8000 5R5G3	25A	4	16
PI8000 7R5G3	40A	4	25
PI8000 011G3	63A	6	32
PI8000 015G3	63A	6	50
PI8000 018G3	100A	10	63
PI8000 022G3	100A	10	80
PI8000 030G3	125A	16	95


Section II Intallation & Standby Circuit

PI8000	037G3	160A	25	120
PI8000	045G3	200A	35	135
PI8000	055G3	250A	35	170
PI8000	075G3	315A	70	230
PI8000	093G3	400A	70	280
PI8000	110G3	400A	95	315
PI8000	132G3	400A	95	380
PI8000	160G3	630A	150	450
PI8000	187G3	630A	185	500
PI8000	200G3	630A	240	580
PI8000	220G3	800A	150*2	630
PI8000	250G3	800A	150*2	700
PI8000	280G3	1000A	185*2	780
PI8000	315G3	1200A	240*2	900
PI8000	355G3	1280A	240*2	960
PI8000	400G3	1380A	185*3	1035
PI8000	500G3	1720A	185*3	1290

2-7. Standby circuit

When the fault or trip of the inverter may cause great loss or accident, please add the standby circuit.


Note:confirm and test the running characteristic of the standby circuit, in order to ensure the industrial phase and the converter phase are in the same direction.



Section III. Operating Keyboard


2-8. Operating keyboard

3-1-1. JP6E8000 specification and function description(Standard)




3-1-2. JP6C8000 keyboard specification and function description(Optional)

Section III



3-2-2. Parameter upload to the keyboard

Parameter Item	Description	
y01 parameter upload to the keyboard	N function	0
	System parameter upload to the memory area1 in the keyboard	1
	System parameter upload to the memory area2 in the keyboard	2
	System parameter upload to the memory area3 in the keyboard	3
	System parameter upload to the memory area4 in the keyboard	4
	Clear memory area in the keyboard1, 2, 3, 4	5




Example . System parameter upload to the memory area3 in the keyboard

1. Under monitoring status, press **PRG** into parameter group to check status;
2. Through **potentiometer** Switch to **y00-23 System FG**;
3. Press **PRG**, or **ENTER**, enter into **y00-23 System FG** parameter group to check status;
4. Through **potentiometer** Switch to **y01P Upload To K**;
5. Press **PRG**, or **ENTER**, enter into **y01P Upload To K** parameter modify status;
6. Through **potentiometer** adjust value to be 3 ;
7. Finish the adjustment, press **SET**; the speed for upload will display on the LED; if cancel the change, press **ESC**, to escape to the modification status;
8. Press **ESC**, to exit to previous menu.


3-2-3. Reset system parameters

Parameter Item	Description	
y00 Reset system parameters	N function	0
	memory area1 in the keyboard to reset system parameter	1
	memory area2 in the keyboard to reset system parameter	2
	memory area3 in the keyboard to reset system parameter	3
	memory area4 in the keyboard to reset system parameter	4
	Use the factory setting reset system parameter	5

**Example 1: memory area3 in the keyboard 1 to reset system parameter**

- Under monitoring status, press **PRG** into parameter group to query status
- Through **potentiometer** Switch to **y00-23 System FG**;
- Press **PRG**, or **ENTER**, enter into **y00-23 System FG** parameter group to query status;
- Through **potentiometer** Switch to **y01P Upload To K**;
- Press **PRG**, or **ENTER**, enter into **y00 Reset SP** parameter modify status;
- Through **potentiometer** adjust to 3 ;
- Finish the adjustment, press **SET**, the speed for download will display on the LED; if cancel the change, press **ESC** ;
- Press **ESC** , to exit to previous menu.

Example 2 Clear memory area 1, 2, 3, 4 in the keyboard



- Under monitoring status, press **PRG** into parameter group to check status
- Through **potentiometer** Switch to **y00-23 System FG**;
- Press **PRG**, or **ENTER**, enter into **y00-23 System FG** parameter group to check status;
- Through **potentiometer** Switch to **y01P Upload To K**;
- Press **PRG**, or **ENTER**, enter into **y01P Upload To K** parameter modify status;
- Through **potentiometer** adjust to 5 ;
- Finish the adjustment, press **SET**; the speed for Clear memory area will display on the LED; if cancle the change, press **ESC**;
- Press **ESC**, to exit to previous menu.

3-2-4. F02 the main set mode of set frequency is set to 4, keyboard potentiometer setting !

- Under monitoring status, Through **potentiometer** adjust the frequency, the resolution ratio potentiometer is 0.05Hz.
- Range of set frequency can be set with the following parameters:

Parameter item	Description
F12 max. frequency	Inverter output maximum frequency allowed Setting range: 10.00~320.00Hz

A45 keyboard potentiometer setting X1	Keyboard potentiometer setting the start value Setting range: 0~100%
A46 keyboard potentiometer setting X2	Keyboard potentiometer setting the end value Setting range: 0~100%
A47 keyboard potentiometer setting value	Display the value of potentiometer setting, range: A45~A46 Also can set directly, Setting range: A45~A46
A48 keyboard potentiometer setting X1 correspond to Y1	Keyboard potentiometer setting the starting point for the corresponding value Setting range: -100%~+100%
A49 keyboard potentiometer setting X2 correspond to Y2	Keyboard potentiometer settings corresponding to the value of the end Setting range: -100%~+100%
S00 setting frequency	Displays the current size of the set frequency,through the potentiometer setting Setting range: F12*A48~ F12*A49

Example:

F12=50.00Hz, A45=0%, A46=100%, A47 Shows the value of potentiometer settings 0%~100%, Numerical size can be adjusted by potentiometer.

- (1) when A48=0%, A49=+100%, S00 Set Fre. range 0.00Hz~50.00Hz.
- (2) when A48=0%, A49=+50%, S00 Set Fre. range 0.00Hz~25.00Hz.
- (3) when A48=-100%, A49=+100%, S00 Set Fre. range -50.00Hz~50.00Hz.

Note: when the motor is in -50.00~0Hz realise reverse, another setting

F45 Ten bit motor forward inverse as

1 Command priority: Analog given positive and negative values, on the F45 details refer to F45 Parameter Description

3-2-5. F02 the main set mode of set frequency is set to 1, All external analog given.

1. Under monitoring status, Through external analog input terminal All adjust the frequency, the resolution ratio is 0.01Hz.
2. Set the frequency range can be set with the following parameters:

Parameter Item	Description
F12 most frequency	Inverter speed adjustment's allowed maximum output frequency Setting range: 10.00~320.00Hz
o00 All input X1	Keyboard potentiometer setting the start value Setting range: 0~100%
o01 All input X2	Keyboard potentiometer setting the end value Setting range: 0~100%
o06 All input X1 correspond to Y1	Keyboard potentiometer setting the starting point for the corresponding value Setting range: -100%~+100%
o07 All input X2 correspond to Y2	Keyboard potentiometer settings corresponding to the value of the end Setting range: -100%~+100%
S00 frequency setting	Display the frequency,Through out analog input terminal All adjust the frequency

Section III Operating Keyboard

Setting range: F12*o06~ F12*o07

Example:

F12=50.00Hz, o00=0%, o01=100%,

(1) When o06=0%, o07=+100%, S00 Set Fre. range 0.00Hz~50.00Hz.

(2) When o06=0%, o07=+50%, S00 Set Fre. range 0.00Hz~25.00Hz.

(3) When o06=-100%, o07=+100%, S00 Set Fre. range -50.00Hz~50.00Hz.

Note: When realize the motor reverse in -50.00~0Hz.


F45Ten bit motor forward reverse as


1 Command priority: Analog given positive and negative values, on the F45 details see F45

Parameter Description

Section IV. Test Running

- Failure occurred when test running, Please take reference of fault diagnosis in 6-1 to get rid of the breakdown
- Inverter parameters have a strong adaptive ability, in general $b11 = 1$ calculation of electrical parameters with the name plate, on this basis, a little manual adjustment can get you high-performance vector control.
- Only when the motor completely without the load can set $b11=3$ motor rotation measurements
- Before the electrical parameter measurement finished, inverter can have the output voltage any time, please ensure the safety.





Section V Parameter Function Table

Notice: ★ mean that the factory setting value of the parameter is according to the power and model. The exact value is referred to the Parameter Function Table. Change limited mean that whether it can be modified while running.

5-1. Functional parameter list

5-1-1. Menu Group

Code	Description / LCD	Function Description	Group ID	Reference page
S	Monitor Function Group	Monitor frequency, current and other 16 monitor objects	0B	53
F	Basic Function Group	Frequency setting, control mode, acceleration time and deceleration time	00	54
A	User Function Group	Monitor, protection, communication setting	01	69
o	IO Function Group	Analog, digital input, output function	02	81
H	Multi-speed PLC Group	Multi-speed running, PLC running	03	99
U	V/F parameter Group	User defined V/F curve	04	107
P	PID Function Group	Internal PID parameter setting	05	108
E	Extend Function Group	Constant pressure water supply and other functions setting	06	111
C	Speed ring function group	Current ring, speed running, PG parameter	07	117
b	Motor parameter group	Motor parameter setting	08	122
y	System Function Group	Parameter reset, fault query, product information, parameter protection	09	124

5-1-2. Monitor function: S00-S15(0x0B00-0x0B0F)

Code	Description / LCD	Setting Range	Factory Setting	Change Limited	Reference page
S00	Setting Frequency	current inverter real setting frequency	-	N	54
S01	Real Frequency	current inverter real output frequency	-	N	54
S02	Motor real Current	Valid value of motor actual current	-	N	54
S03	Percentage of Motor Current	The percentage of actual motor current and rated current	-	N	54
S04	DC Bus Voltage	Detection value of DC bus voltage	-	N	54
S05	The Output Voltage	The real output voltage	-	N	54
S06	Motor Real Speed	Motor real running speed	-	N	54
S07	Total Running Time	The total running time for every time	-	N	54
S08	IGBT Temperature °C	Test the temperature of IGBT in the frequency	-	N	55
S09	PID Set Point	PID Adjust run-time values of the percentage of a given	-	N	55
S10	PID Feedback	PID Adjust run-time values of the percentage of feed back	-	N	55

Section V Parameter Function Table

S11	Motor Output Frequency	The percentage of actual output power of motor	-	N	55
S12	Excitation Heft Set Value	Motor's set excitation heft percentage	-	N	55
S13	Excitation Heft Actual Value	Motor's actual excitation heft percentage	-	N	55
S14	Torque Heft Set Value	Motor set torque percentage	-	N	55
S15	Torque Heft Actual Value	Motor actual torque hefts percentage	-	N	55

5-1-3. Basic function Group:F00-F50(0x0000-0x0032)

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page
F00	Control Mode	V/Fcontrol	0	0	N	55
		Sensorless vector control	1			
		Sensor feedback close loop vector control	2			
F01	Keyboard Setting Frequency	Lower frequency~upper frequency		50.00	Y	55
F02	Frequency Main Set Mode	Keyboard setting frequency or RS485	0	0	Y	55
		A11 the external analog setting	1			
		A12 the external analog setting	2			
		A13 the external analog setting	3			
		Keyboard potentiometer setting	4			
		Multi-segment digital voltage setting	5			
Digital Pulse Setting	6					
F03	Auxiliary Setting Mode Of Frequency	Keyboard setting frequency or RS485	0	0	Y	56
		A11 the external analog setting	1			
		A12 the external analog setting	2			
		A13 the external analog setting	3			
		Keyboard potentiometer setting	4			
		Multi-segment digital voltage setting	5			
		Digital Pulse Set	6			
PID regulation mode	7					
F04	The Relationship Between Main And Auxiliary Setting Frequency	The main setting individual control	0	0	Y	57
		The auxiliary setting individual control	1			
		main + auxiliary	2			
		main -auxiliary	3			
		(main *auxiliary)/maximum frequency	4			

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page	
		Maximum { main, auxiliary }	5				
		Minimum { main, auxiliary }	6				
F05	Running Control Mode	Keyboard+Rs485/CAN	0	0	Y	58	
		Keyboard+terminal+Rs485/CAN	1				
		Rs485/CAN	2				
		Terminal control	3				
		The proportion linkage control	4				
F06	V/F Boost Mode	1 bit	Beeline V/Fcurve	0	0000	N	59
			Power of 1.2 V/Fcurve	1			
			Power of 1.7 power V/Fcurve	2			
			Power of 2 powerV/Fcurve	3			
			Define mode V/Fcurve	4			
		10 bit	Close Automatic torque boost	0			
			Automatic orqueboost	1			
		100 bit	VF mode 0 Speed No Output	0			
			VF mode keep 0 speed	1			
F07	Torque boost Value	0.0~30.0%		0.0	Y	59	
F08	Torque Boost Cut-off Frequency	0.00~Maximum frequency		15.00	Y	59	
F09	Accelerate Time	0.0~3200.0		10.0	Y	60	
F10	Decelerate Time	0.0~3200.0		10.0	Y	60	
F11	Percentage Of Output Voltage	50~110		100	Y	60	
F12	Maximum Frequency	10.00~320.00		50.00	N	60	
F13	Lower Frequency	0.00~Upper frequency		0.00	N	60	
F14	Upper Frequency	Lower frequency~Upper frequency		50.00	N	60	
F15	Basic Frequency	5.00~Maximum frequency		50.00	N	61	
F16	Carrier Frequency	1.0~16.0		★	Y	61	
F17	Carrier Frequency Adjustment Range	0.0~4.0		0.0	Y	62	
F18	Carrier Frequency Adjustment Mode	1 bit	No automatic adjustment	0	00	Y	62
			automatic adjustment Mode	1			
		10 bit	automatic adjustment, Fixed mode	0			
			automatic adjustment, random mode	1			
F19	Waveform Generation	Asynchronous space-vector		0	N	62	

Section V Parameter Function Table

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page	
	Mode	PWM					
		Stepless & subsection synchronous space vector PWM	1				
		two-phase optimization space vector PWM	2				
F20	S Curve Start Time At The Acceleration Step	0.0~50.0		0.0	Y	62	
F21	S Curve Stop Time At The Acceleration Atep	0.0~50.0		0.0	Y	62	
F22	S Curve Start Time At The Deceleration Step	0.0~50.0		0.0	Y	62	
F23	S Curve Stop Time At The Deceleration Step	0.0~50.0		0.0	Y	62	
F24	V/F Control Slip Compensation	slip compensation invalid	0	0	N	63	
		slip compensation valid	1				
F25	Minimum Running Frequency	0.00~maximum frequency		0.00	N	63	
F26	DC Braking Current When Starting	0~135		100	Y	64	
F27	Braking Time When Starting	0.0~60.0		0.0	Y	64	
F28	Stop When The DC Braking Current	0~135		100	Y	64	
F29	Stop And Braking Wait Time	0.0~60.0		0.0	Y	64	
F30	Brake Time Stop	0.0~60.0		0.0	Y	64	
F31	Stop And Brake Starting Frequency	0.00~most frequency		0.00	Y	64	
F32	Stop Setting Mode	Deceleration stop	0	0	N	65	
		Free stop	1				
F33	Jog Acceleration Time	0.0~3200.0		1.0	N	65	
F34	Jog Deceleration Time	0.0~3200.0		1.0	N	65	
F35	Jog Mode Setting	1 bit	Jog direction: forward	0	000	N	65
			Jog direction: reverse	1			
			Jog direction: direction determined by the main terminal	2			
		10 bit	Jog end mode: Stop Running	0			
			Jog end mode:reset to the former state before jog	1			
100 bit	Jog end and acceleration deceleration time: reset	0					

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page	
			to the set acceleration and deceleration time before jog				
			Jog end and acceleration deceleration time:save the set acceleration and deceleration time before jog	1			
F36	Jog Frequency Setting	Lower frequency ~upper frequency		6.00	Y	66	
F37	Skip Frequency1Limit	0.00~Maximum frequency		0.00	Y	66	
F38	Skip Frequency1Upper	0.00~Maximum frequency		0.00	Y	66	
F39	Skip Frequency2Limit	0.00~Maximum frequency		0.00	Y	66	
F40	Skip Frequency2Upper	0.00~Maximum frequency		0.00	Y	66	
F41	Skip Frequency3Limit	0.00~Maximum frequency		0.00	Y	66	
F42	Skip Frequency3Upper	0.00~Maximum frequency		0.00	Y	66	
F43	Preset Frequency	0.00~Max frequency		0.00	Y	67	
F44	Preset Frequency Working Time	0.0~60.0		0.0	Y	67	
F45	Motor Running Direction	1 bit	Direction command: forward command FWD let motor forward running	0	0100	N	67
			Direction command: forward command FWD let motor reverse running	1			
		10 bit	Command prior: terminal/keyboard	0			
			Prior command: Analog given positive and negative values	1			
		100 bit	Reverse allow: reverse forbidden	0			
			Reverse allow: reverse allow	1			
F46	Pass 0 Stopping Time	0.0~60.0s		0	N	67	
F47	Frequency Multiple Setting	*1		0	0	N	68
		*10		1			
F48	Acceleration And Deceleration Configuration Word	1 bit	N adjustment of acceleration time	0	0000	N	68
			A11 adjustment of the external analog giving	1			
			A12 adjustment of the external analog giving	2			

Section V Parameter Function Table

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page	
			AI3 adjustment of the external analog giving	3			
			Adjustment of keyboard potentiometer giving	4			
			Adjustment of Multi steps digital voltage giving	5			
		10 bit	N adjustment of deceleration time	0			
			AI1 adjustment of the external analog giving	1			
			AI2 adjustment of the external analog giving	2			
			AI3 adjustment of the external analog giving	3			
			Adjustment of keyboard potentiometer giving	4			
			Adjustment of Multi steps digital voltage giving	5			
			100 bit	Acceleration time:*s			0
		Acceleration time:*min		1			
		Acceleration time:*h		2			
		Acceleration time:*day		3			
		1000 bit	Deceleration time:*s	0			
			Deceleration time:*min	1			
			Deceleration time:*h	2			
Deceleration time:*day	3						
F49	Running Configuration Word	1 bit	Running direction: forward	0	0000	N	69
			Running direction:reverse	1			
		10 bit	Running time: *S	0			
			Running time: *Min	1			
			Running time: *H	2			
			Running time: *Day	3			
F50	Energy Saving Running Percentage	30~100		100	N	70	

5-1-4. User Function Group:A00-A55(0x0100-0x0137)

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page
		Parameter group N:	parameter group N			
A00	Monitor 1	Parameter group N: X1000/X100 00~0B	parameter group N	0B00	Y	70
A01	Monitor 2		X10/ bit	0B01	Y	
A02	Monitor 3		0~63(0x00~0x3F)	0B02	Y	
A03	Over /Less Voltage Stall Protection	N	0	1	Y	71
		Y	1			
A04	Overvoltage Stall Protection Voltage	110%~140%(Standard bus voltage)		120	Y	71
A05	Auto Stabilize Voltage	Invalid	0	0	Y	71
		Valid	1			
		Valid, unless for deceleration	2			
A06	Dynamic Braking option	Invalid	0	0	Y	71
		Security Type	1			
		General Type	2			
A07	Hysteresis voltage	0~10%		2	Y	72
A08	Dynamic Braking Voltage	110%~140%(Standard bus voltage)		130	Y	72
A09	Less Voltage Level	60%~75%(Standard DC bus voltage)		70	Y	72
A10	Power-down Tracking Options	N	0	0	Y	72
		Power-off tracking mode	1			
		Startup tracking mode	2			
A11	Power-down tTracking Time	0.0~20.0		0.0	Y	72
A12	Power Down Frequency Drop Point	65~100%(standard DC bus voltage)		75	Y	73
A13	Power Down Frequency Drop Time	0.1~3200.0		5.0	Y	73
A14	Current Limit	N	0	0	Y	73
		Y	1			
A15	Limit Fall Time	0.1~3200.0		10.0	Y	73
A16	Limit Deceleration Protection Point	10~250		★	Y	73
A17	Limit Fix-speed Protection Point	10~250		★	Y	73
A18	Output Phase Lose Protection	N protection of phase lost	0	0	Y	73
		Warning and constant running	1			
		Warning and deceleration	2			
		Warning and free stopping	3			
A19	Grade Of Phase Lose Protection	10~100		30	Y	74
A20	Over Torque Inspected	N torque inspection	0	0	Y	74

Section V Parameter Function Table

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page
	Action	Warning and running	1			
		Warning and decelerating stop	2			
		Warning and free stopping	3			
A21	Over Torque Grade	10~250		★	Y	74
A22	Over Torque Inspection Time	0.0~60.0		0.1	Y	74
A23	Electronic Thermal Relay Protection Selection	N	0	1	Y	74
		Y	1			
A24	Electronic Thermal Protection Grade	120~250		★	Y	74
A25	Fault Reset Times	0~10		0	Y	75
A26	Fault Reset Time	0.5~20.0		1.0	Y	75
A27	Fan Startup Temperature	0.0~60.0		0.0	Y	75
A28	This Inverter Communication Address	1~128		8	Y	75
A29	Baud Rate	Baud rate is 1200	0	4	Y	75
		Baud rate is 2400	1			
		Baud rate is 4800	2			
		Baud rate is 9600	3			
		Baud rate is 19200	4			
		Baud rate is 38400	5			
A30	Communication Format	8, N, 1 for RTU	0	0	Y	76
		8, N, 2 for RTU	1			
		8, E, 1 for RTU	2			
		8, O, 1 for RTU	3			
		8, E, 2 for RTU	4			
		8, O, 2 for RTU	5			
A31	Communications Troubleshooting	N warning for communication fault	0	0	Y	76
		Warning and running	1			
		Warning and decelerating stop	2			
		Warning and free stopping	3			
A32	Delay Inspection Time	0: N inspection		10	Y	76
		1~250: late inspection				
A33	Total Running Time Setting	Auto clear to zero after power on	0	1	Y	76
		Continue to accumulate running time after power on	1			
A34	Unit Of Total Running Time	hour	0	0	Y	76
		Day	1			

Section V Parameter Function Table

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page	
A35	Motor Output Speed Adjustment	0.1~1000.0		100.0	Y	76	
A36	Adjustment Of Motor Output Power	0.1~1000.0		100.0	Y	76	
A37	Keyboard Lock Function Options	0~0FF		0FF	Y	77	
A38	UP/DN Control	1 bit	Power down to save	0	0000	Y	77
			Power down to clear saving	1			
		10 bit	saving after stopping	0			
			Stop command to clear saving	1			
			Cleared at the end of stopping	2			
		100 bit	One-direction adjustment	0			
			Double-direction adjustment	1			
		1000 bit	Invalide adjustment	0			
Valide adjustment	1						
A39	UP/DN Time	1 bit	UP fix speed	0	0000	N	78
			UP fix times	1			
		10 bit	DN fix speed	0			
			DN fix times	1			
		100 bit	UP N adjustmentof speed ratio	0			
			A11 adjustment of the external analog giving	1			
			A12 adjustment of the external analog giving	2			
			A13 adjustment of the external analog giving	3			
			adjustment of Potentiometer giving	4			
		1000 bit	Adjustment of multi -steps digital voltage	5			
			DN N adjustmentof speed ratio	0			
			A11 adjustment of the external analog giving	1			
			A12 adjustment of the external analog giving	2			
			A13 adjustment of the external analog giving	3			
		adjustment of Potentiometer giving	4				

Section V Parameter Function Table

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page	
		Adjustment of multi-steps digital voltage	5				
A40	UP/DN Adjustment Value	-300.00~300.00		0.00	N	79	
A41	UP Adjustment Ratio	0.01~20.00		0.01	Y	79	
A42	DN Adjustment Ratio	0.01~20.00		0.01	Y	79	
A43 A44	The Definition Of Multifunction Keys MF1 And MF2	MF is defined as adding function key	0	0 1	Y Y	79	
		MF is defined as reducing function key	1				
		MF is defined as free stopping key	2				
		MF is defined as FWD running key	3				
		MF is defined as REV running key	4				
		MF is defined as forward JOG function key.	5				
		MF is defined as reverse JOG function key.	6				
		MF is defined as JOG function key	7				
		MF is defined as UP function key	8				
		MF is defined as Down function key.	9				
		UP / DN adjusted value reset	10				
keyboard potentiometer setting value resey	11						
A45	Keyboard Potentiometer X1	0~100.0		0.0	Y	80	
A46	Keyboard PotentiometerX2	0~100.0		100.0	Y	80	
A47	The Value Of Keyboard Potentiometer Set	0.0~100.00		-	Y	81	
A48	Keyboard Potentiometer X1 Corresponding Value Y1	-100.0~100.0		0.00	Y	81	
A49	Keyboard Potentiometer X2 Corresponding Value Y2	-100.0~100.0		100.00	Y	81	
A50	Keyboad Potentiometer Control	1 bit	Saving after power down	0	0000	Y	81
			Cleared after power down	1			
		10 bit	Saving after stoppoing	0			
			Clear saving after stopping command	1			
		100 bit	Clear saving at end of stopping	2			
			Reserved				
1000 bit	Reserved						
A51	Temperature Adjustment Of Motor	0.0~200.0		100.0	N	81	

Code	Description / LCD	Setting Range	Factory Setting	Change Limited	Reference page	
A52	Over-heat Temperature Of Motor	0.0~300.0	120.0	N	81	
A53	Reaction For Motor Over-heat	N reaction for motor over-heat	0	0	Y	82
		Warning and runing	1			
		Warning and deceleration stopping	2			
		Warning and free stopping	3			
A54	Display of motor temperature	-50.0~300.0	-	N	82	
A55	Proportion of Linkage Ratio	0.10~10.00	1.00	Y	82	

5-1-5.10 function group:o00-o68(0x0200-0x0244)

Code	Description / LCD	Setting Range	Factory Setting	Change Limited	Reference page	
o00	AI1 Input X1	0~100.0	0.0	Y	82	
o01	AI1 Input X2	0~100.0	100.0	Y	82	
o02	AI2 Input X1	0~100.0	0.0	Y	82	
o03	AI2 Input X2	0~100.0	100.0	Y	82	
o04	AI3 Input X1	0~100.0	0.0	Y	82	
o05	AI3 Input X2	0~100.0	100.0	Y	82	
o06	AI1 Input X1 Corresponding Value Y1	-100.0~100.0	0.0	Y	82	
o07	AI1 Input X2 Corresponding Value Y2	-100.0~100.0	100.0	Y	82	
o08	AI2 Input X1 Corresponding Value Y1	-100.0~100.0	0.0	Y	82	
o09	AI2 Input X2 Corresponding Value Y2	-100.0~100.0	100.0	Y	82	
o10	AI3 Input X1 Corresponding Value Y1	-100.0~100.0	0.0	Y	82	
o11	AI3 Input X2 Corresponding Value Y2	-100.0~100.0	100.0	Y	82	
o12	AI1 Input Filter Time	0.00~2.00	0.10	Y	84	
o13	AI2 Input Filter Time	0.00~2.00	0.10	Y	84	
o14	AI3 Input Filter Time	0.00~2.00	0.10	Y	84	
o15 o16	DA1 Output Terminal DA2 Output Terminal	N reaction	0	-	Y	84
		Setting frequency	1			
		Actual frequency	2			
		Actual current	3			
		Output voltage	4			
		DC bus voltage	5			

Section V Parameter Function Table

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page
		IGBT temperature	6			
		Output power	7			
		Output RPM	8			
		Actual value of torque	9			
o17	DA1 Adjustment Of Lower Limit Output	0.0~100.0		0.0	Y	84
o18	DA1 Adjustment Of Upper Limit Of Output	0.0~100.0		100.0	Y	84
o19	DA2 Adjustment Of Lower Limit Output	0.0~100.0		0.0	Y	84
o20	DA2 Adjustment Of Upper Limit Output	0.0~100.0		100.0	Y	84
		No function	0			
		Fault warning	1			
		Over current inspection	2			
		Over load inspection	3			
		Over voltage inspection	4			
		Less voltage inspection	5			
		Low load inspection	6			
		Over heat inspection	7			
		Running state with command	8			
		Abnormal PID feedback signal	9			
		Motor state of REW running	10			
		Arrival of setting the frequency	11			
o21	O1 Output Signal Option 1	Arrival of Upper frequency	12	0	Y	
o22	O2 Output Signal Option 2	Arrival of Lower frequency	13	0	Y	
o23	O3 Output Signal Option 3	Arrival of FDT setting frequency 1	14	1	Y	
o24	O4 Output Signal Option 4	Arrival of FDT setting frequency 2	15	8	Y	
		FDT frequency level inspection	16			
		Arrival of preset counter value	17			
		Arrival of upper limit counter	18			
		Program running one period completed	19			
		Speed tricking mode inspection	20			
		No command running state	21			
		REV running from inverter command	22			
		Deceleration running	23			
		Acceleration running	24			

Section V

Section V Parameter Function Table

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page	
		Arrival of high pressure	25				
		Arrival of low pressure	26				
		Arrival of inverter rate current	27				
		Arrival of motor rate current	28				
		Arrival of input frequency lower limitation	29				
		Arrival of current upper limitation	30				
		Arrival of current lower limitation	31				
		Time to reach limit time 1	32				
		Time to reach limit time 2	33				
		Inverter ready to run	34				
o25	Output Signal Delay 1	0~32.000		0	Y	87	
o26	Output Signal Delay 2	0~32.000		0	Y	87	
o27	Output Signal Delay 3	0~32.000		0	Y	87	
o28	Output Signal Delay 4	0~32.000		0	Y	87	
o29	FDT Set Frequency 1	o30~Max frequency		0.00	Y	87	
o30	FDT Set Frequency 2	0~o29		0.00	Y	87	
o31	FDT Inspection Range	0.00~5.00		0.00	Y	87	
o32	Arrival Of Current Upper Limitation	o33~200%		120	Y	88	
o33	Arrival Of Current Lower Limitation	o34~o32		20	Y	88	
o34	Current Inspection Range	0~o33		3	Y	88	
o35	Terminal Control Mode	1 bit	Two-wire running control 1	0	0000	N	89
			Two-wire running control 2	1			
			Three-wire running control 1	2			
			Three-wire running control 2	3			
			One-shot operation control 1	4			
			One-shot operation control 2	5			
		10 bit	Terminal command is invalid after power on running	0			
			Terminal command is valid after power on running	1			
o36	(DI1) Input Terminal	No function		0	0	Y	91

Section V Parameter Function Table

Code	Description / LCD	Setting Range	Factory Setting	Change Limited	Reference page
o37	Function Selection	Forward running FWD	1	0	Y
o38	(DI2) Input Terminal	Reverse running REV	2	0	Y
o39	Function Selection	3-line mode running STOP	3	0	Y
o40	(DI3) Input Terminal	Multi-segment command 1	4	0	Y
o41	Function Selection	Multi-segment command 2	5	0	Y
o42	(DI4) Input Terminal	Multi-segment command 3	6	0	Y
o43	Function Selection	Multi-segment command	7	0	Y
o44	(DI5) Input Terminal	Multi-segment speed command 1	8	0	Y
o45	Function Selection	Multi-segment speed command	9	0	Y
o46	(DI6) Input Terminal	Multi-segment speed command 3	10	0	Y
	Function Selection	Multi-segment digital voltage 1	11		
	(DI7) Input Terminal	Multi-segment digital voltage 2	12		
	Function Selection	Multi-segment digital voltage 3	13		
	(DI8) Input Terminal	The main set mode 1 of set frequency	14		
	Function Selection	The main set mode 2 of set frequency	15		
	(AI1) Input Terminal	The main set mode 3 of set frequency	16		
	Function Selection	The auxiliary setting mode 1 of frequency set	17		
	(AI2) Input Terminal	The auxiliary setting mode 2 of frequency set	18		
	Function Selection	The auxiliary setting mode 3 of frequency set	19		
		MSS time running 1	20		
		MSS time running 2	21		
		MSS time running 3	22		
		Operation control mode shift 1	23		
		Operation control mode shift 2	24		
		Operation control mode shift 3	25		
		Forward torque limit shift 1	26		
		Forward torque limit shift 2	27		
		Forward torque limit shift 3	28		
		Reverse torque limit shift 1	29		
		Reverse torque limit shift 2	30		
		Reverse torque limit shift 3	31		
		Torque speed shift	32		
		fault reset command	33		

Code	Description / LCD	Setting Range	Factory Setting	Change Limited	Reference page
		FWD JOG command	34		
		REV JOG command	35		
		JOG order (as F35setting)	36		
		Acceleration and deceleration prohibition command	37		
		Motor 1、 2 shift	38		
		Free stop	39		
		Up command	40		
		Down command	41		
		Automation program running fuction cancel	42		
		Automation program running stop	43		
		Program running start mode	44		
		Program running stop mode	45		
		Pulse counter clearance	46		
		Pulse counter input	47		
		Counter loading	48		
		Upper counter loading	49		
		External default signal input (level)	50		
		1 pump soft-start	51		
		1 pump stop	52		
		2 pump soft-start	53		
		2 pump stop	54		
		3 pump soft-start	55		
		3 pump stop	56		
		4 pump soft-start	57		
		4 pump stop	58		
		handrotate command	59		
		Timing Water Supply change to zero	60		
		Extruder acceleration and deceleration direction	61		
		Extruder acceleration and deceleration allowable	62		
		Limit time 1 input	63		
		Limit time 2 input	64		
		Program switching to the next segment	65		
		UP/DN adjusted value reset	66		

Section V Parameter Function Table

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page	
		Keyboard potentiometer set value reset	67				
		External default signal input (edge)	68				
o47	Polarity of input and output terminals	0000~F7FF		0000	Y	96	
o48	Input Terminal Teponse Time 0	0.001~30.000		0.005	Y	96	
o49	Input Terminal Reponse Time 1	0.001~30.000		0.005	Y	96	
o50	Input Terminal Reponse Time Selection	0~07FF		0	Y	96	
o51	Counter Collocation	1 bit	Circle counter operating	0	0	Y	97
			Single cycle counter running	1			
		10 bit	Arrive at upper counter value and reload	0			
			Arrive at upper counter value and clear savings	1			
		100 bit	Power on to reload	0			
			power on to clear savings	1			
			power on to keep previous count status	2			
		1000 bit	Count period	0			
			Output signal valid time 20ms	1			
			Output signal valid time 100ms	2			
		Output signal valid time 500ms	3				
o52	Maximum Pulse Input Frequency	0.1~50.0		20.0	Y	97	
o53	Current Counter Status	0~9999		0	Y	98	
o54	Preset Counter Setting	0~ o55		0	Y	98	
o55	Upper Limit Counter Setting	o54~9999		9999	Y	98	
o56	Virtual Terminal Effective Selection	0000~F7FF		0000	Y	98	
o57	DII~4 Terminal Status	0000~1111		-	Y	99	
o58	DI5~8 Terminal Status	0000~1111		-	Y	99	
o59	AII~3 Terminal Status	000~111		-	Y	99	
o60	OI~4 Terminal Status	0000~1111		-	Y	99	
o61	PLI Pulse Output	No action	0	0	Y	99	

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page	
o62	PL2 Pulse Output	Set frequency	1	0	Y		
		Actual frequency	2				
		Actual current	3				
		Output voltage	4				
		DC bus voltage	5				
		IGBT temperature	6				
		Output power	7				
		Output rpm	8				
		Actual torque	9				
o63	SPA pulse output ratio	1~1000		1	Y	99	
o64	SPB pulse output ratio	1~1000		1	Y	99	
o65 o66	Limit time 1 configuration Limit time 2 configuration	1 Bit	Boot time	0	0000 0000	Y Y	100
			Running timing	1			
		10Bit	Reserved	-			
		100Bit	Reserved	-			
		1000Bit	Reserved	-			
o67	Limit Time 1	0.0~3200.0		2.0	Y	100	
o68	Limit Time 2	0.0~3200.0		2.0	Y	100	

5-1-6. Multi-speed PLC Group:H00-H55(0x0300-0x0337)

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page	
H00	Multi-speed Collocation	1 bit	Program running function cancel	0	0000	Y	100
			Program running function	1			
		10 bit	Direction decided by H40~H46	0			
			Direction decided by Terminal and keyboard	1			
		100 bit	Deceleration and acceleration time decided by H26~H39	0			
			Time of acceleration and deceleration isdecided by terminal	1			
		1000 bit	Running time decided by H18~H25	0			
			Running time decided by terminal	1			

Section V Parameter Function Table

Code	Description / LCD	Setting Range			Factory Setting	Change Limited	Reference page
H01	Program Running Configuration	1 bit	sequence control	0	0710	Y	101
			terminal control	1			
		10 bit	Program running start segment	0~15			
		100 bit	Program running end segment	0~15			
		1000 bit	Output signal valid time 8ms	0			
			Output signal valid time 20ms	1			
			Output signal valid time 100ms	2			
			Output signal valid time 500ms	3			
H02	Program Running Mode	1 bit	single-cycle	0	0000	Y	102
			Continuous Cycle	1			
			One-cycle command running	2			
		10 bit	The zero speed running when pause	0			
			Fixed-speed running when the suspension	1			
		100 bit	Stop with the parameters set when stop	0			
			Stop with the settings of start up	1			
		1000 bit	Running at the speed when start up segment	0			
Running at the speed before the machine stopped	1						
H03	1 Segment Speed Setting 1X	Lower frequency ~ upper frequency			3.00	Y	104
H04	2 Segment Speed Setting 2X	Lower frequency ~ upper frequency			6.00	Y	104
H05	3 Segment Speed Setting 3X	Lower frequency ~ upper frequency			9.00	Y	104
H06	4 Segment Speed Setting 4X	Lower frequency ~ upper frequency			12.00	Y	104
H07	5 Segment Speed Setting 5X	Lower frequency ~ upper frequency			15.00	Y	104
H08	6 Segment Speed Setting 6X	Lower frequency ~ upper frequency			18.00	Y	104
H09	7 Segment Speed Setting 7X	Lower frequency ~ upper frequency			21.00	Y	104
H10	8 Segment Speed Setting 8X	Lower frequency ~ upper frequency			24.00	Y	104
H11	9 Segment Speed Setting 9X	Lower frequency ~ upper frequency			27.00	Y	104

Section V Parameter Function Table

Code	Description / LCD	Setting Range	Factory Setting	Change Limited	Reference page
H12	10 Segment Speed Setting 10X	Lower frequency ~ upper frequency	30.00	Y	104
H13	11 Segment Speed Setting 11X	Lower frequency ~ upper frequency	33.00	Y	104
H14	12 Segment Speed Setting 12X	Lower frequency ~ upper frequency	36.00	Y	104
H15	13 Segment Speed Setting 13X	Lower frequency ~ upper frequency	39.00	Y	104
H16	14 Segment Speed Setting 14X	Lower frequency ~ upper frequency	42.00	Y	104
H17	15 Segment Speed Setting 15X	Lower frequency ~ upper frequency	45.00	Y	104
H18	0 Segment Running Time T0	0.0~3200.0	2.0	Y	105
H19	1 Segment Running Time T1	0.0~3200.0	2.0	Y	105
H20	2 Segment Running Time T2	0.0~3200.0	2.0	Y	105
H21	3 Segment Running Time T3	0.0~3200.0	2.0	Y	105
H22	4 Segment Running Time T4	0.0~3200.0	2.0	Y	105
H23	5 Segment Running Time T5	0.0~3200.0	2.0	Y	105
H24	6 Segment Running Time T6	0.0~3200.0	2.0	Y	105
H25	7 Segment Running Time T7	0.0~3200.0	2.0	Y	105
H26	1 Segment Acceleration Time at1	0.0~3200.0	10.0	Y	105
H27	1 Segment Deceleration Time dt1	0.0~3200.0	10.0	Y	105
H28	2 Segment Acceleration Time at2	0.0~3200.0	10.0	Y	105
H29	2 Segment Deceleration Time dt2	0.0~3200.0	10.0	Y	105
H30	3 Segment Acceleration Time at3	0.0~3200.0	10.0	Y	105
H31	3 Segment Deceleration Time dt3	0.0~3200.0	10.0	Y	105
H32	4 Segment Acceleration Time at4	0.0~3200.0	10.0	Y	106
H33	4 Segment Deceleration Time dt4	0.0~3200.0	10.0	Y	106
H34	5 Segment Acceleration Time at5	0.0~3200.0	10.0	Y	106
H35	5 Segment Deceleration	0.0~3200.0	10.0	Y	106

Section V Parameter Function Table

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page			
	Time dt5								
H36	6 Segment Acceleration Time at6	0.0~3200.0		10.0	Y	106			
H37	6 Segment Deceleration Time dt6	0.0~3200.0		10.0	Y	106			
H38	7 Segment Acceleration Time at7	0.0~3200.0		10.0	Y	106			
H39	7 Segment Deceleration Time dt7	0.0~3200.0		10.0	Y	106			
H40 H41 H42 H43 H44 H45 H46	1 Segment Speed Configuration Word 2 Segment Speed Configuration Word 3 Segment Speed Configuration Word 4 Segment Speed Configuration Word 5 Segment Speed Configuration Word 6 Segment Speed Configuration Word 7 Segment Speed Configuration Word	1 bit	Running direction: forward 0 Running direction: reverse 1	0000 0000 0000 0000 0000 0000	Y Y Y Y Y Y	106			
		10 bit	Running time: *seconds 0 Running time: *munites 1 Running time: *hours 2 Running time: *days 3						
		100 bit	Acceleration time: *seconds 0 Acceleration time: *munites 1 Acceleration time: hours 2 Acceleration time: *days 3						
		1000 bit	Deceleration time: *seconds 0 Deceleration time: *munites 1 Deceleration time: *hours 2 Deceleration time: *days 3						
H47	0 Segment Digital Voltage Giving	-100.0~100.0					0.0	Y	107
H48	1 Segment Digital Voltage Giving	-100.0~100.0					10.0	Y	107
H49	2 Segment Digital Voltage Giving	-100.0~100.0					20.0	Y	107
H50	3 Segment Digital Voltage Giving	-100.0~100.0					30.0	Y	108
H51	4 Segment Digital Voltage Giving	-100.0~100.0					40.0	Y	108
H52	5 Segment Digital Voltage Giving	-100.0~100.0					50.0	Y	108
H53	6 Segment Digital Voltage Giving	-100.0~100.0					60.0	Y	108

Code	Description / LCD	Setting Range			Factory Setting	Change Limited	Reference page
H54	7 Segment Digital Voltage Giving	-100.0~100.0			70.0	Y	108
H55	Multi-speed Status	1 bit	Current speed step	0-0 xF	-	N	108
		10 bit	Current acceleration segment	0-0 x7			
		100 bit	Current running time segment	0-0 x7			
		1000 bit	Current digit voltage segment	0-0 x7			

5-1-7. V/Fcurve Group:U00-U15(0x0400-0x040F)

Code	Description / LCD	Setting Range	Factory Setting	Change Limited	Reference page
U00	V/ Setting Frequency1	0.00~U02	5.00	N	108
U01	V/F Setting Voltage 1	0~U03	10	N	108
U02	V/F Setting Frequency 2	U00~U04	10.00	N	109
U03	V/F Setting Voltage 2	U01~U05	20	N	109
U04	V/F Setting Frequency 3	U02~U06	15.00	N	109
U05	V/F Setting Voltage 3	U03~U07	30	N	109
U06	V/F Setting Frequency 4	U04~U08	20.00	N	109
U07	V/F Setting Voltage 4	U05~U09	40	N	109
U08	V/F Setting Frequency 5	U06~U10	25.00	N	109
U09	V/F Setting Voltage 5	U07~U11	50	N	109
U10	V/F Setting Frequency 6	U08~U12	30.00	N	109
U11	V/F Setting Voltage 6	U09~U13	60	N	109
U12	V/F Setting Frequency 7	U10~U14	35.00	N	109
U13	V/F Setting Voltage 7	U11~U15	70	N	109
U14	V/F Setting Frequency 8	U12~most frequency	40.00	N	109
U15	V/F Setting Voltage 8	U13~100	80	N	109

5-1-8. PID parameter:P00-P12(0x0500-0x050C)

Code	Description / LCD	Setting Range			Factory Setting	Change Limited	Reference page
P00	PID Configuration	1 bit	Unidirectional regulation	0	0000	N	109
			Bidirectional regulation	1			
		10 bit	Negative effect	0			
			Positive effect	1			
		100 bit	PID fault, N action	0			
			Warning & Continuous running	1			

Section V Parameter Function Table

			Warning & Decelerating stop	2			
			Warning & Free stop	3			
		1000 bit	-	-			
			-	-			
P01	PID Output Limit	0~100			100	Y	110
P02	Feedback Signal Selection	Set frequency by keyboard or RS485		0	1	Y	110
		AI1 external analogy giving		1			
		AI2 external analogy giving		2			
		AI3 external analogy giving		3			
		Keyboard potentiometer giving		4			
		multi-step digital voltage giving		5			
		Digital pulse set		6			
P03	Setting Signal Selection	Set frequency by keyboard or RS485		0	2	Y	110
		AI1 external analogy giving		1			
		AI2 external analogy giving		2			
		AI3 external analogy giving		3			
		Keyboard potentiometer giving		4			
		Multi-step digital voltage giving		5			
		Digital pulse set		6			
P04	Keyboard Set Signal	0.0~100.0			50.0	Y	111
P05	PID integral time	0.002~10.000			0.250	Y	111
P06	PID Differential Time	0.000~10.000			0.000	Y	111
P07	PID Proportion Gain	0~1000.0			100.0	Y	111
P08	PID Sampling Period	0.002~10.000			0.010	Y	112
P09	Deviation Limit	0.0~20.0			5.0	Y	112
P10	PID Fault Detect Time	0.0~3200.0			0.0	N	112
P11	PID Fault Detected Value	0.0~100.0			10.0	N	112
P12	PID Display Range	0.00~100.00			1.00	Y	112

5-1-9. Expanding parameters: E00-E23(0x0600-0x0617)

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page
E00	Load Type	General	0	0	N	112
		Pump	1			
		Fan	2			
		Injection machine	3			
		Textile machine	4			
		Hoist machine	5			

		Kowtow Machine	6					
		belt conveyor	7					
		Variable frequency power	8					
		Multi-pumps constant pressure water supply	9					
		Reserved	10					
		Reserved	11					
		Torque control	12					
		Voltage regulation power	13					
		Current regulation power	14					
		Extruding machine	15					
E01	Starting Pressure Deviation	0.0~100.0		10.0	Y	113		
E02	Starting Delay Time	0.0~3200.0		5.0	Y	113		
E03	Stop Frequency	0~50.00		5.00	N	113		
E04	Stop Delay Time	0.0~3200.0		5.0	Y	113		
E05	High Pressure Arrival Value	0~100.0		90.0	Y	113		
E06	Low Pressure Arribal Value	0~100.0		10.0	Y	113		
E07	Timing To Supply Water	1 bit	Timing water supply	invalid	0	0000	Y	113
				Valid	1			
		10 bit	Pressure giving	Set according to P03	0			
				Set according to H47~H54	1			
		100 bit	Timing mode	Circle mode	0			
Single circle	1							
1000 bit	Current timing step							
E08	Timing Shift Alternation Time	0.0~3200.0		0.0	N	114		
E09	Electromagnetic Switch Action Delay	0.000~10.000		0.500	Y	115		
E10	Pumps Shift Judging Time	0~9999		5	Y	115		
E11	Constant Pressure Water Supply Configuration	1 bit	Stop mode	all pumps slow down stop	0	0000	N	115
				Variable frequency pump stop	1			
				Free stop	2			
				Water supply Pump stop	3			
		10 bit	Pumps status	Keep current situation	0			

Section V Parameter Function Table

			when fault occurs	All-pumps stop	1			
		100 bit	Alternation shift mode	Variable frequency to working frequency	0			
				Variable frequency to stop	1			
		1000 bit	Pump status keep	Keep status	0			
				Stop reset	1			
E12	Multi-pumps Configuration	1 bit	Pump 1 invalid		0	0001	N	117
			Pump 1 variable frequency to control pump		1			
			Pump 1 soft starts to control pump		2			
		10 bit	Pump 2 invalid		0			
			Pump 2 variable frequency to control pump		1			
			Pump 2 soft starts to control pump		2			
		100 bit	Pump 3 invalid		0			
			Pump 3 variable frequency to control pump		1			
			Pump 3 soft starts to control pump		2			
		1000 bit	Pump 4 invalid		0			
			Pump 4 variable frequency to control pump		1			
			Pump 4 soft starts to control pump		2			
E13	Multi-pumps Status	1 bit	Pump 1 stop		0	0000	N	117
			Pump 1 run in variable frequency		1			
			Pump 1 run in working frequency		2			
		10 bit	Pump 2 stop		0			
			Pump 2 run in variable frequency		1			
			Pump 2 run in working frequency		2			

		100 bit	Pump 3 stop	0			
			Pump 3 run in variable frequency	1			
			Pump 3 run in working frequency	2			
		1000 bit	Pump 4 stop	0			
			Pump 4 run in variable frequency	1			
			Pump 4 run in working frequency	2			
E14	Soft Starting Pump Control	1 bit	Pump 1 soft-no commar	0	0000	Y	118
			Pump 1 soft-stop	1			
			Pump 1 soft-start	2			
		10 bit	Pump 1 soft-no command	0			
			Pump 2 soft-stop	1			
			Pump 2 soft-start	2			
		100 bit	Pump 1 soft-no command	0			
			Pump 3 soft-stop	1			
			Pump 3 soft-start	2			
		1000 bit	Pump 1 soft-no command	0			
			Pump 4 soft-stop	1			
			Pump 4 soft-start	2			
E15	User Parameter 0	0~9999		0	Y	118	
E16	User Parameter 1	0~9999		0	Y	118	
E17	User Parameter 2	0~9999		0	Y	118	
E18	User Parameter 3	0~9999		0	Y	118	
E19	User Parameter 4	0~9999		0	Y	118	
E20	User parameter 5	0~9999		0	Y	118	
E21	User Parameter 6	0~9999		0	Y	118	
E22	User Parameter 7	0~9999		0	Y	118	
E23	User Parameter 8	0~9999		0	Y	118	

5-1-10.Speed-loop parameter [SPD]:C00-C31(0x0700-0x071F)

Code	Description / LCD	Setting Range	Factory Setting	Change Limited	Reference page
C00	Filter Time Of Speed-loop	2~200	10	Y	118
C01	Speed-loop Low Speed Ti	0.01~100.00	0.25	Y	118
C02	Speed-loop Low Speed Td	0.000~1.000	0.000	Y	118
C03	Speed-loop Low Speed P	0~150	100	Y	119
C04	Speed-loop Low Speed Shift Frequency	0.0~C08	7.00	Y	119

Section V Parameter Function Table

C05	Speed Loop High Speed Ti	0.01~100.00		0.50	Y	119		
C06	Speed Loop High Speed Td	0.000~1.000		0.000	Y	119		
C07	Speed Loop High Speed P	0~150		75	Y	119		
C08	Speed Loop And High-speed Switching Frequency	C04~max frequency		30.00	Y	119		
C09	Low-speed Slip Gain	0~200		100	Y	119		
C10	Low Speed Slip Switching Frequency	0~C12		5.00	Y	119		
C11	High Speed Slip Gain	0~200		100	Y	119		
C12	High Speed Slip Switching Frequency	C10~ max frequency		30.00	Y	119		
C13	Upper Froward Torque	0.0~300.0		250.0	Y	119		
C14	Upper Reverse Torque	0.0~300.0		250.0	Y	120		
C15	Forward Torque setting mode	1 bit	Setting mode	Set by keyboard or rs485	0	0000	Y	120
				AI1 external analogy giving	1			
				AI2 external analogy giving	2			
				AI3 external analogy giving	3			
				Keypad potentiometer giving	4			
				Multi-step digital voltage giving	5			
		Digital pulse set	6					
		10 bit	direction	Direction uncontrolled	0			
Direction controlled	1							
C16	Reverse Torque setting mode	1 bit	Setting mode	Set by keyboard or RS48	0	0000	Y	120
				AI1 external analogy	1			
				AI2 external analogy giving	2			
				AI3 external analogy giving	3			
				Keypad potentiometer giving	4			
				Multi-step digital voltage giving	5			
				Digital pulse set	6			

		10 bit	direction	Direction uncontrolled	0			
				Direction controlled	1			
C17	Torque Set Gain		0.0~300.0		200.0	Y	121	
C18	Speed /Torque Control Shift		Speed control	0	0	Y	121	
			Torque control	1				
C19	Upper speed Setting mode	1 bit	Separate setting mode	keyboard or RS485 setting	0	0000	Y	121
				A11 external analog setting	1			
				A12 external analog setting	2			
				A13 external analog setting	3			
				Keyboard potentiometer setting	4			
				Multi-segment digital voltage setting	5			
		Digital Pulse Setting	6					
		10 bit	Selection	C19 Unit bit setting	0			
				S00 Setting Frequency	1			
C20	Reverse Speed Limit		0.00~ Maximum frequency		50.00	Y	122	
C21	Torque Acceleration Time		0.0~200.0		1.0	Y	122	
C22	Torque Deceleration Time		0.0~200.0		1.0	Y	122	
C23	Low Speed Excitation Excitation		0~100		30	Y	122	
C24	Current Loop Ti		0~9999		500	Y	122	
C25	Current Loop P		0~1000		100	Y	122	
C26	PG Electronic Gear A		1~5000		1	Y	123	
C27	PG Electronic Gear B		1~5000		1	Y	123	
C28	PG Pulse		300~9999		2500	N	123	
C29	Action When PG Break		N PG break protection	0	3	Y	123	
			Warning and keeping running	1				
			Warning and deceleration stop.	2				
			Warning and free stop.	3				
C30	PG Rotating Direction		When motor forward, phase A leads	0	0	Y	123	
			When motor forward, phase A leads	1				
C31	PG Dropped Inspection Time		0.0~10.0		1.0	N	123	

5-1-11.Motor parameter [MOT]:b00-b22(0x0800-0x0816)

Code	Description / LCD	Setting Range	Factory Setting	Change Limited	Reference page	
b00	Motor 1 Rated Frequency	0.00~Maximum frequency	50.00	Y	123	
b01	Motor 1 Rated Current	y09*(50%~100%)	★	Y	123	
b02	Motor 1 Rated Voltage	100~1140	★	Y	123	
b03	Motor 1 Pole-pairs	1~8	2	Y	123	
b04	Motor 1 Rated Speed	500~5000	1480	Y	123	
b05	Motor 1 N Load Current	0.0~b01	★	Y	124	
b06	Motor 1 Stator Resistance	0.000~30.000	★	Y	124	
b07	Motor 1 Rotor Resistance	0.000~30.000	★	Y	124	
b08	Motor 1 Stator Inductance	0.0~3200.0	★	Y	124	
b09	Motor 1 Mutual Inductance	0.0~3200.0	★	Y	124	
b10	Motor Selection	Motor 1	0	0	N	124
		Motor 2	1			
b11	Motor Parameter Measurement	No measurement	0	0	N	124
		calculate by label data	1			
		inverter static measurement	2			
		inverter rotation measurement	3			
b11	Motor Parameter Measurement	No measurement	0	0	N	124
		calculate by label data	1			
		inverter static measurement	2			
		inverter rotation measurement	3			
b12	Vector Control initial Inspection R1	Not inspection R1	0	0	N	125
		Inspection R1	1			
b13	Motor 2 Rated Frequency	0.00~Maxmum frequency	50.00	Y	125	
b14	Motor 2 Rated Current	y09*(50%~100%)	★	Y	125	
b15	Motor 2 Rated Voltage	100~1140	★	Y	125	
b16	Motor 2 Pole Pairs	1~8	2	Y	125	
b17	Motor 2 Rated Speed	500~5000	1480	Y	125	
b18	Motor 2 N Load Current	0.0~b14	★	Y	125	
b19	Motor 2 Stator Resistance	0.000~30.000	★	Y	125	
b20	Motor 2 Rotator Resistance	0.000~30.000	★	Y	125	
b21	Motor 2 Stator Inductance	0.0~3200.0	★	Y	125	
b22	Motor 2 Mutual Inductance	0.0~3200.0	★	Y	125	

5-1-12. System parameter [SYS]:y00-y17(0x0900-0x0911)

Code	Description / LCD	Setting Range			Factory Setting	Change Limited	Reference page
y00	Reset System Parameter	No action		0	0	N	126
		Reset system parameter with keyboard storage1		1			
		Reset system parameter with keyboard storage 2		2			
		Reset system parameter with keyboard storage 3		3			
		Reset system parameter with keyboard storage 4		4			
		Reset system parameter with factory set value		5			
y01	Parameter Upload To Keyboard	No action		0	0	N	126
		Reset system parameter with keyboard memory area1		1			
		Reset system parameter with keyboard memory area2		2			
		Reset system parameter with keyboard memory area3		3			
		Reset system parameter with keyboard memory area4		4			
		Clear up keyboard memory area 1, 2, 3, 4		5			
y02	Lastest Fault record	Lastest fault record number			0	Y	126
y03	Fault Record 1	Press [PRG]and [▲/▼] key the frequency, crrent and running status of fault time can be known.			0	Y	126
y04	Fault Record 2						
y05	Fault Record 3						
y06	Fault Record 4						
y07	Fault Record 5						
y08	Fault Record Reset	No action		0	0	Y	128
		Reset		1			
y09	Rated Output Current	0.1~1000.0			★	N	128
y10	Rated Input Voltage	100~1140			★	N	128
y11	Product Series	80	0	3	★	N	128
		Family code	Product serial	Input oltage grade 1			
y12	Software Version	-			-	N	128
y13	Product Date-- Year	YYYY			-	N	128
y14	Product Date -Month/Day	MMDD			-	N	128

Section V Parameter Function Table

Code	Description / LCD	Setting Range		Factory Setting	Change Limited	Reference page	
y15	User Decode Input	0~9999		Set range	-	Y	128
		Record password wrongly input times		Display info			
y16	User password key-in	0~9999		Set range	-	Y	129
		No password or decode input is correct	code	Display info			
		Parameter lock-in	code				
y17	Parameter Group Protection	Corresponding parameter group protection after set password Set to 0: change is not allowed Set to 1: change is allowed		0000	Y	129	

Section V

5-2. Functional parameter specification

5-2-1. Menu Group

Code	Description / LCD	Function Discription	Group ID	Refer to page
S	Monitor Function Group	Monitor frequency, current and other 16 monitor objects	0B	53
F	Basic Function Group	Frequency setting, control mode, acceleration time and deceleration time	00	54
A	User Function Group	Monitor, protection, communication setting	01	69
o	IO Function Group	Analog, digital input, output function	02	81
H	Multi-speed PLC Group	Multi-speed running, PLC running	03	99
U	V/F parameter Group	User defined V/F curve	04	107
P	PID Function Group	Internal PID parameter setting	05	108
E	Extend Function Froup	Constant pressure water supply and other function setting	06	111
C	Speed ring function group	Current ring, speed running, PG parameter	07	117
b	Motor parameter group	Motor parameter setting	08	122
y	System Function Group	Parameter reset, fault query, product information, parameter protection	09	124

5-2-2. Monitor function: S00-S15(0x0B00-0x0B0F)

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited
S00	Setting Frequency	current inverter real setting frequency	Hz	-	N
S01	Real Frequency	current inverter real output frequency	Hz	-	N
S02	Motor real Current	Valid value of motor actual current	A	-	N
S03	Percentage of Motor Current	The percentage of actual motor current and rated current	%	-	N
S04	DC Bus Voltage	Detection value of DC bus voltage	V	-	N
S05	The Output Voltage	The real output voltage	V	-	N
S06	Motor Real Speed	Motor real running speed	-	-	N
<p>Under running, the real speed of the motor = $60 \times$ the real output frequency \times Gain Speed surveillance / pole of the motor .</p> <p>Example: the real output frequency 50.00Hz, Gain Speed surveillance A35=100.0%, the pole of the motor b03/b16=2, the real speed of the motor = 1500rpm.</p> <p>When stop, based Residual voltage test motor speed, renew speed 500ms.</p> <p>The real speed = $60 \times$ residual frequency \times Gain Speed surveillance / the pole of the motor</p> <p>Max display of motor real speed 9999rpm.</p>					
S07	Total Running Time	The total running time for every time	hour	-	N
<p>When the output, the frequency inverter calculated the running time.</p> <p>Total running time can be cleared up automatically with A33 selecting reboot or continue accumulation after reboot</p>					

Section V Parameter Function Table

Total running time of the units can be changed by parameter A34, you can choose hours or days as the unit					
S08	IGBT Temperature °C	Test the temperature of IGBT in the frequency	°C	-	N
S09	PID Set Point	PID Adjust run-time values of the percentage of a given	%	-	N
S10	PID Feedback	PID Adjust run-time values of the percentage of feed back	%	-	N
S11	Motor Output Frequency	The percentage of actual output power of motor	%	-	N
The output frequency of the motor=the actual frequency of the motor *A36 the regulation of the motor frequency Max display of the output frequency 2999.9					
S12	Excitation Heft Set Value	Motor's set excitation heft percentage	%	-	N
S13	Excitation Heft Actual Value	Motor's actual excitation heft percentage	%	-	N
S14	Torque Heft Set Value	Motor set torque percentage	%	-	N
S15	Torque Heft Actual Value	Motor actual torque hefts percentage	%	-	N

5-2-3. Basic function Group:F00-F50(0x0000-0x0032)

Code	Description / LCD	Setting Range		Unit	Factory Setting	Change Limited
F00	Control Mode	V/Fcontrol	0	-	0	N
		Sensorless vector control	1			
		Sensor feedback close loop vector control	2			
<p>Control mode choose, setting 0~2.</p> <p>0 : V/ Fcontrol It is not sensitive to motor parameters, can be used as power supply; for motor control, using the combination of vector control and V / F control strategies, appropriately adjusts motor parameters, obtain high-performance control effect; suitable for a inverter driving a motor occasions; suitable for a inverter driving multiple motors occasions; suitable for the inverter as a variable frequency power supplies.</p> <p>1 : Sensorless vector control High-performance speed sensorless vector control; need to set the appropriate electrical parameters or the motor parameter tuning; truly achieved the decoupled AC motor, so that operational control of DC motors.</p> <p>2 : Sensor feedback close loop vector control Suitable for high precision speed control occasions, need to install PG card and pulse encoder shaft in the motor or mechanical equipment.</p>						
F01	Keyboard Setting Frequency	Lower frequency~upper frequency		Hz	50.00	Y
<p>The keyboard for a given operating frequency,it can be any frequency between lower frequency and upper frequency . F02/F03setting to 0, Involved in setting frequency calculation.</p>						
F02	Frequency Main Set Mode	Keyboard setting frequency or RS485	0	-	0	Y
		All the external analog setting	1			

		AI2 the external analog setting	2			
		AI3 the external analog setting	3			
		Keyboard potentiometer setting	4			
		Multi-segment digital voltage setting	5			
		Digital Pulse Setting	6			
<p>The main mode of the frequency running frequency:</p> <p>0 : keyboard setting frequency or RS485 change F01 keyboard setting frequency Multi-digital voltage terminal effective exchange, change F01keyboard setting value</p> <p>1 : AI1 the external analog setting Given the external analog0~10V,-10V~+10V,0~20mA.For detail please read the o group parameter.</p> <p>2 : AI2 the external analog setting</p> <p>3 : AI3 the external analog setting Given the external analog 0~10V, 0~20mA. For detail please read the o group parameter.</p> <p>4 : Keyboard potentiometer setting Keyboard potentiometer setting, keyboard potentiometer for a given start and end values of the corresponding values can be positive role and negative effects. For detail please read the A group parameter.</p> <p>5 : Multi-segment digital voltage setting o36~o46 IO input terminal function set to 11, 12, 13, switch H47~H54 Multi-digital voltage setting, 100% Corresponding to the maximum frequency .</p> <p>6 : Digital pulse setting Digital pulse input frequency Corresponding to the setting frequency, For detail please read the o52 group parameter. Pulse input terminal and DI8 terminal reset, after using the digital pulse input,o43set to0,Otherwise, the function settings will take effect, the pulse input on status of o58 can be checked, be limited to low-speed pulse. Through o36~o46 IO input terminal set to 14, 15, 16 be configured to switch the source</p>						
F03	Auxiliary Setting Mode Of Frequency	Keyboard setting frequency or RS485	0	-	0	Y
		AI1 the external analog setting	1			
		AI2 the external analog setting	2			
		AI3 the external analog setting	3			
		Keyboard potentiometer setting	4			
		Multi-segment digital voltage setting	5			
		Digital Pulse Set	6			
PID regulation mode	7					
<p>Auxiliary setting mode of frequency set:</p> <p>0 : keyboard frequency setting frequency or RS485, change F01 keyboard setting frequency After multi-digital voltage terminal effective switch, change F01keyboard setting.</p> <p>1 : AI1 the external analog setting Given the external analog0~10V,-10V~+10V,0~20mA.For detail please read the o group parameter.</p> <p>2 : AI2 the external analog setting Given the external analog 0~10V, 0~20mA.For detail please read the o group parameter.</p> <p>3 : AI3 the external analog setting Given the external analog 0~10V, 0~20mA.For detail please read the o group parameter.</p>						





Section V Parameter Function Table

Section V

- 4 : Keyboard potentiometer setting
Keyboard potentiometer setting, keyboard potentiometer for a given start and end values of the corresponding values can be positive role and negative effects. For detail please read the A group parameter.
- 5 : Multi-segment digital voltage setting
o36~o46 IO input terminal function set to 11, 12, 13, switch H47~H54 Multi-digital voltage setting, 100% Corresponding to the maximum frequency .
- 6 : Digital pulse set
Digital pulse input frequency corresponding to set the frequency, For detail please read o52 parameter.
Pulse input terminal and DI8 terminal resetting, After use digital pulse input, o43set to 0, Otherwise, the function settings will take effect, can check the pulse input status o58, be limited to low-speed pulse.
- 7 : PID regulation mode
The completion of the main to the frequency of common analog feedback loop control. Speed control accuracy requirements applicable to the general occasions.
The given value can be given through the keyboard can also be given through the analog.
Analog feedback can represent the pressure, flow, temperature.
Details see the P group of parameters.
The completion of the main to the frequency of common analog feedback loop control. Speed control accuracy requirements applicable to the general occasions.
For a given value can be given through the keyboard can also be given through the analog.
Analog feedback can represent the pressure, flow, temperature.
Details see the P group of parameters.
Through o36~o46 IO input terminal, set to 17, 18, 19 be configured to switch the source for a given ratio.

F04	The Relationship Between Main And Auxiliary Setting Frequency	The main setting individual control	0	-	0	Y
		The auxiliary setting individual control	1			
		main + auxiliary	2			
		main -auxiliary	3			
		(main *auxiliary)/maximum frequency	4			
		Maximum { main, auxiliary }	5			
		Minimum { main, auxiliary }	6			

Main given and auxiliary given set frequency relations:
Main given value and auxiliary given value can be added up, subtracted, multiplied, maximum, minimum calculation.
O group parameters can be adjusted to coordinate the main given and auxiliary given proportion, to meet the requirements of the system fine-tuning and bias.

<div style="display: flex; justify-content: space-between;"> <div style="width: 30%;">  <p>The relationship between main give and auxiliary given</p> </div> <div style="width: 65%;">  <p style="text-align: center;">Main+Auxiliary</p> </div> </div>						
<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;">  <p style="text-align: center;">Main-Auxiliary</p> </div> <div style="width: 45%;">  <p style="text-align: center;">(Main*Auxiliary)/The Max Frequency</p> </div> </div>						
Maximum(Main&Auxiliary)			Manimum(Main&Auxiliary)			
F05	Running Control Mode	Keyboard+Rs485/CAN	0	-	0	Y
		Keyboard+terminal+Rs485/CAN	1			
		Rs485/CAN	2			
		Terminal control	3			
		The proportion linkage control	4			
<p>Stop and running command control mode:</p> <p>0 : keyboard+Rs485/CAN Control</p> <p>1 : keyboard+Terminal+Rs485/CAN Control control terminal, edge trigger, falling edge of the implementation of the Forward command FWD / Reverse command REV, rising edge of the implementation of the STOP command</p> <p>2 : Rs485/CAN Control Under this function, only free stop fuction is valid under the keyboard control, other operation control is invalid</p> <p>3 : Terminal control, Level trigger. Under this function, only free stop fuction is valid under the keyboard control, other operation control is invalid</p>						


Section V Parameter Function Table

<p>4 : The proportion linkage control Select this function, the slave unit would execute the command from the proportion linkage host unit. Select this function, can also use keyboard, terminal, RS485 to control the proportion linkage slave unit to run. The proportion of linkage running,after stop the proportion linkage slave unit with the keyboard terminal, Rs485, the slave unit will not run the proportion linkge host unit's command, it needs once again to respond to host commands through the keyboard, terminal, RS485, or the proportion linkage host sends stop command so that slave unit could respond to run commands.</p>							
F06	V/F Boost Mode	1 bit	Beeline V/Fcurve	0	-	0000	N
			Power of 1.2 V/Fcurve	1			
			Power of 1.7 power V/Fcurve	2			
			Power of 2 powerV/Fcurve	3			
			Define mode V/Fcurve	4			
		10 bit	Close Automatic torque boost	0			
			Automatic torqueboost	1			
		100 bit	VF mode 0 Speed No Output	0			
			VF mode keep 0 speed	1			
		<p>1 Bit: V/F promote curve 0 Line V/F curve: Suitable for ordinary constant torque load 1 Power of 1.2 V/F curve: Appropriate torque down V/F curve, Suitable for liquid loads 2 Power of 1.7 V/F curve: Appropriate torque down V/F curve, Suitable for liquid loads 3 Power of 2 V/F curve: Torque down V/F curve, It is suitable for fans, pumps, centrifugal load 4 Define mode V/Fcurve: Can be customized appropriate curve according to the actual situation .</p> <p>10 bit: Auto-torque boost mode 0 Close Automatic torque boost 1 Open automatic torque boost</p> <p>parameters which affect automatic torque enhance : Actual value torque component S15 b06/b19 stator resistance F07 torque enhance value Automatic torque enhance value = actual value of torque component * stator resistance *torque enhance value.</p> <p>100 bit: VF mode 0 speed maintain function 0 VF mode 0 Speed No Output: Output frequency is less than 0.5Hz, stop PWM output to reduce the switching loss. 1 VF mode keep 0 speed: the output frequency is 0Hz, in accordance with the DC braking current of starting F26, keep 0 speed.</p>					
F07	Torque boost Value	0.0~30.0%	%	0.0	Y		
F08	Torque Boost Cut-off Frequency	0.00~Maximum frequency	Hz	15.00	Y		
<p>Torque increase is mainly used to improve the low-frequency torque characteristics under sensorless -V / F control mode. Torque boost is too low, weak low speed motor</p>							

<p>Torque boost is too high, motor over-excitation operation, large inverter output current, and low efficiency.</p> <p>The setting frequency of the inverter is lower than the frequency of the torque rising, the torque rising will be valid; over than the setting frequency the torque rising will be invalid.</p>					
F09	Accelerate Time	0.0~3200.0	s	10.0	Y
F10	Decelerate Time	0.0~3200.0	s	10.0	Y
<p>F09 Accelerate time: accelerate time from 0Hz to maximum frequency. F10 Decelerate time: decelerate time from maximum frequency to 0Hz.</p> <p style="text-align: center;">Linear Acceleration</p>					
F11	Percentage Of Output Voltage	50~110	%	100	Y
<p>The percentage of the actual output voltage and the rated output voltage. Used to adjust the output voltage, output voltage = inverter rated output voltage * percentage of output voltage.</p>					
F12	Maximum Frequency	10.00~320.00	Hz	50.00	N
<p>Inverter output maximum frequency allowed is also the setting basis of acceleration / deceleration time. This parameter setting, you should consider characteristics of the motor speed and capacity.</p>					
F13	Lower Frequency	0.00~Upper frequency	Hz	0.00	N
F14	Upper Frequency	Lower frequency~Upper frequency	Hz	50.00	N
<p>F13 Lower frequency: the lower limit of the output frequency. F14 Upper frequency: the upper limit of output frequency. When the frequency setting command is higher than the upper frequency, the operating frequency will be the upper frequency; when the frequency setting command below the lower frequency, the operating frequency is lower frequency. Start the motor that in the status of stopping, the inverter outputs accelerate starting from 0Hz, accordance with the step 1 acceleration time towards the upper or the setting frequency to accelerate. when motor Stop, the operating frequency decelerate according to deceleration time down to 0Hz.</p>					


Section V Parameter Function Table

Section V



F15	Basic Frequency	5.00~Maximum frequency	Hz	50.00	N
-----	-----------------	------------------------	----	-------	---

Corresponding to different fundamental frequency of the motor select this function. The basic V / F characteristic curve is as below.



F16	Carrier Frequency	1.0~16.0	kHz	★	Y
-----	-------------------	----------	-----	---	---

This function is chiefly used to improve the possible noise and vibration during the operation of frequency converter. When carrier frequency is higher, the output current has better wave, the torque is great at lower frequency and the motor produces light noise. So it is very suitable for use in the applications where great torque is output at low frequency quietly. But in these applications, the damage to the switches of main components and the heat generated by the inverter are great, the efficiency is decreased and the output capacity is reduced. At the same time, more serious radio interference is resulted and special attention must be paid for application where very low EMI is needed, and filter option can be used if necessary. Another problem for application of high carrier frequency is the increase of capacitance-leakage current. The protector for leakage current may invalidate function, and over current is also possibly caused.

When low carrier frequency is applied, the case is almost contrary to the above-mentioned one.

Different motor has different reflection to the carrier frequency. The best carrier frequency is gained after regulation according to actual conditions. The higher the motor capacity is, the lower the carrier frequency should be selected.

The company reserves the right to limit maximum carrier frequency as following:

The relation between carrier frequency and Motor Noise, Electric disturbance, Switch dissipation is expressed as following:

Carrier Frequency	Motor Noise	Electric disturbance	Switch dissipation
1.0KHz	Big ↓ Small	Small ↓ Big	Small
8.0KHz			↓
16.0KHz			Big


The relationship of the carrier frequency and power :

Power(kW)	0.4-18.5	22-30	37-55	75-110	132-200	220 以上
Carrier Frequency (Hz)	8.0K	7.0K	4.0K	3.6K	3.0K	2.5K

Note: Carrier frequency is bigger, the temperature of the machine is higher.							
F17	Carrier Frequency Adjustment Range	0.0~4.0		kHz	0.0	Y	
F18	Carrier Frequency Adjustment Mode	1 bit	No automatic adjustment	0	-	00	Y
			automatic adjustment Mode	1			
		10 bit	automatic adjustment, Fixed mode	0			
			automatic adjustment, random mode	1			
<p>F17 Carrier frequency adjustment range 0.0~4.0kHz, Actual Carrier frequency adjustment range 1.0~16.0kHz F18 Carrier frequency adjustment Mode 1 Bit: Carrier frequency automatic adjustment mode 0: No automatic adjustment Carrier frequency according to F16 to set. 1: automatic adjustment Mode The carrier frequency automatically adjusts the model 10 can select random mode and fixed pattern. 10 Bit: Stochastic adjustment mode 0: automatic adjustment, Fixed mode Load current > 80% Carrier frequency = F16-F17 Load current < 60% Carrier frequency = F16+F17 1: automatic adjustment, random mode Load current > 80% Carrier frequency = (F16-F17)~F16 Load current < 60% Carrier frequency = F16~(F16+F17)</p>							
F19	Waveform Generation Mode	Asynchronous space-vector PWM		0	-	0	N
		Stepless & subsection synchronous space vector PWM		1			
		two-phase optimization space vector PWM		2			
<p>PWM wave produce mode 0: Asynchronous space-vector PWM 1: Stepless & subsection synchronous space vector PWM 2: two-phase optimization space vector PWM</p>							
F20	S Curve Start Time At The Acceleration Step	0.0~50.0		%	0.0	Y	
F21	S Curve Stop Time At The Acceleration Step	0.0~50.0		%	0.0	Y	
F22	S Curve Start Time At The Deceleration Step	0.0~50.0		%	0.0	Y	
F23	S Curve Stop Time At The Deceleration Step	0.0~50.0		%	0.0	Y	
<p>1 indicate that the slope of the output frequency from 0 to the max. 2 indicate that the slope of the output frequency at constant segment. 3 indicate that the slope of the output frequency is reduced to 0 from the max. Such as setting the S curve acceleration and deceleration, acceleration and deceleration time from 0Hz to the maximum frequency is calculated as follows: Plus acceleration S characteristic time = F09 * F20 Constant extra acceleration S characteristic time = F09-(F09 * F20 + F09 * F21)</p>							

Section V Parameter Function Table

Minus acceleration S characteristic time = $F09 * F21$
 Full acceleration time = $F09$ Acceleration time
 Velocity S addition and subtraction characteristic time = $F10 * F22$
 Constant deceleration S characteristics time = $F10 - (F10 * F22 + F10 * F23)$
 And reduction rate of S characteristic time = $F10 * F23$
 All deceleration time = $F10$ deceleration time



S curve acceleration&deceleration

F24	V/F Control Slip Compensation	slip compensation invalid	0	-	0	N
		slip compensation valid	1			


Valid only under V/F control mode.

- 0 : Slip compensation function is invalid.
- 1 : Slip compensation function is valid.

Slip compensation value adjusted by the following parameters to ensure stable speed under load fluctuations and heavy load,

- C09 Low Slip Gain
- C10 Low Slip switching frequency
- C11 High-Speed Slip Gain
- Slip C12 high-speed switching frequency

F25	Minimum Running Frequency	0.00~maximum frequency	Hz	0.00	N
-----	---------------------------	------------------------	----	------	---




The set frequency lower than the minimum running frequency, the converter will stop, that is, when the set frequency is less than the minimum running frequency, are determined that the set frequency is 0.

Minimum running frequency" and "lower frequency" relationship is as follows.

F26	DC Braking Current When Starting	0~135	%	100	Y
F27	Braking Time When Starting	0.0~60.0	s	0.0	Y

When frequency inverter starting, the first injection of DC current, the current size is determined by starting to set when the DC braking current and braking time, braking time from the start to set.


Value is based on inverter rated current as the benchmark, that is inverter rated current corresponds to 100%. During setting process, be sure to gradually increase, until adequate braking torque, and can not exceed the motor rated current.



F28	Stop When The DC Braking Current	0~135	%	100	Y
F29	Stop And Braking Wait Time	0.0~60.0	s	0.0	Y
F30	Brake Time Stop	0.0~60.0	s	0.0	Y
F31	Stop And Brake Starting Frequency	0.00~most frequency	Hz	0.00	Y


Inverter slowing down to stop braking start frequency, stop the output PWM waveform to begin injection of DC current, the current size by the shutdown of DC braking current setting, braking time, braking time set by the downtime.

Value is based on inverter rated current as the benchmark, that is inverter rated current corresponds to 100%. Setting process, be sure to gradually increase from a small, until adequate braking torque, and can not exceed the motor rated current.



Stop braking (RUN → STOP)

Section V Parameter Function Table



F32	Stop Setting Mode	Deceleration stop	0	-	0	N
		Free stop	1			

When the frequency inverter receives the "stop" command, it will set the parameters accordingly to this parameter to set the motor stop mode.

0 : deceleration to stop

Mode converter according to parameters set by the deceleration time to set the deceleration mode to slow down to the lowest frequencies to stop.

1 : Free stop mode


Inverter receive "stop" command immediately stop output, according to the load inertia, motor free-run to stop.

F33	Jog Acceleration Time	0.0~3200.0	s	1.0	N
-----	-----------------------	------------	---	-----	---

F34	Jog Deceleration Time	0.0~3200.0	s	1.0	N
-----	-----------------------	------------	---	-----	---

F35	Jog Mode Setting	1 bit	Jog direction: forward	0	-	000	N
			Jog direction: reverse	1			
			Jog direction: direction determined by the main terminal	2			
		10 bit	Jog end mode: Stop	0			
			Jog end mode: reset to the former state before jog	1			
			100 bit	Jog end and acceleration deceleration time: reset			

		to the set acceleration and deceleration time before jog				
		Jog end and acceleration deceleration time:save the set acceleration and deceleration time before jog	1			
F36	Jog Frequency Setting	Lower frequency ~upper frequency		Hz	6.00	Y



Jog acceleration/deceleration time configuration defines the same section of acceleration / deceleration time.

The direction of jog is set by the unit bit of F35, when the Jog command does not contain the direction of jog, the direction of job will run as to the unit bit designated by F35. It is set to 2, the direction of jog is run by the terminal or current direction.


The running status after jogging is identified by F35.

Whether jog acceleration/deceleration time is maintained through the confirmation on hundred bit of F35 after jogging

F37	Skip Frequency1Limit	0.00~Maximum frequency	Hz	0.00	Y
F38	Skip Frequency1Upper	0.00~Maximum frequency	Hz	0.00	Y
F39	Skip Frequency2Limit	0.00~Maximum frequency	Hz	0.00	Y
F40	Skip Frequency2Upper	0.00~Maximum frequency	Hz	0.00	Y
F41	Skip Frequency3Limit	0.00~Maximum frequency	Hz	0.00	Y
F42	Skip Frequency3Upper	0.00~Maximum frequency	Hz	0.00	Y

During running, to skip resonance produced by the immanent resonance point in the machine systems, skip mode can do this.

At most three resonance points could be set to skip.



Upper skip frequency and lower skip frequency define skip frequency range.

Section V Parameter Function Table

In the acceleration and deceleration process, inverter output frequency can normally through skip frequency area.							
F43	Preset Frequency	0.00~Max frequency	Hz	0.00	Y		
F44	Preset Frequency Working Time	0.0~60.0	s	0.0	Y		
After inverter startup, it firstly run with preset frequency, running time is preset frequency time, then it will run with given frequency. Jog run will not be effective by preset frequency.							
F45	Motor Running Direction	1 bit	Direction command: forward command FWD let motor forward running	0	-	0100	N
			Direction command: forward command FWD let motor reverse running	1			
		10 bit	Command prior: terminal/keyboard	0			
			Prior command: Analog given positive and negative values	1			
		100 bit	Reverse allow: reverse forbidden	0			
			Reverse allow: reverse allow	1			
<p>1 : Bit: used to change the direction of motor running 0: Forward command FWD is to let motor forward running. 1: Forward command FWD is to let motor reverse running.</p> <p>10 : Motor forward reverse running can be controlled by the keyboard potentiometer and analog input input positive or negative value. 0: Prior command:terminal / keyboard, set frequency can be negative value, but running direction decided by terminal and keyboard command. 1: Prior command: positive or negative value of analog input, setting frequency positive value let motor forward running, setting negative value let motor reverse running.</p> <p>100: motor reverse allow. For some producing equipment, the reverse may lead to damage to the equipment, so this feature can be used to prevent motor reverse, Inverter default forbidden reverse. When the motor running direction opposes to equipment required direction, you can exchange the wiring of any two inverter output terminals to let equipment forward running direction is consistent with motor running. 0: reverse forbidden 1: reverse allow</p>							
F46	Pass 0 Stopping Time	0.0~60.0s	s	0	N		
Setting this parameter to achieve the motor forward to reverse (or from reverse running to forward), the waiting time of motor speed being zero							

F47	Frequency Multiple Setting	*1	0	-	0	N	
		*10	1				
<p>0 : Set frequency display accuracy 0.01Hz With this accuracy, F12 Maximum frequency setting range 10.00~320.00Hz.</p> <p>1 : Set frequency display accuracy 0.1Hz with this accuracy, F12 Maximum frequency setting range 100.0~800.0Hz.</p> <p>After setting this parameter, there must be reset F12 maximum frequency.</p>							
F48	Acceleration And Deceleration Configuration Word	1 bit	N adjustment of acceleration time	0	-	0000	N
			A11 adjustment of the external analog giving	1			
			A12 adjustment of the external analog giving	2			
			A13 adjustment of the external analog giving	3			
			Adjustment of keyboard potentiometer giving	4			
		Adjustment of Multi steps digital voltage giving	5				
		10 bit	N adjustment of deceleration time	0			
			A11 adjustment of the external analog giving	1			
			A12 adjustment of the external analog giving	2			
			A13 adjustment of the external analog giving	3			
			Adjustment of keyboard potentiometer giving	4			
		100 bit	Adjustment of Multi steps digital voltage giving	5			
			Acceleration time:*s	0			
			Acceleration time:*min	1			
			Acceleration time:*h	2			
1000 bit	Acceleration time:*day	3					
	Deceleration time:*s	0					

Section V

Section V Parameter Function Table

			Deceleration time:*min	1			
			Deceleration time:*h	2			
			Deceleration time:*day	3			

1 bit: Acceleration time adjustment mode

0	No Adjustment Of Acceleration Time	No adjustment
1	A11 Adjustment Of The External Analog Giving	Actual Acc. time=Acc. time*A11 giving percentage
2	A12 Adjustment Of The External Analog Giving	Actual Acc. time = Acc. time*A12 giving percentage
3	A13 Adjustment Of The External Analog Giving	Actual Acc. time = Acc. time*A13 giving percentage
4	Adjustment Of Keyboard Potentiometer Giving	Actual Acc.time = Acc. time*keyboard potentiometer giving percentage
5	Adjustment Of Multi Steps Digital Voltage Giving	Actual Acc.time=Acc.time*Multi steps digital voltage giving percentage

10 bit: Deceleration time adjustment mode

0	No Adjustment Of Acceleration Time	No adjustment
1	A11 Adjustment Of The External Analog Giving	Actual Acc.time =Dec. time*A11 giving percentage
2	A12 Adjustment Of The External Analog Giving	Actual Acc.time = Dec. time *A12 giving percentage
3	A13 Adjustment Of The External Analog Giving	Actual Acc.time = Dec. time *A13 giving percentage
4	Adjustment Of Keyboard Potentiometer Giving	Actual Acc.time = Dec. time*keyboard potentiometer giving percentage
5	Adjustment Of Multi Steps Digital Voltage	Actual Acc.time=Dec.time*Multi steps digital voltage giving percentage

100, 1000 bit: The unit of Acc. and Dec time when program running on 0 step speed

Acc. and Dec. time	1000 bit 100 bit	Range(e.g. F09, F10=3200.0)
*s	0	3200.0s
*Min	1	3200.0 Min
*H	2	3200.0 h
*Day	3	3200.0 Day

F49	Running Configuration Word	1 bit	Running direction: forward	0	-	0000	N
			Running direction: reverse	1			
		10 bit	Running time: *S	0			
			Running time: *Min	1			
			Running time: *H	2			
			Running time: *Day	3			

Unit adjustment of actual running time. It is only valid on program running.

1 bit: Program running on multi-speed running period, Set bit to running direction of $-θ$ ' step speed.

Running direction	Setting value
Forward	0
Reverse	1

When running control mode F05=0/1/2, control direction of $-θ$ ' step speed.

When running control mode F05=3, Setting the value and terminal FWD / REV jointly decide the direction of 0 step speed, FWD priority.

FWD=1 running direction	REV=1 running direction	Setting value
FWD	REV	0
REV	FWD	1

10 bit: unit of time running when on $-θ$ ' step speed.


Running time	10 bit	range(e.g. H18~H25=3200.0)
*S	0	3200.0s
*Min	1	3200.0Min
*H	2	3200.0H
*Day	3	3200.0 Day

F50	Energy Saving Running Percentage	30~100	%	100	N
-----	----------------------------------	--------	---	-----	---

This parameter describes the minimum output voltage percentage of energy-saving operation. In the constant speed operation, the inverter can be automatically calculated the best output voltage by the load conditions. In the process of acceleration and deceleration is not to make such calculations.

Power-saving function is by lowering the output voltage and improve power factor to achieve the purpose of saving energy, this parameter determines the minimum value of reducing of output voltage; This parameter is set to 100%, then energy-saving function will take off.

When energy-saving function in effect, Actual output voltage value of inverter= The inverter rated output voltage*The percentage of output voltage*output voltage percentage of energy saving operation.



5-2-4. User Function Group: A00-A55(0x0100-0x0137)

Code	Description / LCD	Setting Range		Unit	Factory Setting	Change Limited
A00	Monitor 1	Parameter group N:	Parameter group N:	-	0B00	Y
A01	Monitor 2	X1000/X100	X10/ bit	-	0B01	Y
A02	Monitor 3	00~0B	0~63(0x00~0x3F)	-	0B02	Y
Code	Keyboard display	Parameter group N	Function spec	Parameter N(16 Hexadecimal Input)		
S	Monitor Function Group	0B	S	0~16 (0x00~0x10)		

Section V Parameter Function Table

F	Basic Function Group	00	F	0~60 (0x00~0x3C)
A	User Function Group	01	A	0~56 (0x00~0x38)
o	IO Function Group	02	o	0~61 (0x00~0x3D)
H	Multi-step Speed PLC Group	03	H	0~56 (0x00~0x38)
U	V/F Curve Group	04	U	0~16 (0x00~0x10)
P	PID Function Group	05	P	0~13 (0x00~0x0D)
E	Extend Function Group	06	E	0~14 (0x00~0x0E)
C	Speed Loop Parameter Group	07	C	0~32 (0x00~0x20)
b	Motor Parameter Group	08	b	0~23 (0x00~0x17)
y	System Function Group	09	y	0~18 (0x00~0x12)

That parameter N. should be 16 hex input.

Monitor1 will be valid when first power on, and which decide keyboard display content.

Such as:monitor 1 S01 actual frequency, A00=0x0B01.

Monitor 2 o57 DI1~4 terminal status, A01=0x0239.

Monitor 3 H55 multi-steps speed status, A02=0x0337.


A03	Over /Less Voltage Stall Protection	N	0	-	1	Y
		Y	1			
A04	Overvoltage Stall Protection Voltage	110%~140%(Standard bus voltage)		%	120	Y

0 : This function invalid

1 : This function valid

When the inverter deceleration, as the motor load inertia, motor will produce feedback voltage to inverter inside, which will increase DC bus voltage and surpass max voltage. When you choose Over /less voltage stall protection and it is valid, Inverter detects DC side voltage, if the voltage is too high, the inverter to stop deceleration (the output frequency remains unchanged), until the DC side voltage is below the set value, the inverter will re-implement the deceleration

With braking models and external braking resistor, this function should be set to -θ°.



A05	Auto Stabilze Voltage	Invalid	0	-	0	Y
		Valid	1			
		Valid, usless for deceleration	2			

CPU automatically detect the inverter DC bus voltage and to make real-time optimized processing, when the grid voltage fluctuate, the output voltage fluctuation is very small,the V / F curve characteristic has always been close to setting state of rated input voltage..

0 : function inalid.

1 : function Valid.

2 : function Valid, but useless for deceleration.

A06	Dynamic Braking option	Invalid	0	-	0	Y
-----	------------------------	---------	---	---	---	---

		Security Type	1			
		General Type	2			
A07	Hysteresis voltage	0~10%	%	2	Y	
A08	Dynamic Braking Voltage	110%~140%(Standard bus voltage)	%	130	Y	
<p>0: Invalid 1: Security Type Only in the inverter deceleration process, and detected high-voltage DC bus exceeds a predetermined value, the dynamic braking will be implemented 2: general Type under any state, when the inverter detected high-voltage DC bus exceeds a predetermined value, the dynamic braking will be implemented. When the inverter is running on emergency deceleration state or load great fluctuation, it may appear over-voltage or over-current. This phenomenon is relatively prone to happen when the motor load inertia is heavy. When inverter The inverter internal DC bus detected voltage exceeds a certain value, the output brake signal through an external braking resistor implement energy-braking function. Users can select inverter models with a braking function to apply this feature.</p>						
A09	Less Voltage Level	60%~75%(Standard DC bus voltage)	%	70	Y	
<p>The definition of allowed the lower limit voltage of normal working inverter DC side .For some low power occasions, inverter less voltage value can be appropriately put down in order to ensure the inverter normal working.. Under normal condition, keeping default setting.</p>						
A10	Power-down Tracking Options	N	0	-	0	Y
		Power-off tracking mode	1			
		Startup tracking mode	2			
A11	Power-down tTracking Time	0.0~20.0	s	0.0	Y	
<p>This parameter is used to select the inverter tracking mode. 0: N speed tracking means to start tracking from 0 Hz. 1: power-down tracking When the inverter instantaneous power off and re-start, the motor will continue running with current speed and direction. If the power off time is longer than A11 set time, the inverter will not re-start power on again. 2: Startup tracking means that when power on, inverter will first inspect motor direction and speed, and then driving motor with current speed and direction. Set startup tracking function, power off tracking function is still valid.</p>						

Section V Parameter Function Table


A12	Power Down Frequency Drop Point	65~100%(standard DC bus voltage)	%	75	Y																							
A13	Power Down Frequency Drop Time	0.1~3200.0	s	5.0	Y																							
<p>Correctly setting this parameter can let inverter does not less voltage stop in case of instantaneous power off.</p> <p>When the DC bus voltage drop to frequency drop point A12 set, inverter will decelerate according to deceleration time A13 set and stop outputting power to load. Meanwhile, inverter will use load feedback energy to compensate DC bus voltage dropping and keep inverter working in short time.</p> <p>Power down frequency drop time actually is deceleration time of frequency dropping after power off.</p> <p>If this value set is too large, the load feedback energy is small, then inverter can not compensate for voltage dropping in DC.</p> <p>if this value set is too small and there is large energy feedback from load, the excessive energy compensation may cause inverter over-voltage fault.</p> <p>Set A12 100% to cancel power off frequency dropping function.</p>																												
A14	Current Limit	N	0	-	0	Y																						
		Y	1																									
A15	Limit Fall Time	0.1~3200.0	s	10.0	Y																							
A16	Limit Deceleration Protection Point	10~250	%	★	Y																							
A17	Limit Fix-speed Protection Point	10~250	%	★	Y																							
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Series</th> <th style="width: 25%;">Current limitaiton%</th> <th style="width: 60%;">Corresponding parameter</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">F</td> <td style="text-align: center;">120</td> <td style="text-align: center;">A17</td> </tr> <tr> <td style="text-align: center;">130</td> <td style="text-align: center;">A16</td> </tr> <tr> <td rowspan="2" style="text-align: center;">G</td> <td style="text-align: center;">150</td> <td style="text-align: center;">A17</td> </tr> <tr> <td style="text-align: center;">170</td> <td style="text-align: center;">A16</td> </tr> <tr> <td rowspan="2" style="text-align: center;">M、T、Z</td> <td style="text-align: center;">170</td> <td style="text-align: center;">A17</td> </tr> <tr> <td style="text-align: center;">190</td> <td style="text-align: center;">A16</td> </tr> <tr> <td rowspan="2" style="text-align: center;">H</td> <td style="text-align: center;">250</td> <td style="text-align: center;">A17</td> </tr> <tr> <td style="text-align: center;">270</td> <td style="text-align: center;">A16</td> </tr> </tbody> </table> <p>Current limitation function can effectively restrain over-current caused by motor load fluctuation in the process of acceleration and deceleration or constant speed operation.</p> <p>This function will be good effect for V/F control mode.</p> <p>Under protection of current lost- speed state, the motor speed will drop. so it is not adapted by systme which is not allowed to automatically drop speed.</p> <p>In operation process, when the motor current surpass value A16 set, motor will decelerate according to deceleration time A15 set until current below value A16 set.</p> <p>In operation process, when the motor surpass value A17 set, motor will run with this speed until current below value A17 set.</p> <p>Deceleration current limitation is prior of constant speed limitation.</p>						Series	Current limitaiton%	Corresponding parameter	F	120	A17	130	A16	G	150	A17	170	A16	M、T、Z	170	A17	190	A16	H	250	A17	270	A16
Series	Current limitaiton%	Corresponding parameter																										
F	120	A17																										
	130	A16																										
G	150	A17																										
	170	A16																										
M、T、Z	170	A17																										
	190	A16																										
H	250	A17																										
	270	A16																										
A18	Output Phase Lose Protection	N protection of phase lost	0	-	0	Y																						
		Warning and constant running	1																									
		Warning and deceleration	2																									

Section V Parameter Function Table

		Warning and free stopping	3																		
A19	Grade Of Phase Lose Protection	10~100	%	30	Y																
<p>When ratio of unbalance 3phase output surpass A19 Grade of phase lose protection, the inverter output phase lose protection i will action, and the system display fault PH-O.</p> <p>Output frequency less than 2.00Hz, there is N output phase lose protection.</p> <p>Phase lost protection grade=max current difference between phases, which will be according to load condition.</p>																					
A20	Over Torque Inspected Action	N torque inspection	0	-	0	Y															
		Warning and running	1																		
		Warning and decelerating stop	2																		
		Warning and free stopping	3																		
A21	Over Torque Grade	10~250	%	★	Y																
A22	Over Torque Inspection Time	0.0~60.0	s	0.1	Y																
<p>Motor output current surpass value A21 set, Over torque inspection will be force and the system will show OL2 fault.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Series</th> <th>Over torque inspection class</th> <th>Parameter</th> </tr> </thead> <tbody> <tr> <td>F</td> <td>130</td> <td>A21</td> </tr> <tr> <td>G</td> <td>170</td> <td>A21</td> </tr> <tr> <td>M、T、Z</td> <td>190</td> <td>A21</td> </tr> <tr> <td>H</td> <td>270</td> <td>A21</td> </tr> </tbody> </table>							Series	Over torque inspection class	Parameter	F	130	A21	G	170	A21	M、T、Z	190	A21	H	270	A21
Series	Over torque inspection class	Parameter																			
F	130	A21																			
G	170	A21																			
M、T、Z	190	A21																			
H	270	A21																			
A23	Electronic Thermal Relay Protection Selection	N	0	-	1	Y															
		Y	1																		
A24	Electronic Thermal Protection Grade	120~250	%	★	Y																
<p>This function is to protect motor overheating when motor does not use thermal relay. Inverter using some parameters to calculate motor temperature rise, at the same time to determine whether the use of current caused motor overheat. When you choose electronic thermal protection function, the drive output is shutdown after overheating detected also shows information of protection.</p> <p>0: No selecting this function</p> <p>1: Select this function.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Series</th> <th>electronic Thermal Protection Level</th> <th>Parameters</th> </tr> </thead> <tbody> <tr> <td>F</td> <td>120</td> <td>A24</td> </tr> <tr> <td>G</td> <td>150</td> <td>A24</td> </tr> <tr> <td>M、T、Z</td> <td>170</td> <td>A24</td> </tr> <tr> <td>H</td> <td>250</td> <td>A24</td> </tr> </tbody> </table> <p>A24 set the electronic thermal protection level . When the current is the rated motor current multiplies the parameter, the drive in 1 minute protects, thermal protection within one minute that means the actual current is A24 times of the rated current.</p>							Series	electronic Thermal Protection Level	Parameters	F	120	A24	G	150	A24	M、T、Z	170	A24	H	250	A24
Series	electronic Thermal Protection Level	Parameters																			
F	120	A24																			
G	150	A24																			
M、T、Z	170	A24																			
H	250	A24																			

Section V

Section V Parameter Function Table



A25	Fault Reset Times	0~10	-	0	Y	
<p>In the inverter operation process, Over Current expressed by OC, Over Voltage by OU, inverter can automatically recover and run with state of preceding fault. Recovering times will be according to this parameter. It can set 10 times at most. When this parameter is set -0”, inverter will not automatically recover after meeting fault. But if relay in DC main circuit meet fault -MCC” or less vottage -LU” fault, inverter will automatically recover without limitation.</p> <p>Restarting from fault and normally running over 36s, inverter will automatically recover fault reset times preset.</p> <p>Restarting from fault and normally running over 36s, inverter will automatically recover to display monitor parameter.</p> <p>After 10 s of meeting fault, inverter will not recover fault reset function.</p>						
A26	Fault Reset Time	0.5~20.0	s	1.0	Y	
<p>Setting interval of fault reset time. When inverter met fault and stopped outputting, and when it inspected without fault time is longer than fault reset time, Inverter will automatically implement fault reset.</p>						
A27	Fan Startup Temperature	0.0~60.0	°C	0.0	Y	
<p>Set the fan start temperature. When the actual temperature of the S08 is higher than the set temperature the fan starts.</p> <p>To avoid the the fan frequently starts and stops , the fan stop temperature = A27 fan start temperature -1.0 °C.</p>						
A28	This Inverter Communication Address	1~128	-	8	Y	
<p>This Inverter communication address: it is the only code to differentiate from other inverters. Setting range -1~127” is slave inverter address, that can receive command and send out this inverter state. Seeing attachment 1 for detailed specification.</p> <p>The proportion of linkage function: The proportion of linkage host inverter: This inverter communication address=128, Communication interface A is set as host inverter communication interface for proportion of linkage.</p> <p>Communication interface B can be treated as keyboard interface or -PC” Host Computer Interface. The proportion of linkage slave inverter: This inverter communication address =1~127, Communication interface A and B both can be set as communication interface of slave inverter for the proportion of linkage. Seeing appendix 2 for detailed specification.</p>						
A29	Baud Rate	Baud rate is 1200	0	-	4	Y
		Baud rate is 2400	1			
		Baud rate is 4800	2			
		Baud rate is 9600	3			

Section V Parameter Function Table

		Baud rate is 19200	4			
		Baud rate is 38400	5			
The baud rate of communication port A can be set accordingly. The baud rate of communication port B is fixed 19200bps.						
A30	Communication Format	8, N, 1 for RTU	0	-	0	Y
		8, N, 2 for RTU	1			
		8, E, 1 for RTU	2			
		8, O, 1 for RTU	3			
		8, E, 2 for RTU	4			
		8, O, 2 for RTU	5			
Seeing attachment for detailed specification.						
A31	Communications Troubleshooting	N warning for communication fault	0	-	0	Y
		Warning and running	1			
		Warning and decelerating stop	2			
		Warning and free stopping	3			
A32	Delay Inspection Time	0: N inspection		s	10	Y
		1~250: late inspection				
When communication time between interface A or B surpassed A32 delayt inspection time, the system will warn according to A31 setting. After power on, interface without communication will not implement warning.						
A33	Total Running Time Setting	Auto clear to zero after power on	0	-	1	Y
		Continue to accumulate running time after power on	1			
To set whether the time of inverer running accumulating or not. 0: Auto clear to 0 after power on. 1: Continue to accumulate running time after power on.						
A34	Unit Of Total Running Time	hour	0	-	0	Y
		Day	1			
The set for unit of accumulation running time, only for display of running time. 0: unit /hour display range 0~3200.0 hour. 1: unit/day display range 0~3200.0 day.						
A35	Motor Output Speed Adjustment	0.1~1000.0		%	100.0	Y
Using for displaying adjustment of motor actual running speed.SeeingA00~A02 monitor options: 6: motor actual running speed. Setting 100%, corresponding display unit : rpm. The max speed of displaying after adjustment is 9999.						
A36	Adjustment Of Motor Output Power	0.1~1000.0		%	100.0	Y
Used for displaying motor ouput power of adjustment. Seeing A00~A02 monitor options: 11 :motor output power. Setting 100%, corresponding display unit:%. The max ouput power of displaying after adjustment is 2999.9.						
A37	Keyboard Lock	0~OFF		-	OFF	Y

Section V Parameter Function Table

Function Options																						
<p>Key SET+ESC in Keyboard can activate and cancel keyboard lock function.</p> <p>To lock which key will be decided by corresponding parameter :</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td style="text-align: center;">2^7</td> <td style="text-align: center;">2^6</td> <td style="text-align: center;">2^5</td> <td style="text-align: center;">2^4</td> <td style="text-align: center;">2^3</td> <td style="text-align: center;">2^2</td> <td style="text-align: center;">2^1</td> <td style="text-align: center;">2^0</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> </table> <div style="margin-left: 100px;"> <p>↑ FWD</p> <p>↑ STOP</p> <p>↑ PRG</p> <p>↑ SET</p> <p>↑ ESC</p> <p>↑ MF1</p> <p>↑ MF2</p> <p>↑ Potentiometer</p> </div>							2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0	7	6	5	4	3	2	1	0
2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0															
7	6	5	4	3	2	1	0															
Set 0~10 bit		Keyboard locked state																				
0	0	Unlock FWD key																				
	1	Lock FWD key																				
1	0	Unlock STOP key																				
	1	Lock STOP key																				
2	0	Unlock PRG key																				
	1	Lock PRG key																				
3	0	unlock SET key																				
	1	Lock SET key																				
4	0	Unlock ESC key																				
	1	Lock ESC key																				
5	0	Unlock MF1 key																				
	1	Lock MF1 key																				
6	0	Unlock MF2 key																				
	1	Lock MF2 key																				
7	0	Unlock potentiometer																				
	1	Lock potentiometer																				
A38	UP/DN Control	1 bit	Power down to save	0	-	0000	Y															
			Power down to clear saving	1																		
		10 bit	saving after stopping	0																		
			Stop command to clear saving	1																		
		100 bit	Cleared at the end of stopping	2																		
			One-direction adjustment	0																		
			Double-direction adjustment	1																		
1000 bit	Invalide adjustment	0																				
	Valide adjustment	1																				
<p>1 bit: UP/DN control saving state after power down</p> <p>0: power down to save</p> <p>1: power down to clear</p>																						

<p>10 bit: UP/DN control saving after stopping 0: Keeping afer stopping 1: Stop command to clear saving 2: Cleared at the end of stopping</p> <p>100 bit: UP/DN control direction of adjustment. 0: one direction adjustment, it is one direction adjustment within 0~max frequency range. 1: double direction adjusment, it is FEW and REW adjustment within 0~max frequency range.</p> <p>1000 bit: UP/DN control validity of adjustment. 0: UP/DN invalid ajustment 1 : UP/DN valid adjustment</p>												
A39	UP/DN Time	1 bit	UP fix speed	0	-	0000	N					
			UP fix times	1								
		10 bit	DN fix speed	0								
			DN fix times	1								
		100 bit	UP N adjustmentof speed ratio	0								
			A11 adjustment of the external analog giving	1								
			A12 adjustment of the external analog giving	2								
			A13 adjustment of the external analog giving	3								
			adjustment of Potentiometer giving	4								
			Adjustment of multi -steps digital voltage	5								
		1000 bit	DN N adjustmentof speed ratio	0								
			A11 adjustment of the external analog giving	1								
			A12 adjustment of the external analog giving	2								
			A13 adjustment of the external analog giving	3								
adjustment of Potentiometer giving	4											
Adjustment of multi -steps digital voltage	5											
<p>1 bit: UP acceleration mode 0: fix speed acceleration, according to A41 fix speed: To increase frequency every 200ms. 1: fix times acceleration, according to fix times: To increase frequency every triggering.</p> <p>10 bit: DN deceleration mode 0: fix speed deceleration, according to A42 fix speed: To reduce frequency every 200ms. 1: fix times deceleration, according to A42 fix times: To reduce frequency every triggering.</p> <p>100 bit: UP adjustment mode of adjusting speed ratio</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 5%; text-align: center;">0</td> <td style="width: 40%;">UP N Adjustment Of Speed Ratio</td> <td style="width: 55%;">N adjustment</td> </tr> <tr> <td style="text-align: center;">1</td> <td>A11 Adjustment Of The</td> <td>Actual UP adjustment ratio= percentage given by A41*A11</td> </tr> </table>							0	UP N Adjustment Of Speed Ratio	N adjustment	1	A11 Adjustment Of The	Actual UP adjustment ratio= percentage given by A41*A11
0	UP N Adjustment Of Speed Ratio	N adjustment										
1	A11 Adjustment Of The	Actual UP adjustment ratio= percentage given by A41*A11										

Section V Parameter Function Table

	External Analog Giving	
2	A12 Adjustment Of The External Analog Giving	Actual UP adjustment ratio= percentage given by A41*A12
3	A13 Adjustment Of The External Analog Giving	Actual UP adjustment ratio= percentage given by A41*A13
4	Adjustment Of Potentiometer Giving	Actual UP adjustment ratio= percentage given by A41* potentiometer
5	Adjustment Of Multi-steps Digital Voltage	Actual UP adjustment ratio=percentage given by A41* multi-steps digital voltage

1000 bit: DN adjustment mode of adjusting speed ratio

0	N Adjustment Of Acceleration Time	N adjustment
1	A11 Adjustment Of The External Analog Giving	Actual DN adjustment ratio =percentage given by A42*A11
2	A12 Adjustment Of The External Analog Giving	Actual DN adjustment ratio =percentage given by A42*A12
3	A13 Adjustment Of The External Analog Giving	Actual DN adjustment ratio=percentage given by A42*A13.
4	Adjustment Of Potentiometer Giving	Actual DN adjustment ratio=percentage given by A42*potentiometer
5	Adjustment Of Multi-steps Digital Voltage	Actual DN adjustment ratio=percentage given by A42*multi-steps digital volatge.

A40	UP/DN Adjustment Value	-300.00~300.00	-	0.00	N
-----	------------------------	----------------	---	------	---

Frequency after adjustment = set frequency + UP/DN adjustment value.

A41	UP Adjustment Ratio	0.01~20.00	Hz	0.01	Y
-----	---------------------	------------	----	------	---

Fix speed: To increase frequency every 200ms.

Fix times: To increase frequency every triggering.

A42	DN Adjustment Ratio	0.01~20.00	Hz	0.01	Y
-----	---------------------	------------	----	------	---

Fix speed: To reduce frequency every 200ms.

Fix times: To reduce frequency every triggering.


A43 A44	The Definition Of Multifunction Keys MF1 And MF2	MF is defined as adding function key	0	-	0	Y
		MF is defined as reducing function key	1			
		MF is defined as free stopping key	2			
		MF is defined as FWD running key	3			
		MF is defined as REV running key	4			
		MF is defined as forward JOG function key.	5			
		MF is defined as reverse JOG function key.	6			
		MF is defined as JOG function key.	7			
		MF is defined as UP function key	8			
		MF is defined as Down function	9			

		key.			
		UP / DN adjusted value reset	10		
		keyboard potentiometer setting value resey	11		
<p>The user defined keyboard can define MF key functions.</p> <p>0 : MF is defined as adding function key: Under monitor menu, adding function key MF can adding revise frequency F01 set. Under parameter choosing menu, adding function key MF can adjust parameter choice. Under parameter revising menu, adding function key MF can adjust parameter value.</p> <p>1 : MF is defined as reducing function key: Under monitor menu, reducing function key MFcan reducing revise frequency F01 set Under parameter choosing menu, reducing function key MF can adjust parameter choice. Under parameter revising menu, reducing function key MF can adjust parameter value.</p> <p>2 : MF is defined as free stopping key: MF key is valid under monitor menu and select parameter menu, inverter will be free stopping. After free stop, no start command, 1 S later, allow running again..</p> <p>3 : MF is defined as FWD running key: Pressing MF key is valid under monitor menu and parameter choosing menu, inverter will be forward running.</p> <p>4 : MF is defined as REV running key: Pressing MF key is valid under monitor menu and parameter choosing menu, inverter will be reverse running.</p> <p>5 : MF is defined as forward JOG function key: Pressing MF key is valid under monitor menu and parameter choosing menu, inverter will be forward JOG running.</p> <p>6 : MF is defined as reverse JOG function key: Pressing MF key is valid under monitor menu and parameter choosing menu, inverter will be reverse JOG running.</p> <p>7 : MF is defined as JOG function key: Pressing MF key is valid under monitor menu and parameter choosing menu, inverter will be JOG running. Running direction decided by F35 bit setting and terminal state.</p> <p>8 : MF is defined as UP function key: Pressing MF is always valid, inverter will be UP control, control parameter decided by A38~A42.</p> <p>9 : MF is defined as Down function key: Pressing MF is always valid, inverter will be DOWN control, control parameter decided by A38~A42.</p> <p>10: MF is defined as the UP / DN adjusted value resetA40 UP / DN adjusted value reset, level-triggered.</p> <p>11 : MF is defined as the setting value of potentiometer on the keyboard A47 keyboard potentiometer setting is reset, level-triggered</p>					
A45	Keyboard Potentiometer X1	0~100.0	%	0.0	Y
The start point of value keyboard potentiometer set.					
A46	Keyboard PotentiometerX2	0~100.0	%	100.0	Y
The end point of value keyboard potentiometer set.					
A47	The Value Of Keyboard Potentiometer Set	0.0~100.00	%	-	Y
<p>Displaying value potentiometer set, which can be revised by potentiometer under monitor menu. Value potentiometer set can be regarded as analog of frequency giving , set value = max frequency *keyboard potentiometer set value.</p>					

Section V Parameter Function Table

Potentiometer set value can be regarded as value of PID giving,value of PID giving=keyboard potentiometer set value.							
A48	Keyboard Potentiometer X1 corresponding value Y1	-100.0~100.0	%	0.00	Y		
A49	Keyboard Potentiometer X2 Corresponding Value Y2	-100.0~100.0	%	100.00	Y		
A50	Keyboard Potentiometer Control	1 bit	Saving after power down	0	-	0000	Y
			Cleared after power down	1			
		10 bit	Saving after stoppoing	0			
			Clear saving after stopping command	1			
			Clear saving at end of stopping	2			
		100 bit	Reserved				
1000 bit	Reserved						
1 bit: Saving state of potentiometer after power down. 0: Saving after power down. 1: Clearing saving after power down. 10 bit: keeping potentiometer set after stopping. 0: keeping after stopping 1: To clear saving after stop command. 2: To clear saving at end of stopping.							
A51	Temperature Adjustment Of Motor	0.0~200.0	%	100.0	N		
Being used to revise displaying of A54 motor temperature.							
A52	Over-heat Temperature Of Motor	0.0~300.0	℃	120.0	N		
A53	Reaction For Motor Over-heat	N reaction for motor over-heat	0	-	0	Y	
		Warning and runing	1				
		Warning and deceleration stopping	2				
		Warning and free stopping	3				
When the displaying value of motor temperature A5 surpassed value A52, inverter will warn and react according to reaction for motor over-heat A53 set.							
A54	Display Of Motor Temperature	-50.0~300.0	℃	-	N		

Shows the motor temperature or temperature at other point.
 Control card PT100 plug should plug into the optional PT100 thermocouple devices
 Three lines PT100




A55	Proportion Of Linkage Ratio	0.10~10.00	-	1.00	Y
-----	-----------------------------	------------	---	------	---

In application of proportion of linkage, A55 setting is multiply ratio of that when slave inverter received setting frequency command from host inverter.
 Setting this inverter as one slave inverter of system for proportion of linkage.
 Frequency Keyboard F01 set=proportion of linkage ratio* frequency S00 set by host inverter

5-2-5.IO function group:o00-o68(0x0200-0x0244)

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited
o00	AI1 Input X1	0~100.0	%	0.0	Y
o01	AI1 Input X2	0~100.0	%	100.0	Y
o02	AI2 Input X1	0~100.0	%	0.0	Y
o03	AI2 Input X2	0~100.0	%	100.0	Y
o04	AI3 Input X1	0~100.0	%	0.0	Y
o05	AI3 Input X2	0~100.0	%	100.0	Y
o06	AI1 Input X1 Corresponding Value Y1	-100.0~100.0	%	0.0	Y
o07	AI1 Input X2 Corresponding Value Y2	-100.0~100.0	%	100.0	Y
o08	AI2 Input X1 Corresponding Value Y1	-100.0~100.0	%	0.0	Y
o09	AI2 Input X2 Corresponding Value Y2	-100.0~100.0	%	100.0	Y
o10	AI3 Input X1 Corresponding Value Y1	-100.0~100.0	%	0.0	Y
o11	AI3 Input X2 Corresponding Value Y2	-100.0~100.0	%	100.0	Y


Under the situation Max frequency = 50.00hz:




X1=0%, Y1=0% potentiometer 0V corresponding set frequency: f=Max frequency*Y1=0.00Hz

Section V Parameter Function Table


X2=100%,Y2=100% potentiometer 10V corresponding set frequency: $f = \text{Max frequency} * Y2 = 50.00\text{Hz}$



X1=20%, Y1=0% potentiometer 2V corresponding set frequency: $f = \text{Max frequency} * Y1 = 0.00\text{Hz}$
 X2=50%, Y2=50% potentiometer 5V corresponding set frequency: $f = \text{Max frequency} * Y2 = 25.00\text{Hz}$



X1=0%, Y1=20% potentiometer 0V corresponding set value: $f = \text{Max frequency} * Y1 = 10.00\text{Hz}$
 X2=50%, Y2=50% potentiometer 5V corresponding set value: $f = \text{Max frequency} * Y2 = 25.00\text{Hz}$



X1=0%, Y1=-100% potentiometer 0V corresponding set frequency: $f = \text{Max frequency} * Y1 = -50.00\text{Hz}$
 X2=100%, Y2=100% potentiometer 10V correspond set frequency: $f = \text{maximum frequency} * Y2 = 50.00\text{Hz}$

Skipping thread of A11, A12, A13 respectively are JP3/JP5, JP6, JP7, seeing the following detailed specification:

JP3
 1 -10V~+10V DC
 2 0~+10V DC (default)
 3

JP5
 Disconnesso 0~+10V DC (default)
 In corto 0~20mA DC

JP6
 Disconnect 0~+10V DC
 Shorted 0~20mA DC (Default)


JP7
 Disconnesso 0~+10V DC
 Shorted 0~20mA DC (Default)

o12	A11 Input Filter Time	0.00~2.00	s	0.10	Y
o13	A12 Input Filter Time	0.00~2.00	s	0.10	Y

Section V Parameter Function Table

o14	A13 Input Filter Time	0.00~2.00	s	0.10	Y																																	
Filter time constant of analog signal input, that is 0.00~2.00s.If time parameter is set too long, the changement of setting frequency will be stable, but responding speed will be slow;If time parameter is set too short, the changement of setting frequency will not be stable, but responding speed will be quick.																																						
o15 o16	DA1 Output Terminal	N reaction	0	-	-	Y																																
		Setting frequency	1																																			
		Actual frequency	2																																			
		Actual current	3																																			
	DA2 Output Terminal	Output voltage	4																																			
		DC bus volgte	5																																			
		IGBT temperature	6																																			
		Output power	7																																			
		Output RPM	8																																			
		Actual value of torque	9																																			
o17	DA1 Adjustment Of Lower Limit Output	0.0~100.0	%	0.0	Y																																	
o18	DA1 Adjustment Of Upper Limit Of Output	0.0~100.0	%	100.0	Y																																	
o19	DA2 Adjustment Of Lower Limit Output	0.0~100.0	%	0.0	Y																																	
o20	DA2 Adjustment Of Upper Limit Output	0.0~100.0	%	100.0	Y																																	
<table border="1"> <thead> <tr> <th>Output Content</th> <th>Setting Value</th> <th>Giving Output Singla Range</th> </tr> </thead> <tbody> <tr> <td>N Reaction</td> <td>0</td> <td>N output</td> </tr> <tr> <td>Setting Frequency</td> <td>1</td> <td>0~Max frequency</td> </tr> <tr> <td>Actual Frequency</td> <td>2</td> <td>0~Max frequency</td> </tr> <tr> <td>Actual Current</td> <td>3</td> <td>0~200%, corresponding parameter: S03 percentage of output curent</td> </tr> <tr> <td>Output Voltage</td> <td>4</td> <td>0~200%, corresponding parameter: b02、 b15 rate voltage of motor</td> </tr> <tr> <td>DC Bus Voltage</td> <td>5</td> <td>0~1000VDC, DC voltage</td> </tr> <tr> <td>IGBT Temperature</td> <td>6</td> <td>0~100.0℃</td> </tr> <tr> <td>Output Power</td> <td>7</td> <td>0~200%</td> </tr> <tr> <td>Output RPM</td> <td>8</td> <td>0~Max RPM</td> </tr> <tr> <td>Actual Value Of Torque</td> <td>9</td> <td>0~200% torque</td> </tr> </tbody> </table>						Output Content	Setting Value	Giving Output Singla Range	N Reaction	0	N output	Setting Frequency	1	0~Max frequency	Actual Frequency	2	0~Max frequency	Actual Current	3	0~200%, corresponding parameter: S03 percentage of output curent	Output Voltage	4	0~200%, corresponding parameter: b02、 b15 rate voltage of motor	DC Bus Voltage	5	0~1000VDC, DC voltage	IGBT Temperature	6	0~100.0℃	Output Power	7	0~200%	Output RPM	8	0~Max RPM	Actual Value Of Torque	9	0~200% torque
Output Content	Setting Value	Giving Output Singla Range																																				
N Reaction	0	N output																																				
Setting Frequency	1	0~Max frequency																																				
Actual Frequency	2	0~Max frequency																																				
Actual Current	3	0~200%, corresponding parameter: S03 percentage of output curent																																				
Output Voltage	4	0~200%, corresponding parameter: b02、 b15 rate voltage of motor																																				
DC Bus Voltage	5	0~1000VDC, DC voltage																																				
IGBT Temperature	6	0~100.0℃																																				
Output Power	7	0~200%																																				
Output RPM	8	0~Max RPM																																				
Actual Value Of Torque	9	0~200% torque																																				

Section V Parameter Function Table





This parameter is used for setting upper/lower limitation of DA1/DA2 output signal.

Such as:

If DA1 output 1~5V voltage, setting parameter as: o17=10.0%, o18=50.0%

If DA2 output 4~20mA current, setting parameter as: o19=20.0%, o20=100.0%

DA1, DA2 Skipping thread:



Caution: Every terminal has choice of voltage output and current output, the default setting is voltage output. When the voltage output is needed, please connect JP1/JP2 and DA1V/DA2V(seeing the panel); When the current output is needed, please connect JP1/JP2 and DA1C/DA2C.

		No function	0			
		Fault warning	1			
		Over current inspection	2			
		Over load inspection	3			
		Over voltage inspection	4			
		Less voltage inspection	5			
		Low load inspection	6			
		Over heat inspection	7			
		Running state with command	8			
o21	O1 Output Signal Option1	Abnormal PID feedback signal	9	-	0	Y
o22	O2 Output Signal Option2	Motor state of REW running	10	-	1	Y
o23	O3 Output Signal Option3	Arrival of setting the frequency	11	-	8	Y
o24	O4 Output Signal Option4	Arrival of Upper frequency	12			
		Arrival of Lower frequency	13			
		Arrival of FDT setting frequency 1	14			
		Arrival of FDT setting frequency 2	15			
		FDT frequency level inspection	16			
		Arrival of preset counter value	17			
		Arrival of upper limit counter	18			
		Program running one period completed	19			

	Speed tricking mode inspection	20			
	No command running state	21			
	REV running from inverter command	22			
	Deceleration running	23			
	Acceleration running	24			
	Arrival of high pressure	25			
	Arrival of low pressure	26			
	Arrival of inverter rate current	27			
	Arrival of motor rate current	28			
	Arrival of input frequency lower limitation	29			
	Arrival of current upper limitation	30			
	Arrival of current lower limitation	31			
	Time to reach limit time 1	32			
	Time to reach limit time 2	33			
	Inverter ready to run	34			

Setting Value	Output Content	Specification Explanation
0	No Function	Setting -0° , N output reaction, but inverter can be controlled by theoretical terminal.
1	Fault Warning	Inverter at fault or after fault with unconfirmed status.
2	Over Current Inspection	Inverter met fault of over current
3	Over Load Inspection	Inverter met fault of over load of heat protection
4	Over Voltage Inspection	Inverter met fault of over voltage
5	Less Voltage Inspection	Inverter met fault of less voltage
6	Lower Load Inspection	Inverter met fault of lower load
7	Over Heat Inspection	Inverter met fault of over heat.
8	Running State Of Command	Inverter is under running state of command
9	Abnormal PID Feedback Signal	PID feedback signal is abnormal
10	Motor State Of REW Running	Motor is reverse running
11	Arrival Of Setting Frequency	Arrive at set frequency
12	Arrival Of Upper Frequency	Arrive at upper frequency
13	Arrival of lower frequency	Arrive at lower frequency
14	Arrival Of FDT Set Frequency1	Arrive at frequency 1 FDT set
15	Arrival Of FDT Set Frequency2	Arrive at frequency 2 FDT set
16	Inspection Level Of FDT Frequency	FDT frequency levels to meet the inspection conditions, 029~031
17	Arrival Of Preset Counting Value	Present counting value arrives at preset counting value


Section V Parameter Function Table

18	Arrival Of Counting Value Upper Limitation	Present counting value arrives at upper limitation of counting value.			
19	Program Running One Period Completion	Program runs one period to complete.			
20	Inspection In Speed Trick Mode	Inverter is under speed trick state, the valid time is A11			
21	No Command Running State	Inverter is under N command running state			
22	REW Command Of Inverter	Inverter is under reverse running command			
23	Deceleration Running	Inverter is under deceleration running			
24	Acceleration Running	Inverter is under acceleration running			
25	Arrival Of High Pressure	Arrival at high pressure			
26	Arrival Of Low Pressure	Arrival at low pressure			
27	Arrival Of Inverter Rate Current	Arrival at inverter rate current			
28	Arrival Of Motor Rate Current	Arrival at motor rate current			
29	Arrival Of Input Frequency Lower Limitation	Present set frequency is less than frequency lower limitation			
30	Arrival Of Current Upper Limitation	Arrive at current of upper limitation			
31	Arrival Of Current Lower Limitation	Arrive at current of lower limitation			
32	Time to reach limit time 1	Timing action mode refer to o65 configuration			
33	Time to reach limit time 2	Timing action mode refer to o66 configuration			
34	Inverter ready to run	The end of initialization when the drive power on , running command is acceptable.			
o25	Output Signal Delay 1	0~32.000	s	0	Y
o26	Output Signal Delay 2	0~32.000	s	0	Y
o27	Output Signal Delay 3	0~32.000	s	0	Y
o28	Output Signal Delay 4	0~32.000	s	0	Y
o25~o28 defines o21~o24 output signal reaction delay time, unit is S. Output signal cut off action without delay.					
o29	FDT Set Frequency 1	o30~Max frequency	Hz	0.00	Y
o30	FDT Set Frequency 2	0~o29	Hz	0.00	Y
o31	FDT Inspection Range	0.00~5.00	Hz	0.00	Y
<p>When the choice of output signal(o21~o24)is set as14, inverter output frequency arrives at or surpass FDT set frequency 1, the corresponding signal output terminal will react; When inverter output frequency is below of frequency 1 FDT set, the corresponding signal output terminal will not react.</p> <p>When the output signal options(o21~o24)is set as 15, inverter output frequency reaches or surpass FDT set frequency 2, the corresponding signal output terminal will react;When inverter output frequency is below of frequency 3 FDT set, the corresponding signal output terminal will not react.</p> <p>When the output signal options (o21~o24)is set as16, inverter will firstly inspect FDT set frequency 1, then inverter output frequency arrives at or surpass FDT set frequency 1, the corresponding signal output terminal will react;After terminal reaction, inverter will inspect FDT set frequency 2, When inverter output frequency is below of frequency 2 FDT set, the corresponding signal output terminal will not react.</p>					
o31 frequency inspection range					


This parameter is used to define inspection range. When the difference of actual frequency and inspected frequency has surpassed inspection range, terminal will output react.

e.g.: FDT set frequency 1 as 35Hz, FDT set frequency 2 as 30Hz,

Frequency inspection range is 0, the signal output terminal will react as below:



o32	Arrival Of Current Upper Limitation	o33~200%	%	120	Y
o33	Arrival Of Current Lower Limitation	o34~o32	%	20	Y
o34	Current Inspection Range	0~o33	%	3	Y



When the output signal options (o21~o24) is set as 30, and inverter output current reach or surpass $-o32+o34$, the corresponding output signal terminal will react. When the inverter output current is less than $o32-o34$, The corresponding output signal terminal will not react.

When the output signal options (o21~o24) is set as 31, and inverter output frequency reach or less than $o33-o34$, the corresponding output signal terminal will react; When the inverter output current is more than $o33+o34$, The corresponding output signal terminal will not react.

o34 is used to define current inspection range. When the difference of actual current and inspected current has surpassed inspection range, The output terminal will react.

o35	Terminal Control Mode	bit	Two-wire running control 1	0	-	0000	N
			Two-wire running control 2	1			

Section V Parameter Function Table

Section V

			Three-wire running control 1	2		
			Three-wire running control 2	3		
			One-shot operation control 1	4		
			One-shot operation control 2	5		
		10 bit	Terminal command is invalid after power on running	0		
			Terminal command is valid after power on running	1		

Setting terminal running mode by this parameter.


1 Bit set terminal running mode:

The polarity of electrical level is 047 default setting polarity. Low electrical level or falling edge is valid, and the terminal is leakage-source driving mode.

X can be used to express high or low electrical level, rising or falling edge.


Running Control Mode	Keyboard Running Control	Prior Running	Prior Direction
Edge Trigger	Valid	Same	Same
E-level Trigger	Invalid	Prior running	Prior FWD

0: Two wire running control 1



F05=1 or F05=4		F05=3		Command
FWD	REV	FWD	REV	
Rising edge	X	Low E Level	X	FWD running
X	Falling edge	High E-level	Low E-level	REV running
Falling edge	Rising edge	High E-level	High E-level	STOP running


1: Two wire running control 2



F05=1 or F05=4		F05=3		Command
FWD	REV	FWD	REV	
Falling edge	Falling edge	Low e-level	Low e-level	FWD running


Falling edge	Rising edge	Low e-level	High e-level	REV running
Rising edge	X	High e-level	X	STOP running

2: Three wire running control 1




F05=1 ; F05=3; F05=4			Command
FWD	REV	STOP	
Falling edge	Low e-level	Low e-level	FWD running
Falling edge	High e-level	Low e-level	REV running
X	X	High e-level	STOP running

3: Three wire running control 2



F05=1 ; F05=3; F05=4			Command
FWD	REV	STOP	
Falling edge	X	Low e-level	FWD running
X	Falling edge	Low e-level	REV running
X	X	High e-level	STOP running


4: One-shot operation control 1



F05=1; F05=4; F05=3		Command	Current state
FWD	REV		
	X	FWD running	STOP running
Keep		REV running	STOP running
	X	STOP running	FWD running
Keep		REV running	FWD running
	X	FWD running	REV running
Keep		STOP running	REV running

5: One-shot operation control 2

Section V Parameter Function Table



F05=1; F05=4; F05=3		Command	Current state
FWD	REV		
	Low e-level	FWD running	STOP running
	High e-level	REV running	STOP running
	X	STOP running	FWD running
	X	STOP running	REV running

10 bit: Set the terminal status when power on

0: Terminal run command invalid when Power on.

Terminal run command invalid when power on., Only run 3S later after power on and set terminals invalid.

1: Terminal run command valid when Power on.

Terminal status is effective when power on, inverter will run immediately, in some cases such status will not be allowable.

		No function	0			
		Forward running FWD	1			
		Reverse running REV	2			
		3-line mode running STOP	3			
	(DI1) Input Terminal Function Selection	Multi-segment command 1	4			
	(DI2) Input Terminal Function Selection	Multi-segment command 2	5			
	(DI3)Input Terminal Function Selection	Multi-segment command 3	6			
o36	(DI4) Input Terminal Function Selection	Multi-segment command	7	-	0	Y
o37	(DI5) Input Terminal Function Selection	Multi-segment speed command 1	8	-	0	Y
o38	(DI6) Input Terminal Function Selection	Multi-segment speed command 3	10	-	0	Y
o39	(DI7) Input Terminal Function Selection	Multi-segment digital voltage 1	11	-	0	Y
o40	(DI8) Input Terminal Function Selection	Multi-segment digital voltage 2	12	-	0	Y
o41	(AI1) Input Terminal Function Selection	Multi-segment digital voltage 3	13	-	0	Y
o42	(AI2) Input Terminal Function Selection	The main set mode 1 of set frequency	14	-	0	Y
o43	(AI3) Input Terminal Function Selection	The main set mode 2 of set frequency	15			
o44		The main set mode 3 of set frequency	16			
o45		The auxiliary setting mode 1 of frequency set	17			
o46		The auxiliary setting mode 2 of frequency set	18			

	The auxiliary setting mode 3 of frequency set	19			
	MSS time running 1	20			
	MSS time running 2	21			
	MSS time running 3	22			
	Operation control mode shift 1	23			
	Operation control mode shift 2	24			
	Operation control mode shift 3	25			
	Forward torque limit shift 1	26			
	Forward torque limit shift 2	27			
	Forward torque limit shift 3	28			
	Reverse torque limit shift 1	29			
	Reverse torque limit shift 2	30			
	Reverse torque limit shift 3	31			
	Torque speed shift	32			
	fault reset command	33			
	FWD JOG command	34			
	REV JOG command	35			
	JOG order (as F35setting)	36			
	Acceleration and deceleration prohibition command	37			
	Motor 1、 2 shift	38			
	Free stop	39			
	Up command	40			
	Down command	41			
	Automation program running fuction cancel	42			
	Automation program running stop	43			
	Program running start mode	44			
	Program running stop mode	45			
	Pulse counter clearance	46			
	Pulse counter input	47			
	Counter loading	48			
	Upper counter loading	49			
	External default signal input (level)	50			
	1pump soft-start	51			
	1 pump stop	52			
	2pump soft-start	53			
	2 pump stop	54			

Section V Parameter Function Table

		3pump soft-start	55		
		3 pump stop	56		
		4pump soft-start	57		
		4 pump stop	58		
		handrotate command	59		
		Timing Water Supply change to zero	60		
		Extruder acceleration and deceleration direction	61		
		Extruder acceleration and deceleration allowable	62		
		Limit time 1 input	63		
		Limit time 2 input	64		
		Program switching to the next segment	65		
		UP/DN adjusted value reset	66		
		Keyboard potentiometer set value reset	67		
		External default signal input (edge)	68		

Setting Value	Output Detail	Specification Explanation
0	No function	N- function
1	Forward command FWD	Forward command FWD, Can be set to edge triggered or level-triggered
2	Reverse command REV	Reverse command REV, Can be set to edge triggered or level-triggered
3	Three line running STOP	035 setting 3 line running, STOP function
4	Multi-speed command 1	Synthes is of16 multi-speed settings.See H parameter Group
5	Multi-speed command 2	
6	Multi-speed command 3	
7	Multi-speed command 4	
8	multi-acceleration command 1	Synthes is of 8 acceleration settings.See H parameter Group
9	multi-acceleration command 2	
10	multi-acceleration command 3	
11	multi-segment digital voltage 1	Synthes is of8digital voltage settings.See H parameter Group
12	multi-segment digital voltage 2	
13	multi-segment digital voltage 3	
14	The main set mode 1 of set frequency	Synthesized frequency given to the way the main switch. See F parameter group
15	The main set mode 2 of set	

	frequency	
16	The main set mode 3 of set frequency	
17	The auxiliary setting mode 1 of frequency set 1	
18	The auxiliary setting mode 2 of frequency set	Synthesized frequency secondary to the way a given switch. See F parameter set
19	The auxiliary setting mode 3 of frequency set	
20	MSS timing running 1	
21	MSS timing running 2	Synthes is of segment8 run time setting. See H parameter set.
22	MSS timing running 3	
23	Operation control mode shift 1	
24	Operation control mode shift 2	Synthes is of operation mode switching. Read F05 parameter
25	Operation control mode shift 3	
26	Forward torque limit shift 1	
27	Forward torque limit shift 2	Synthes is of reverse torque limit switch. See C parameter set C15 Group
28	Forward torque limit shift 3	
29	Reverse torque limit shift 1	
30	Reverse torque limit shift 2	Synthes is of reverse torque limit switch. See C parameter set C16 Group
31	Reverse torque limit shift 3	
32	Torque speed shift	Vector control mode, speed control mode and torque control mode switching. Disconnected status: Speed Control Closed Status: torque control Detail C parameter set C18
33	Fault reset command	Edge-triggered, the fault occurred on the current failure to confirm or not confirm
34	FWD JOG command	JOG forward running command
35	REV JOG command	JOG reverse running command
36	JOG command(as F35 setting)	JOGrunning command,direction,set a direction in accordance with F35.
37	Acceleration and deceleration forbid commandr	To maintain the current state to prohibit the acceleration and deceleration movements.
38	Motor 1、2 shift	Motor 1、2 change Invalid status : Motor 1 Valid status : Motor 2
39	Free stop	Free stop:After free stop, no start command,after 1s, allows running again
40	Up command	Up order, detail A38~A42
41	Down command	Down order, detail A38~A42
42	Auto-run feature programs canceled	Cancle program running function

Section V Parameter Function Table



43	Automatic procedures to suspend operation	program running pause
44	program running start mode	program running start mode
45	program running stop mode	program running stop mode
46	pulse count clearance	Edge-triggered,frequency inverter pulse counter053Clearance
47	pulse count input	Edge-triggered, set the pulse counter input terminal
48	before count loading	Edge-triggered, pulse-load preset counter o53counts to o54
49	upper count loading	Edge-triggered pulse counter counts o5 maximum load o53
50	External default signal input (level)	External default signal input(level), level trigger , the system will alarm E. Set after valid
51	1 pump soft-start	Electric level spring, control 1 pump soft-start or stop. soft-start control must use 2 terminal control, stop priority.
52	1 pump stop	Need to set E01 load model 9, E12 1pump is soft-start control pump.
53	2 pump soft-start	Electric level spring, control 2 pump soft-start or stop. soft-start control must use 2 terminal control,stop priority.
54	2 pump stop	Need to set E01 load model 9, E12 2pump is soft-start control pump.
55	3pump soft-start	Electric level spring, control 3 pump soft-start or stop. soft-start control must use 2 terminal control, stop priority.
56	3 pump stop	Need to set E01 load model 9 , E12 3pump is soft-start control pump.
57	4 pump start	Electric level spring, control 4 pump soft-start or stop. Soft-start control must use two terminal control, stop has the priority.
58	4 pump stop	Need setting E01 load style 9, E12 4 pump is soft - start control pump.
59	Hand change order	electric level spring, automation multi-pump constant water changed
60	the period of time water supply change to zero	electric level spring the period of time water supply change to zero
61	Extruder acceleration and deceleration direction	DIx input terminal function selection, read o36- 046
62	Extruder acceleration and deceleration allowable	DIx input terminal function selection, read o36-046.
63	Limit time 1 input	DIx input timing - limit time 1, refer to o65, o67.
64	Limit time 2 input	DIx input timing - limit time 2, refer to o66, o68
65	Program switching to the next segment	Program running controlled, single trigger switch to the next segment
66	UP/DN adjusted value reset	A40 UP/DN adjusted value reset, level trigger.
67	Keyboard potentiometer set value reset	A47keyboard potentiometer setting value reset level trigger.
68	External default signal input (edge)	External default signal input, edge trigger (falling edge),the system will alarm E-Set after valid

o47	Polarity of input and output terminals	0000~F7FF	-	0000	Y						
<p>This parameter used to select every IO terminal is valid in which polarity and terminal running command is valid or not when power on.</p>											
0~10 bit	Input Terminal Polarity		12~15 bit	Output Terminal Polarity							
0	Low level valid(closed)		0	Low level valid(closed)							
	Falling edge valid, rising edge invalid										
1	High level valid(disconnected)		1	High level valid(cut off)							
	Rising edge valid, falling edge invalid										
o48	Input Terminal Teponse Time 0	0.001~30.000	s	0.005	Y						
o49	Input Terminal Reponse Time 1	0.001~30.000	s	0.005	Y						
o48,o49define Input terminal reponse time,through o50select the reponse time according theterminal.											
o50	Input Terminal Reponse Time Selection	0~07FF	-	0	Y						
<p>o48,o49define Input terminal reponse time,througho50select the reponse time according theterminal. The delay time of the input terminal is valid to the close and cut off action! Set the parameter choose Input terminal reponse time according every terminal.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Setting 0~10</td> <td>the polarity of input terminal</td> </tr> <tr> <td>0</td> <td>o48 input terminal reponse time 0</td> </tr> <tr> <td>1</td> <td>o49 input terminal reponse time 1</td> </tr> </table>						Setting 0~10	the polarity of input terminal	0	o48 input terminal reponse time 0	1	o49 input terminal reponse time 1
Setting 0~10	the polarity of input terminal										
0	o48 input terminal reponse time 0										
1	o49 input terminal reponse time 1										
o51	Counter Collocation	1 bit	Circle counter operating	0	-	0	Y				
			Single cycle counter running	1							

Section V Parameter Function Table

Section V

		10 bit	Arrive at upper counter value and reload	0			
		10 bit	Arrive at upper counter value and clear savings	1			
		100 bit	Power on to reload	0			
			power on to clear savings	1			
			power on to keep previous count status	2			
		1000 bit	Count period	0			
			Output signal valid time 20ms	1			
			Output signal valid time 100ms	2			
			Output signal valid time 500ms	3			
<p>1 bit: Control count mode 0: Circulate count, Arrive at upper counter value, output the arrival pulse(output terminal setting) 1: single circulate count, after arrive at upper counter value, output the arrival pulse, stop running.</p> <p>10 bit : Operating after circulate mode reach upper limit count 0: Reload 1: Clear up</p> <p>100 bit: Define the status of the counter after power on 0: Reload after power on 1: Clear up after power on 2: Keep the status of the previous count</p> <p>1000 bit: Define o21~o24 is set to reach the preset count or counts to reach the maximum output signal delay time 0: Count period, when reach this digital, keep this status valid, direct the change of the count. 1: the valid time of the output signal10ms, when reach this count, fixed keep the output status valid 10ms. 2: the valid time of the output signal 100ms, when reach this count, fixed keep the output status valid 100ms. 3: the valid time of the output signal 500ms, when reach this count, fixed keep the output status valid 500ms.</p>							
o52	Maximum Pulse Input Frequency	0.1~50.0			kHz	20.0	Y
<p>This parameter define the most pulse input frequency of analog setting frequency . Input high signal frequency, only through multi-function input terminal Di8 as the pulse input terminal. input pulse setting frequency according the the most input upper limit. input pulse setting frequency, most input pulse frequency o52according the most output frequency F12. Pulse input frequency f_pulse corresponding setting frequency f_set formula:f_set=f_pulse/o52*F12. Pulse input analog setting, input most pulse frequency o52 according 100.0%. Pulse input frequency f_pulse corresponding analog p_set formula: p_set=f_pulse/o52*100.0%.</p>							
o53	Current Counter Status	0~9999			-	0	Y
o54	Preset Counter Setting	0~o55			-	0	Y

o55	Upper Limit Counter Setting	o54~9999	-	9999	Y						
 <p>When the pulse signal of the input terminal satisfy with the preset condition, Yi terminal output the corresponding indication.</p> <p>1 、 Selection of Input terminal DiX (X=1~8) Input terminal is set to “pulse count input”, and set o54、o55. Input terminal is set to “pulse counter clear”, after terminal works, counter is cleared. Input terminal is set to “upload of pulse count value”, after terminal works, counter uploads preset count value. Input terminal is set to “upload of upper count value”, after terminal works, counter uploads the upper count value.</p> <p>2 、 Selection of Output Terminal o21~o24 o21 set the arrival of preset count, the effective time of output signal after reaching up count value is set by o51. o22 set the arrival of up count value, the effective time of output signal after arriving at the upper count value is set by o51. Frequency range of counting pulse signal: 0~100Hz.</p>											
o56	Virtual Terminal Effective Selection	0000~F7FF	-	0000	Y						
 <table border="1" data-bbox="261 1070 745 1177"> <tr> <th>Setting 0~10</th> <th>Virtual terminal valid choose</th> </tr> <tr> <td>0</td> <td>Actual input terminal valid</td> </tr> <tr> <td>1</td> <td>Virtual input terminal valid</td> </tr> </table>						Setting 0~10	Virtual terminal valid choose	0	Actual input terminal valid	1	Virtual input terminal valid
Setting 0~10	Virtual terminal valid choose										
0	Actual input terminal valid										
1	Virtual input terminal valid										
<p>This parameter is used to select a terminal whether each virtual terminal functionality is valid.</p>											
o57	DI1~4 Terminal Status	0000~1111	-	-	Y						
o58	DI5~8 Terminal Status	0000~1111	-	-	Y						
o59	AI1~3 Terminal Status	000~111	-	-	Y						
o60	O1~4 Terminal Status	0000~1111	-	-	Y						
<p>Make the actual terminal can only be effective check terminal state. Make the Virtual terminal can only be effective through register check terminal state.</p>											
o61	PL1 Pulse Output	No action	0	-	0	Y					
o62	PL2 Pulse Output	Set frequency	1	-	0	Y					

Section V Parameter Function Table

		Actual frequency	2			
		Actual current	3			
		Output voltage	4			
		DC bus voltage	5			
		IGBT temperature	6			
		Output power	7			
		Output rpm	8			
		Actual torque	9			
o63	SPA pulse output ratio	1~1000	-	1	Y	
o64	SPB pulse output ratio	1~1000	-	1	Y	

SPA, SPB provide two isolated pulse output signal can be analogical multiple analog output signals.

SPA, SPB provide high speed pulse output function. Set by o61~o64 and set functions valid when inverter power on again.

SPA corresponding output signal 1, this function selected, o21 DO1 output action is invalid.

SPB corresponding output signal 2, this function selected, o22 DO2 output action is invalid.

Pulse output ratio = 1, output signal range 0 ~ 50hz.

Maximum pulse output frequency 50 KHz, minimum frequency 1hz.

for example

SPA pulse output options = 2 Actual frequency ;

SPA pulse output options = 10

The actual output pulse frequency = actual frequency / maximum frequency * 50hz*10.

SPA pulse output options =3 Actual current

SPB pulse output ratio=20

The actual output pulse frequency = actual current percentage 200*50hz*20

Output	Set Value	Output Signal Range Definition
No action	0	No output
Set frequency	1	0~Max frequency
Actual frequency	2	0~Max frequency
Actual current	3	0~200%, corresponding parameter: S03 output current percentage
Output voltage	4	0~200%, correlation parameter: b02、 b15 motor rated voltage
Bus voltage	5	0~1000V DC voltage
IGBT temperature	6	0~100.0℃
Output power	7	0~200%
Output torque	8	0~Max torque
Actual torque value	9	0~200% torque

o65 o66	Limit time 1 configuration	1 Bit	Boot time	0	-	0000	Y
			Running timing	1	-	0000	Y

	Limit time 2 configuration	10Bit	Reserved	-		
		100Bit	Reserved	-		
		1000Bit	Reserved	-		
<p>1 Bit: Timing mode 0 Boot time , timing of running and breaking 1 Running timing, only timing of running</p> <p>10 Bit: Reserved 100 Bit: Reserved 1000 Bit: Reserved</p>						
o67	Limit Time 1	0.0~3200.0		s	2.0	Y
o68	Limit Time 2	0.0~3200.0		s	2.0	Y
<p>Set timing of limit time 1 , Time limit 2 Actual limit time on the basis of the set time multiplied by a run time multiple, such time multiple set by the ten bit of F49, refer to F49 instructions.</p>						

5-2-6. Multi-speed PLC Group:H00-H55(0x0300-0x0337)

Code	Description / LCD	Setting Range		Unit	Factory Setting	Change Limited	
H00	Multi-speed Collocation	1 bit	Program running function cancel	0	-	0000	Y
			Program running function	1			
		10 bit	Direction decided by H40~H46	0			
			Direction decided by Terminal and keyboard	1			
		100 bit	Deceleration and acceleration time decided by H26~H39	0			
			Time of acceleration and deceleration is decided by terminal	1			
		1000 bit	Running time decided by H18~H25	0			
			Running time decided by terminal	1			
<p>1 bit: Program running functions intelligent To use the program to run PLC functionality requires setting the bit to 1. Multi-segment speed run only need to set the corresponding multi-stage o36 ~ o46-speed switching can be used without the need to set this parameter. 0: Program running functions cancel 1: Program running function intelligent</p> <p>10 bit: Define program runs or direction settings of multi-segment speed running 0: the direction decided by the H40 ~ H46 1: The direction decided by the keyboard or terminal</p>							

Section V Parameter Function Table

<p>100 bit: Define program runs or acceleration and deceleration time settings of multi-segment speed running</p> <p>0: deceleration time decided by the H26 ~ H39</p> <p>1: The acceleration and deceleration time determined by terminal</p> <p>1000 bit: Set running time of defined program running</p> <p>0: running-time decided by the H18 ~ H25</p> <p>1: Running time decided by terminal</p>							
H01	Program Running Configuration	1 bit	sequence control	0	-	0710	Y
			terminal control	1			
		10 bit	Program running start segment	0~15			
			Program running end segment	0~15			
		1000 bit	Output signal valid time 8ms	0			
			Output signal valid time 20ms	1			
			Output signal valid time 100ms	2			
Output signal valid time 500ms	3						
<p>1 bit: program run control mode.</p> <p>0: sequential control</p> <p>Run automatically according to the start segment, end segment and program running time of program running.</p> <p>You can use o36 ~ o46 switchover next function , switchover to the next program running .</p> <p>1: Terminal control</p> <p>Use multi segment control terminal o36 ~ o46 multi segment instruction 1, 2, 3, 4, Control program segment, running time arrives. Running based on the 0 paragraph speed. After Multi - Stage speed control terminal switchover, reevaluate running time</p> <p>Do not use of multi - stage speed control terminal o 36 ~ o46 multi - speed instruction, You can use o36 ~ o46 switchover next function. The terminal control for single trigger, triggered once, program running to next paragraph, running time recalculated. Running time of arrival, Running based on the 0 paragraph speed.</p> <p>10 bit: defining the start running of the Program</p> <p>100 bit: Defines the end of the program period</p> <p>1000 bit: Define effective time of the program output signal</p>							
H02	Program Running Mode	1 bit	single-cycle	0	-	0000	Y
			Continuous Cycle	1			
			One-cycle command running	2			
		10 bit	The zero speed running when pause	0			
			Fixed-speed running when the suspension	1			
		100 bit	Stop with the parameters set when stop	0			
			Stop with the settings of start up	1			

			Running at the speed when start up segment	0			
		1000 bit	Running at the speed before the machine stopped	1			

1 bit: Running cycle


0: single cycle

1: continuous cycle


2: Single cycle, running according to H01 speed of the end, stop after accepted the stopped orders.

The program runs three styles as following:


Eg1: The program is run single - cycle modes



Eg2: program run Continuous cycle modes



Eg3: Program is running in single cycle, According to Paragraph seventh of Speed mode



10 bit: Running condition when pause

0: speed run when pause

1: fixed Segment Speed operation when pause

100 bit: Running Segment when stop

0: Set stopping according to the parameters of stop segment.

1: Set down to the initial segment

1000 bit: start Running Segment

0: Set down to the speed running


1: Running at the speed before the machine stopped.

100 bit=0 Set stopping according to the parameters of stop segment


Section V

Section V Parameter Function Table


1000 bit=0 running at Start Segment



Eg:100 bit=0 Set stopping according to the parameters of stop segment
 1000 bit=1 Running at the speed before the machine stopped.



Eg:100 bit=1 Set down to the initial segment
 1000 bit=1 Running at the speed before the machine stopped.



Note : at1' : at the time of segment 1 acceleration time ; dt1' : at the time of segment 1 deceleration time ; at3' at the time of segment 3 acceleration time ; dt3' : at the time of segment 3 deceleration time

H03	1 Segment Speed Setting 1X	Lower frequency ~ upper frequency	Hz	3.00	Y
H04	2 Segment Speed Setting 2X	Lower frequency ~ upper frequency	Hz	6.00	Y
H05	3 Segment Speed Setting 3X	Lower frequency ~ upper frequency	Hz	9.00	Y
H06	4 Segment Speed Setting 4X	Lower frequency ~ upper frequency	Hz	12.00	Y
H07	5 Segment Speed Setting 5X	Lower frequency ~ upper frequency	Hz	15.00	Y
H08	6 Segment Speed Setting 6X	Lower frequency ~ upper frequency	Hz	18.00	Y
H09	7 Segment Speed Setting 7X	Lower frequency ~ upper frequency	Hz	21.00	Y
H10	8 Segment Speed Setting 8X	Lower frequency ~ upper frequency	Hz	24.00	Y
H11	9 Segment Speed Setting 9X	Lower frequency ~ upper frequency	Hz	27.00	Y

H12	10 Segment Speed Setting 10X	Lower frequency ~ upper frequency	Hz	30.00	Y
H13	11 Segment Speed Setting 11X	Lower frequency ~ upper frequency	Hz	33.00	Y
H14	12 Segment Speed Setting 12X	Lower frequency ~ upper frequency	Hz	36.00	Y
H15	13 Segment Speed Setting 13X	Lower frequency ~ upper frequency	Hz	39.00	Y
H16	14 Segment Speed Setting 14X	Lower frequency ~ upper frequency	Hz	42.00	Y
H17	15 Segment Speed Setting 15X	Lower frequency ~ upper frequency	Hz	45.00	Y

Set the frequency of program running and the running frequency of 7-segment speed respectively. short-circuit the multi-terminal command 1, 2, 3, 4 with COM combinatorially to realized the 16-segment speed/acceleration speed.

0Xspeed is the regular running mode, setting source can be adjusted by F02, F03 and other parameters, running time is controlled by the H18.

Terminal multi-segment speed is defined as follows (shorted with COM it is ON, disconnected then it is OFF):

Speed Terminal	0X	1X	2X	3X	4X	5X	6X	7X
Multiterminal-speed Command 1	OFF	ON	OFF	ON	OFF	ON	OFF	ON
Multiterminal-speed Command 2	OFF	OFF	ON	ON	OFF	OFF	ON	ON
Multiterminal-speed Command 3	OFF	OFF	OFF	OFF	ON	ON	ON	ON
Multiterminal-speed Command 4	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Speed Terminal	8X	9X	10X	11X	12X	13X	14X	15X
Multiterminal-speed Command 1	OFF	ON	OFF	ON	OFF	ON	OFF	ON
Multiterminal-speed Command 2	OFF	OFF	ON	ON	OFF	OFF	ON	ON
Multiterminal-speed Command 3	OFF	OFF	OFF	OFF	ON	ON	ON	ON
Multiterminal-speed Command 4	ON	ON	ON	ON	ON	ON	ON	ON

Acceleration and deceleration time and the direction of running

		0X-7X	8X-15X
H00 10 bit	0	0X-7X Direction controlled by parameter	8X-15X Direction controlled by keyboard and terminal
	1	0X-7X Direction controlled by keyboard and terminal	
H00 100 bit	0	0X-7X deceleration and acceleration time controlled by parameter	8X-15X deceleration and acceleration time controlled by keyboard and terminal
	1	0X-7X deceleration and acceleration time controlled by terminal	
H00 1000 bit	0	0X-7X running time controlled by parameter	8X-15X running time controlled by terminal
	1	0X-7X running time controlled by terminal	


H18	0 Segment Running	0.0~3200.0	s	2.0	Y
-----	-------------------	------------	---	-----	---

Section V Parameter Function Table

	Time T0				
H19	1 Segment Running Time T1	0.0~3200.0	s	2.0	Y
H20	2 Segment Running Time T2	0.0~3200.0	s	2.0	Y
H21	3 Segment Running Time T3	0.0~3200.0	s	2.0	Y
H22	4 Segment Running Time T4	0.0~3200.0	s	2.0	Y
H23	5 Segment Running Time T5	0.0~3200.0	s	2.0	Y
H24	6 Segment Running Time T6	0.0~3200.0	s	2.0	Y
H25	7 Segment Running Time T7	0.0~3200.0	s	2.0	Y
Actual running time equals to the set multi-segment running time multiples a time which is times of speed running time, and such actual running time decided by the tens digit of H40~H46. Please refer to H40~H46.					
H26	1 Segment Acceleration Time at1	0.0~3200.0	s	10.0	Y
H27	1 Segment Deceleration Time dt1	0.0~3200.0	s	10.0	Y
H28	2 Segment Acceleration Time at2	0.0~3200.0	s	10.0	Y
H29	2 Segment Deceleration Time dt2	0.0~3200.0	s	10.0	Y
H30	3 Segment Acceleration Time at3	0.0~3200.0	s	10.0	Y
H31	3 Segment Deceleration Time dt3	0.0~3200.0	s	10.0	Y
H32	4 Segment Acceleration Time at4	0.0~3200.0	s	10.0	Y
H33	4 Segment Deceleration Time dt4	0.0~3200.0	s	10.0	Y
H34	5 Segment Acceleration Time at5	0.0~3200.0	s	10.0	Y
H35	5 Segment Deceleration Time dt5	0.0~3200.0	s	10.0	Y
H36	6 Segment Acceleration Time at6	0.0~3200.0	s	10.0	Y
H37	6 Segment Deceleration Time dt6	0.0~3200.0	s	10.0	Y
H38	7 Segment Acceleration Time at7	0.0~3200.0	s	10.0	Y
H39	7 Segment Deceleration Time dt7	0.0~3200.0	s	10.0	Y
Set the Acc/Dec time of 7 steps respectively. They determine the time needed to reach the speed, respectively depending on the acceleration time for acceleration or on the deceleration time for deceleration, but the time is not the actual time needed. Actual acc/dec time equals to the set acc/dec					

time multiplies a time multiple which is decided by the hundreds and thousands digit of H40~H46. Please refer to H40~H46.

Definite acceleration and deceleration time for multi-step speed:



Definition of multi-step speed acceleration/deceleration time

Remark: at1: 1 segment acceleration time;at2: 2 segment acceleration time;dt2: 2 segment deceleration time;dt3: 3 segment deceleration time.

H40 H41 H42 H43 H44 H45 H46	1 Segment Speed Configuration Word 2 Segment Speed Configuration Word 3 Segment Speed Configuration Word 4 Segment Speed Configuration Word 5 Segment Speed Configuration Word 6 Segment Speed Configuration Word 7 Segment Speed Configuration Word	1 bit	Running direction: forward	0	-	0000	Y	
			Running direction: reverse	1				
		10 bit	Running time: *seconds	0				
			Running time: *munites	1				
			Running time: *hours	2				
			Running time: *days	3				
		100 bit	Acceleration time: *seconds	0				
			Acceleration time: *munites	1				
			Acceleration time: *hours	2				
			Acceleration time: *days	3				
			1000 bit	Deceleration time: *seconds				0
				Deceleration time: *munites				1
		Deceleration time: *hours		2				
		Deceleration time: *days		3				

1 bit: Under multi-segment program running, the 1 bit parameter decides the direction of each segment speed.

Running Direction	Setting Value
forward	0
reverse	1

When running control mode F05=0/1/2, these parameters decide the direction of each segment speed.

When running control mode F05=3, the setting value and terminal FWD/REV decide the direction of each segment speed together. FWD is prior.

Section V Parameter Function Table

Section V

FWD=1 Running direction		REW =1 Running direction		Setting Value	
forward		reverse		0	
reverse		forward		1	

10 bit: Unit of multi-segment speed program running time.

Running Time	10 bit	Range(e.g.H18~H25=3200.0)
*seconds	0	3200.0 seconds
*minutes	1	3200.0 minutes
*hours	2	3200.0 hours
*days	3	3200.0 days

100 bit, 1000 bit : Unit of acc/deceleration time of multi-segment speed program running

Acceleration / Deceleration time	1000 bit, 100bit	Range(e.g.H26~H39=3200.0)
*seconds	0	3200.0 seconds
*minutes	1	3200.0 minutes
*hours	2	3200.0 hours
*days	3	3200.0 days

H47	0 Segment Digital Voltage Giving	-100.0~100.0	%	0.0	Y
H48	1 Segment Digital Voltage Giving	-100.0~100.0	%	10.0	Y
H49	2 Segment Digital Voltage Giving	-100.0~100.0	%	20.0	Y
H50	3 Segment Digital Voltage Giving	-100.0~100.0	%	30.0	Y
H51	4 Segment Digital Voltage Giving	-100.0~100.0	%	40.0	Y
H52	5 Segment Digital Voltage Giving	-100.0~100.0	%	50.0	Y
H53	6 Segment Digital Voltage Giving	-100.0~100.0	%	60.0	Y
H54	7 Segment Digital Voltage Giving	-100.0~100.0	%	70.0	Y

Digital voltage set function can analogy give frequency, select by F02, F03;analogy give PID set or feedback, select by P02, P03;it can be shifted by the input terminal o36~o46.

H55	Multi-speed Status	1 bit	Current speed step	0~0xF	-	-	N
		10 bit	Current acceleration segment	0~0x7			
		100 bit	Current running time segment	0~0x7			
		1000 bit	Current digit voltage segment	0~0x7			

1 bit: Current speed segment

<p>0~16 segment, In hex, can be shifted t by o36~o46 10 bit: Current acceleration segment 0~7 segment, in hex, can be shifted by o36~o46 100 bit: Current running time segment 0~7 segment, in hex, can be shifted by o36~o46, valid when program running 1000 bit: Current digital voltage segment 0~7 segment, in hex, can by shifted by terminal o36~o46</p>

5-2-7. V/Fcurve Group:U00-U15(0x0400-0x040F)

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited
U00	V/ Setting Frequency1	0.00~U02	Hz	5.00	N
<p>User-defined the first frequency value of V / F curve, corresponding to V1</p>					
U01	V/F Setting Voltage 1	0~U03	%	10	N
<p>User-defined the first voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency inverter, corresponding to F1.</p>					
U02	V/F Setting Frequency 2	U00~U04	Hz	10.00	N
<p>User-defined the second frequency value of V / F curve, corresponding to V2.</p>					
U03	V/F Setting Voltage 2	U01~U05	%	20	N
<p>User-defined the second voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F2.</p>					
U04	V/F Setting Frequency 3	U02~U06	Hz	15.00	N
<p>User-defined the third frequency value of V / F curve, corresponding to V3.</p>					
U05	V/F Setting Voltage 3	U03~U07	%	30	N
<p>User-defined the third voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F3.</p>					
U06	V/F Setting Frequency 4	U04~U08	Hz	20.00	N
<p>User-defined the fourth frequency value of V / F curve, corresponding to V4.</p>					
U07	V/F Setting Voltage 4	U05~U09	%	40	N
<p>User-defined the fourth voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F4.</p>					
U08	V/F Setting Frequency 5	U06~U10	Hz	25.00	N
<p>User-defined the fifth frequency value of V / F curve, corresponding to V5.</p>					
U09	V/F Setting Voltage 5	U07~U11	%	50	N


Section V Parameter Function Table

User-defined the fifth voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F5.					
U10	V/F Setting Frequency 6	U08~U12	Hz	30.00	N
User-defined the sixth frequency value of V / F curve, corresponding to V6.					
U11	V/F Setting Voltage 6	U09~U13	%	60	N
User-defined the sixth voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F6.					
U12	V/F Setting Frequency 7	U10~U14	Hz	35.00	N
User-defined the seventh frequency value of V / F curve, corresponding to V7.					
U13	V/F Setting Voltage 7	U11~U15	%	70	N
User-defined the seventh voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F7.					
U14	V/F Setting Frequency 8	U12~most frequency	Hz	40.00	N
User-defined the eighth frequency value of V / F curve, corresponding to V8.					
U15	V/F Setting Voltage 8	U13~100	%	80	N
User-defined the eighth voltage percentage of V / F curve, on the base of rated output voltage 100% of frequency converter, corresponding to F8.					

5-2-8. PID parameter:P00-P12(0x0500-0x050C)

Code	Description / LCD	Setting Range		Unit	Factory Setting	Change Limited	
P00	PID Configuration	1 bit	Unidirectional regulation	0	-	0000	N
			Bidirectional regulation	1			
		10 bit	Negative effect	0			
			Positive effect	1			
		100 bit	PID fault, N action	0			
			Warning & Continuous running	1			
			Warning & Decelerating stop	2			
			Warning & Free stop	3			
		1000 bit	-	-			
			-	-			

When the inverter receives running command, it can control output frequency automatically in the PID regulation mode after comparing the setting signal and feedback signal from terminal. The process is explained as following:



(Δ = setting signal - feedback signal)

PI8000/PI8100 PID regulation

0: negative action, when $\Delta > 0$ is positive, frequency rises and when $\Delta < 0$ is negative, frequency falls.

<p>1: positive action, when $\Delta > 0$ is positive, frequency falls and when $\Delta < 0$ is negative, frequency rises.</p> <p>PID abnormality treatment:</p> <p>1: Warning & Continuous running: continue running g after abnormality feedback signal.</p> <p>2: Warning & Decelerating stop: decelerate and stop after abnormality feedback signal.</p> <p>3: Warning & Free stop: free stop after abnormality feedback signal .</p>						
P01	PID Output Limit	0~100	%	100	Y	
The parameter defines the limited range of the output when using PID control.						
P02	Feedback Signal Selection	Set frequency by keyboard or RS485	0	-	1	Y
		AI1 external analogy giving	1			
		AI2 external analogy giving	2			
		AI3 external analogy giving	3			
		Keyboard potentiometer giving	4			
		muti-step digital voltage giving	5			
	Digital pulse set	6				
PID feedback signal selection, can select keyboard/Rs485, potentiometer, digital voltage, digital pulse for feedback signal.						
P03	Setting Signal Selection	Set frequency by keyboard or RS485	0	-	2	Y
		AI1 external analogy giving	1			
		AI2 external analogy giving	2			
		AI3 external analogy giving	3			
		Keyboard potentiometer giving	4			
		Multi-step digital voltage giving	5			
	Digital pulse set	6				
PID giving signal selection, can select keyboard/Rs485, potentiometer, digital voltage, digital pulse for giving signal.						
P04	Keyboard Set Signal	0.0~100.0	%	50.0	Y	
When P03 is 0, the setting pressure set by the keyboard. 0.0~100.0% is 0 to the maximum pressure respectively.						
P05	PID integral time	0.002~10.000	s	0.250	Y	
<p>0.002~10.000s</p> <p>The PID integral time determines the integral regulation speed,the regulation acts on the difference between PID feedback and setting value by PID regulator.</p> <p>When the difference between PID feedback and setting value is 100% , integral regulator PID regulator ouput=(P01*F12*12.5%)Hz.(single direction PIDregulation,ignores proportion and differential effect).</p> <p>If the value is great,the control is stable but response is slow;if the value is little,the system response is rapid but perhaps surge occurs.</p>						

Section V Parameter Function Table

Section V

P06	PID Differential Time	0.000~10.000	s	0.000	Y
<p>0.000~1.000s</p> <p>The parameter determines the regulation intensity, the regulation acts on the change ratio of the difference between PID feedback and setting value by PID regulator.</p> <p>When the change ratio of the difference between PID feedback and setting value is 100% in the differential time, PID regulator regulates output to $(P01 * F12 * 12.5\%)$Hz (single direction PID regulation, ignores proportion and integral effect).</p> <p>If the value is great, the greater the intensity is, the system surge is to occur more easily</p>					
P07	PID Proportion Gain	0~1000.0	%	100.0	Y
<p>0~100.0%</p> <p>The PID Proportion Gain defines regulation intensity of PID regulator, the larger the P is, the more the intensity is.</p> <p>When proportion gain is 100%, and the difference between PID feedback and getting value is 100%, PID regulator's output is $(P01 * F12 * 12.5\%)$Hz (single direction PID regulation, ignores differential and integral effect).</p> <p>Proportion gain is the parameter decides PID regulator's response extent.</p> <p>If the gain is great, the response is rapid, but if too great, the surge will occur; the gain is little, the response will lag.</p>					
P08	PID Sampling Period	0.002~10.000	s	0.010	Y
<p>Set Sampling period of feedback signal.</p> <p>When set this parameter small, the system response speed to the giving and feedback deviation is slow, but control is stable.</p> <p>When set this parameter low, the system response speed to the giving and feedback deviation is slow, but easy to cause vibration</p>					
P09	Deviation Limit	0.0~20.0	%	5.0	Y
<p>Deviation limit effects system control accuracy and stability.</p> <p>When the deviation of feedback signal and giving signal < deviation limit, PID N regulation, keep output stable.</p> <p>When the deviation of feedback signal and giving signal > deviation limit, PID regulates according to deviation, update output</p>					
P10	PID Fault Detect Time	0.0~3200.0	s	0.0	N

Section V Parameter Function Table

P11	PID Fault Detected Value	0.0~100.0	%	10.0	N
<p>Set P10 to 0. 0 for N fault inspection. When PID feedback signal <P11 set PID fault inspection value, last P10set time, regard it as PID regulation fault.</p>					
P12	PID Display Range	0.00~100.00	-	1.00	Y
<p>A09 PID set value=PID set value(%)*P12 A10 PID feedback value=PID feedback value(%)*P12 If PID feedback 10V corresponding 4.0Mpa pressure, if need A09, A10 to display actual value, only need to set P12 = 0.04.</p>					

5-2-9. Expanding parameters:E00-E23(0x0600-0x0617)


Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited	
E00	Load Type	General	0	-	0	N
		Pump	1			
		Fan	2			
		Injection machine	3			
		Textile machine	4			
		Hoist machine	5			
		Kowtow Machine	6			
		belt conveyor	7			
		Variable frequency power	8			
		Multi-pumps constant pressure water supply	9			
		Reserved	10			
		Reserved	11			
		Torque control	12			
		Voltage regulation power	13			
		Current regulation power	14			
Extruding machine	15					
Details, see Appendix IV.						
E01	Starting Pressure Deviation	0.0~100.0	%	10.0	Y	
E02	Starting Delay Time	0.0~3200.0	s	5.0	Y	
<p>Feedback pressure <given pressure –starting pressure deviation. Continuously exceed E02 start delay time, the inverter will restart under in the standby mode. This parameter is used to prevent the inverter frequent start-stop.</p>						
E03	Stop Frequency	0~50.00	Hz	5.00	N	
E04	Stop Delay Time	0.0~3200.0	s	5.0	Y	
<p>If the set frequency is less than or equal to E03, stop frequency exceeding E04 stop delay time, the ac drive will change from running to the stop standby state. The bigger E03 parameter setting, the easier for stop, E03 parameter is set to 0, indicating the stop frequency and the start pressure control function is invalid.</p>						

Section V Parameter Function Table

Section V

E01, E02, E03, E04 mix are used to control system operation and water supply systems in the energy-saving water pressure regulator.
 For example:
 Given pressure = 50%
 Starting pressure deviation = 10%, starting pressure = given pressure - starting pressure deviation = 40%

Topping frequency = 5Hz



E05	High Pressure Arrival Value	0~100.0	%	90.0	Y
-----	-----------------------------	---------	---	------	---

When feedback pressure reach and exceed the high pressure reached value of this parameter, the I/O output terminal select 25, then it will output arrival signal.

E06	Low Pressure Arrival Value	0~100.0	%	10.0	Y
-----	----------------------------	---------	---	------	---

When feedback pressure less than the low pressure reached value of this parameter, the I / O output terminal select 26, then it will output arrival signal.

E07	Timing To Supply Water	1 bit	Timing water supply	invalid	0	-	0000	Y
				Valid	1			
		10 bit	Pressure giving	Set according to P03	0			
				Set according to H47~H54	1			
100 bit	Timing mode	Circle mode	0					
		Single circle	1					
1000 bit	Current timing step							

1 bit: Timing water supply
 0 Timing water supply function is invalid
 1 Timing water supply function is valid
 10 bit: pressure giving
 0 the pressure given during regular pressure water supply is set according PID given value selecting P03.
 1 the pressure given during regular pressure water supply is set according the current corresponding H47~H54 digital voltage given.
 100 bit: timing mode
 0 cycle mode

Start to time from start running, after it reached the setting time, the inverter will automatically move to the next period of time set, after the end of a loop, it will automatically re-start from the first paragraph 0, then cycle to run.

1 single cycle

Start to time from start running, after it reached the setting time, the inverter will automatically move

to the next period of time set, after the end of a loop, the inverter will stop and wait for the next running command.

1000 bit: the current regular time

When the water supply time set 0, it means cancel the water supply time setting of this period.

Current time	Water supply time	Pressure given
0	H18	H47
1	H19	H48
2	H20	H49
3	H21	H50
4	H22	H51
5	H23	H52
6	H24	H53
7	H25	H54

E08	Timing Shift Alternation Time	0.0~3200.0	Hours	0.0	N
<p>Timing Shift Alternation Time control the alternation ways and time of pump.</p> <p>When Timing Shift Alternation Time is set to 0.0 hour and cancel Timing Shift Alternation function.</p> <p>When the Timing Shift Alternation Time between 0.1~3,200 , after corresponding time of the stable running, in accordance with the principle of first stop for the one first started to control switch of pump.</p> <p>First stop for the first pump started: When reduce pumps control, stop the first pump which started first.</p> <p>According to the principle of start first – stop first control, in order to ensure that every pump can have the chance to run to prevent some pumps rusted as a result of no use for long , such as the need to ensure that each operation of the pump can receive equal time, set Timing Shift Alternation Time.</p> <p>Pump alternation order : E12 = 0x 0001</p> <p>Starting State : No. 1 pump frequency, No. 2 pump frequency conversion and No. 3 pump stops ;</p> <p>Rotation : No. 1 pump stops, No. 2 pump frequency, No. 3 pump frequency conversion ;</p> <p>After the second rotation : No.1pump frequency conversion and No.2pump stops, No.3pump power frequency.</p>					
E09	Electromagnetic Switch Action Delay	0.000~10.000	s	0.500	Y
<p>Electromagnetic switch action delay time when set up a pump (drive motor) to switch from variable frequency to industry frequency, or from industry frequency to variable frequency. This is to avoid inverter output frequency meet with the AC power supply and occur short circuit caused because electromagnetic switch action too slow.</p>					
E10	Pumps Shift Judging Time	0~9999	s	5	Y
<p>Set when output frequency converter arrives to upper frequency, until the judgment time of increasing pumps (driving motor); or when output frequency converter arrives to lower frequency, until the judgment time reducing pumps (driving motor). Set the time long or short according to the speed of pressure change, without oscillating range, the shorter the better.</p>					

Section V Parameter Function Table

Drives add or subtract pump control with E12 Water Supply Configuration
 Add pump order No. 1 pump → No. 2 pump → No. 3 pump → No. 4 pump.
 Reduce pump order No. 4 pump → No. 1 pump → No. 2 pump → No. 3 pump.
 If the current : No. 1 pump frequency, No. 2 pump frequency, No. 3 pump convert frequency
 after reduce pump: No. 1 pump frequency, No. 2 pump convert frequency,
 after add pump: 1 pump frequency, No. 2 pump frequency, No. 4 pump convert frequency
 after reduce pump :No. 1 pump frequency, No. 2 pump convert frequency,
 after reduce pump: No. 1 pump frequency,
 after add pump: No. 1 pump frequency, No. 3 pump convert frequency
 after add pump: No. 3 pump frequency No. 4 pump convert frequency
 after add pump: No. 1 pump frequency, No. 3 pump frequency No. 4 pump. frequency ,No. 2 pump
 converter frequency,

E11	Constant Pressure Water Supply Configuration	1 bit	Stop mode	All pumps slow down stop	0	-	0000	N
				Variable frequency pump stop	1			
				Free stop	2			
				Water supply Pump stop	3			
		10 bit	Pumps status when fault occurs	Keep current situation	0			
				All-pumps stop	1			
		100 bit	Alternation shift mode	Variable frequency to working frequency	0			
				Variable frequency to stop	1			
		1000 bit	Pump status keep	Keep status	0			
				Stop reset	1			

1 bit : Stop mode
 0 All slow down, all pumps in turn slowing down.
 1 variable frequency pump stop:variable frequency pump stop running,variable frequency pump and soft start pump under frequency keep running.
 Stop power frequency pump,you need to use o36~o46parking command or keyboard input terminal free multi - function keys MF1, MF2 set to 2 : Free Parking function.
 2 Free stop, all pumps free stop
 After free stop,E11 1000bit pump reset according to the order start and stop,but reorder according to E12 multi - pumps configuration.
 3 Water supply pump stops,only those constant pressure water supplying pumps stop,soft start pump keep running under pump frequency.
 Stop soft - starting pump, you need to use stop command of the soft star pump for o36 ~ o46 input

terminal or keyboard multi - function keys MF1, MF2 set to 2 : Free stop function.

10 bit: Treatment under fault pump states

0 maintain the status quo, when inverter failure, stop the current variable frequency pump operation and other power - frequency operation of variable frequency pump and soft start pump maintain the status quo

Fault occurs, if the following breakdown, select fault treatment according to failure action.

12	E.PId	regulating fault
13	E.OHt	Motor over heated fault
14	E.OL2	Motor over loading fault
15	E.PG	PG fault
16	E.PHo	Inverter output Phase lost
17	E.COA	RS485 communication A fault
18	E.COb	RS485 communication B fault

The feature only applies to the fault under the mode allowing fault runs. The fault is not allowed to run, all stop.

1 All pump stop, when inverter failure, all pumps free stop.

100 Bit: Soft start switching mode

0 Convert frequency to power frequency, frequency control of the pump current increases the speed to the frequency, the rotation of the pump start and stop switch control or soft start pump

1 Frequency conversion to stop, stopped the current frequency conversion control of pump and pump rotation switch or soft start pump start - stop control.

1000 Bit : pumping States maintain

0 Maintaining state, After multi pumps constant pressure water supply stop, keep the current multipumps at the first start- first stop order.

1 Stopping reset , After multi pumps constant pressure water supply stop , E12 multipumps configuration reorder multi - pump at the stop order.

E12	Multi-pumps Configuration	1 bit	Pump 1 invalid	0	-	0001	N
			Pump 1 variable frequency to control pump	1			
			Pump 1 soft starts to control pump	2			
		10 bit	Pump 2 invalid	0			
			Pump 2 variable frequency to control pump	1			
			Pump 2 soft starts to control pump	2			
		100 bit	Pump 3 invalid	0			
			Pump 3 variable frequency to control pump	1			
			Pump 3 soft starts to control pump	2			
		1000 bit	Pump 4 invalid	0			

Section V Parameter Function Table

			Pump 4 variable frequency to control pump	1			
			Pump 4 soft starts to control pump	2			
Under Multi-pump control mode, set the control mode of each pump.							
E13	Multi-pumps Status	1 bit	Pump 1 stop	0	-	0000	N
			Pump 1 run in variable frequency	1			
			Pump 1 run in working frequency	2			
		10 bit	Pump 2 stop	0			
			Pump 2 run in variable frequency	1			
			Pump 2 run in working frequency	2			
		100 bit	Pump 3 stop	0			
			Pump 3 run in variable frequency	1			
			Pump 3 run in working frequency	2			
		1000 bit	Pump 4 stop	0			
			Pump 4 run in variable frequency	1			
			Pump 4 run in working frequency	2			
Under Multi-pump control mode, displays the status of each pump.							
E14	Soft Starting Pump Control	1 bit	Pump 1 soft-no command	0	-	0000	Y
			Pump 1 soft-stop	1			
			Pump 1 soft-start	2			
		10 bit	Pump 1 soft-no command	0			
			Pump 2 soft-stop	1			
			Pump 2 soft-start	2			
		100 bit	Pump 1 soft-no command	0			
			Pump 3 soft-stop	1			
			Pump 3 soft-start	2			
		1000 bit	Pump 1 soft-no command	0			
			Pump 4 soft-stop	1			
			Pump 4 soft-start	2			
Under Multi-pump control mode, set the control mode of each pump.							
E15	User Parameter 0	0~9999			-	0	Y

E16	User Parameter 1	0~9999	-	0	Y
E17	User Parameter 2	0~9999	-	0	Y
E18	User Parameter 3	0~9999	-	0	Y
E19	User Parameter 4	0~9999	-	0	Y
E20	User parameter 5	0~9999	-	0	Y
E21	User Parameter 6	0~9999	-	0	Y
E22	User Parameter 7	0~9999	-	0	Y
E23	User Parameter 8	0~9999	-	0	Y

※Please check appendix 4 for the detailed expanding parameter instruction.

5-2-10.Speed-loop parameter [SPD]:C00-C31(0x0700-0x071F)

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited
C00	Filter Time Of Speed-loop	2~200	ms	10	Y
It defines the filter time of the speed-loop. The range is 0.01~100s.If the value is too great, the control is stable but response is slow; if the value is too little, the system response is rapid but perhaps is unstable. So it is necessary to consider the stability and the response speed at the same time when setting the value.					
C01	Speed-loop Low Speed Ti	0.01~100.00	s	0.25	Y
It defines the integral time of the speed-loop low speed. The range is 0.01~100.00s. If the integral time is too great, response is slow and the control of external disturbing signal become bad; if the time is too little, response is rapid, but perhaps brings the surge.					
C02	Speed-loop Low Speed Td	0.000~1.000	s	0.000	Y
It defines the differential time of the speed-loop low speed segment and the range is 0.000~1.000s. If the time is great enough, the surge which is caused by P action when difference occurring can attenuate quickly. But too great, the surge will happen contrary. When the time is little, the attenuation function is little too.					
C03	Speed-loop Low Speed P	0~150	%	100	Y
It defines the proportion gain of speed loop low speed segment.And the range is 0~1000%.If the gain is great, the response is rapid, but too great, surge perhaps occurs; if the gain is too little, response is slower.					
C04	Speed-loop Low Speed Shift Frequency	0.0~C08	Hz	7.00	Y
It defines low-speed loop switching frequency, the parameter and switching frequency at high-speed optimize Speed-loop PID parameter.					
C05	Speed Loop High Speed Ti	0.01~100.00	s	0.50	Y
It defines integration time of High-speed section of the speed loop.Range is0.01~100.00s.integration time too large and unresponsive, external interference control variation becomes weak ; integration time is small the reaction speed, oscillation occurs when it is too small.					
C06	Speed Loop High Speed Td	0.000~1.000	s	0.000	Y
It defines the differential time of the speed-loop high speed segment and the range is 0.000~1.000s. If the time is great enough, the surge which is caused by P action when difference occurring can attenuate quickly. But too great, the surge will happen contrary. When the time is little, the attenuation function is little too.					

Section V Parameter Function Table



C07	Speed Loop High Speed P	0~150	%	75	Y			
It defines the proportion gain of speed loop high-speed section, range from 0~1000%. Gain is large, response speed, but too large gain will occur vibration; if the gain is small, the reaction lag.								
C08	Speed Loop And High-speed Switching Frequency	C04~max frequency	Hz	30.00	Y			
It defines Integral time of speed loop high speed , the parameter and switching frequency at low - speed optimize the speed-loop PID parameter.								
C09	Low-speed Slip Gain	0~200	%	100	Y			
Low-speed segment slip compensation gain								
C10	Low Speed Slip Switching Frequency	0~C12	Hz	5.00	Y			
Low speed segment slip compensation switching frequency								
C11	High Speed Slip Gain	0~200	%	100	Y			
High speed segment slip compensation gain								
C12	High Speed Slip Switching Frequency	C10~ max frequency	Hz	30.00	Y			
High speed segment slip compensation switching frequency								
C13	Upper Froward Torque	0.0~300.0	%	250.0	Y			
The parameter is a ratio, setting value is 100%. Responding to motor rated output torque. Set forward torque mode through C15. In speed control mode, it's upper forward torque. In torque control mode, it's forward torque setting value.								
C14	Upper Reverse Torque	0.0~300.0	%	250.0	Y			
The parameter is a ratio, setting value is 100%. Set reverse torque mode through C16. In speed control mode, it's upper reverse torque. In torque control mode, it's reverse torque setting value.								
C15	Forward Torque setting mode	1 bit	Setting mode	Set by keyboard or RS485	0	-	0000	Y
				AI1 external analogy giving	1			
				AI2 external analogy giving	2			
				AI3 external analogy giving	3			
				Keypad potentiometer giving	4			
				Multi-step digital voltage giving	5			
				Digital pulse set	6			
		10 bit	direction	Direction uncontrolled	0			

Section V

C16	Reverse Torque setting mode	1 bit	Setting mode	Direction controlled	1	-	0000	Y
				Set by keyboard or RS485	0			
				AI1 external analogy	1			
				AI2 external analogy giving	2			
				AI3 external analogy giving	3			
				Keypad potentiometer giving	4			
				Multi-step digital voltage giving	5			
		Digital pulse set	6					
		10 bit	direction	Direction uncontrolled	0			
				Direction controlled	1			
C17	Torque Set Gain	0.0~300.0		%	200.0	Y		
C15 1 bit: Setting mode								
C16 1 bit: Setting mode								
0		Set by keyboard or RS485		Responding to C13/C14				
1		AI1 external analog setting		As per AI1 external analog setting				
2		AI2 external analog setting		As per AI2 external analog setting				
3		AI3 external analog setting		As per AI3 external analog setting				
4		Keyboard potentiometer setting		As per keyboard potentiometer setting				
5		Multi segment digital voltage setting		As per multi segment digital voltage setting				
6		Digital Pulse Setting		As per digital pulse setting				
While the unit digital of C15,C16 is 1—6, the torque up-limit of C13,C14 is for checking.								
C15 10 bit: Direction Control								
C16 10 bit: Direction Control								
0: No control Direction								
Direction is controlled by terminal or keyboard								
1:Control Direction								
Setting value of forward torque > setting value of reverse torque, forward direction.								
Setting value of forward torque < setting value of reverse torque, reverse direction.								
C13 upper forward torque =setting value percentage * C17 torque given gain.								
C14 upper reverse torque =setting value percentage * C17 torque given gain.								
Such as:								
C15 forward torque setting way=4 keyboard potentiometer setting.								
C16 reverse torque setting way=4 keyboard potentiometer setting.								
Forward/reverse both can control direction, C15=0x14, C16=0x14.								

Section V Parameter Function Table

Potentiometer corresponding setting value A48=-100%, A49=100% Keyboard potentiometer set A47=100%, C17=200.0% C13 forward torque up-limit=100%*200.0%=200.0%, control direction forward 200% torque Keyboard potentiometer set A47=100%, C17=200.0% C14 reverse torque up-limit=100%*200.0%=200.0%, control direction reverse 200% torque																										
C18	Speed /Torque Control Shift	Speed control	0	-	0	Y																				
		Torque control	1																							
F00 control method is to select senseless vector control or sensor feedback close loop vector control can change speed or torque control through input terminal. After setting IP terminal change, keyboard set invalid, only for query.																										
C19	Upper speed Setting mode	1 bit	Separate setting mode	keyboard or RS485 setting	0	-	0000	Y																		
				A11 external analog setting	1																					
				A12 external analog setting	2																					
				A13 external analog setting	3																					
				Keyboard potentiometer setting	4																					
				Multi-segment digital voltage setting	5																					
		Digital Pulse Setting	6																							
		10 bit	Selection	C19 Unit bit setting	0																					
				S00 Setting Frequency	1																					
C20	Reverse Speed Limit	0.00~ Maximum frequency		-	50.00	Y																				
While torque control, setting upper speed. C19 1 bit: Separate setting mode																										
<table border="1"> <tr> <td>0</td> <td>keyboard or RS485 setting</td> <td>As per C20 setting</td> </tr> <tr> <td>1</td> <td>A11 external analog setting</td> <td>As per A11 external analog setting</td> </tr> <tr> <td>2</td> <td>A12 external analog setting</td> <td>As per A12 external analog setting</td> </tr> <tr> <td>3</td> <td>A13 external analog setting</td> <td>As per A13 external analog setting</td> </tr> <tr> <td>4</td> <td>Keyboard potentiometer setting</td> <td>As per keyboard potentiometer setting</td> </tr> <tr> <td>5</td> <td>Multi-step digital voltage setting</td> <td>As per Multi-step digital voltage setting</td> </tr> <tr> <td>6</td> <td>Digital Pulse Setting</td> <td>As per Digital Pulse Setting</td> </tr> </table>						0	keyboard or RS485 setting	As per C20 setting	1	A11 external analog setting	As per A11 external analog setting	2	A12 external analog setting	As per A12 external analog setting	3	A13 external analog setting	As per A13 external analog setting	4	Keyboard potentiometer setting	As per keyboard potentiometer setting	5	Multi-step digital voltage setting	As per Multi-step digital voltage setting	6	Digital Pulse Setting	As per Digital Pulse Setting
0	keyboard or RS485 setting	As per C20 setting																								
1	A11 external analog setting	As per A11 external analog setting																								
2	A12 external analog setting	As per A12 external analog setting																								
3	A13 external analog setting	As per A13 external analog setting																								
4	Keyboard potentiometer setting	As per keyboard potentiometer setting																								
5	Multi-step digital voltage setting	As per Multi-step digital voltage setting																								
6	Digital Pulse Setting	As per Digital Pulse Setting																								
While the unit digital of C19 is 1—6, the speed up-limit of C20 is for checking. C19 10 bit: Select Speed Up-limit Setting Ways 0: separate setting, as per the selection of C19 Units digital.																										

<p>1:setting frequency is according to S00,and affected by the following parameters. F02 frequency main setting ways/F03 frequency secondary setting ways/F04 frequency setting main and secondary.</p>						
C21	Torque Acceleration Time	0.0~200.0	s	1.0	Y	
C22	Torque Deceleration Time	0.0~200.0	s	1.0	Y	
<p>C21, C22 torque acceleration time, turning moment deceleration torque control mode and effective. Torque acceleration time, torque accelerated from 0 to 300 hours. Torque speed, torque, from 300 down to 0.</p>						
C23	Low Speed Excitation Excitation	0~100	%	30	Y	
<p>Under low speed, compensate excitation quantity, increase torque feature, in case of meeting the requirement, try to make it lower, could reduce the motor heating up caused by magnetic path full.</p>						
C24	Current Loop Ti	0~9999	ms	500	Y	
<p>Define the current loop integral time. When integral time is too long, response is inactive; the ability to control external jamming becomes weak. When integral time is short, response is fast, if too short, vibration will occur.</p>						
C25	Current Loop P	0~1000	%	100	Y	
<p>Define current loop proportion gain, When select big gain, response fast, but too big will occur vibration. when select low gain, response lag.</p>						
C26	PG Electronic Gear A	1~5000	-	1	Y	
C27	PG Electronic Gear B	1~5000	-	1	Y	
<p>When encoder and motor is in different shaft, can calculate current motor speed according to encoder and gear ratio. Electronic gear A for denominator, B for molecule.</p>						
C28	PG Pulse	300~9999	-	2500	N	
<p>PG pulse quantity used, set value is the pulse quantity when motor rotates for a circle.</p>						
C29	Action When PG Break	N PG break protection	0	-	3	Y
		Warning and keeping running	1			
		Warning and deceleration stop.	2			
		Warning and free stop.	3			
<p>Set the brake method when detect PG break. 0: N PG break protection 1: Warning and keeping running. 2: Warning and deceleration stop. 3: Warning and free stop.</p>						
C30	PG Rotating Direction	When motor forward, phase A leads	0	-	0	Y
		When motor forward, phase A lags	1			
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>phase A is forward</p> </div> <div style="text-align: center;">  <p>phase B is forward</p> </div> </div> <p>Encoder rotating direction, refer to the motor forward direction</p>						

Section V Parameter Function Table

0 : When motor forward, phase A leads, set C27= 0					
1 : When motor forward, phase B leads, set C27= 1					
Note: above parameters are valid when with encoder(PG), need to layout PG card. If needed, please contact our company.					
C31	PG Dropped Inspection Time	0.0~10.0	s	1.0	N
PG feedback signal is 0, exceed C31 set time, system reports PG dropped fault. Set speed to 0, or sert C31 to 0, don't check PG dropped fault.					

5-2-11. Motor parameter [MOT]:b00-b22(0x0800-0x0816)

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited
b00	Motor 1 Rated Frequency	0.00~Maximum frequency	Hz	50.00	Y
b01	Motor 1 Rated Current	y09*(50%~100%)	A	★	Y
b02	Motor 1 Rated Voltage	100~1140	V	★	Y
b03	Motor 1 Pole-pairs	1~8	-	2	Y
b04	Motor 1 Rated Speed	500~5000	rpm	1480	Y

b00~b04 are the motor's nameplate parameters which touch the precision. Set the parameters according to the motor's nameplate.

b00 ~ b04 motor nameplate in parameters, it is necessary to re-calculate motor parameters by using b11.

Excellent vector control performance requires exact motor parameters. Exact parameters are base on the correct setting of motor's rated parameters.

To assure the control performance, please match the right motor as per the inverter's standard, motor rated currents limited between 30%~120% of inverter rated current.

The rated current can be set, but can't be more than the rated current of the inverter. The parameter confirms the OL protection capability of the motor and energy-saving running.

To prevent self-cooled motor form overheat when running in a low speed, and the motor capacity change when motor character change little, the user can correct the parameter to protect the motor.

The number of motor pole pairs, such as the four pole motor, the number of pole pairs is set to 2

b05	Motor 1 N Load Current	0.0~b01	A	★	Y
b06	Motor 1 Stator Resistance	0.000~30.000	ohm	★	Y
b07	Motor 1 Rotor Resistance	0.000~30.000	ohm	★	Y
b08	Motor 1 Stator Inductance	0.0~3200.0	mH	★	Y
b09	Motor 1 Mutual Inductance	0.0~3200.0	mH	★	Y

b05~b09 can by input by motor actual parameters value, also can define motor parameter by b11 parameter measure function. and save automatically. If know the correct motor parameter, can input by hand

When b11 is 1, 2, 3, the system calculates and measures automatically.

b05~b09 is the motor's basic electric parameters, these parameters is essential to achieve vector control calculation.

b10	Motor Selection	Motor 1	0	-	0	N
		Motor 2	1			

The system can select any group motor parameters.

Motor parameter measurements modify and save to corresponding motor parameter area automatically.

b11	Motor Parameter Measurement	No measurement	0	-	0	N
		calculate by label data	1			
		inverter static measurement	2			
		inverter rotation measurement	3			
<p>Set whether the measurement of electrical parameters in order to b10 motors choose motor 1 as an example.</p> <p>0 : N measurement</p> <p>1 : Calculate by label data</p> <p>According to the motor nameplate parameters b00 ~ b04 , automatic calculation b05 ~ b09 and other electrical parameters,the advantage does not require power-on self - tuning,suitable for general - purpose Y series of four pole motor, the other type motor can be adjusted based on this parameter.</p> <p>2 : Inverter static measurement</p> <p>3 : If the motor parameters can not be measured without load,you can choose static frequency converter measurement. Make sure that motor in a static status ,after static measurement, it can be manually adjusted some parameters, optimal control.</p> <p>4 : The b11 is set to 2, the inverter automatically start parameter determination.</p> <p>Keyboard figures area show "-RUN": waiting to run the command, start the measurement.</p> <p>Keyboard figures area show "CAL1", inverter without output.</p> <p>Keyboard figures area show "CAL2", inverter with output, static state.</p> <p>Keyboard figures area show "-END": measuring ends.</p> <p>Keyboard figures area show "E. CAL": the measurement process errors.</p> <p>Process can be measured through the STOP key to stop.</p> <p>3 : Inverter rotation measurement</p> <p>Motor can be measured without load, can choose the rotation measurement. Measurements started, make sure the motor is static.</p> <p>Static measurement converter, the output DC voltage, pay attention to safety.</p> <p>The b11 is set to 3, the inverter automatically start parameter determination.</p> <p>Keyboard figures show that the regional show "-RUN": waiting to run the command, start the measurement.</p> <p>Keyboard figures area show "CAL1", "CAL3": N output inverter.</p> <p>Keyboard figures area show "CAL2", inverter with output, under static state.</p> <p>Keyboard figures area show "CAL4", inverter with output, the motor forward in high-speed.</p> <p>Keyboard figures area show "-END": measuring the end.</p> <p>Keyboard figures area show "E. CAL": the measurement process errors.</p> <p>Process can be measured through the STOP key to stop.</p> <p>Set this parameter,the motor parameters will be determined dynamically.Be sure the motor is without load (N-load operation).</p> <p>Before setting,be sure to run well prepared,the motor will run in high speed during the measurement Measurement is completed, b11 return to 0. The measured parameters will select parameters on the base of b10 motor parameters which is automatically saved to the b05 ~ b09 or b18 ~ b22.</p> <p>Note: Before auto-measure the motor parameter, must input motor rated parameter b00~b04or b13~17 correctly</p> <p>Please regulate accelerating and deceleration time or torque increasing parameter, if there is over - current or over voltage faults while auto- measurement.</p> <p>When automatic regulation, motor should be in stop status.</p>						
b12	Vector Control initial Inspection R1	Not inspection R1	0	-	0	N
		Inspection R1	1			
b13	Motor 2 Rated Frequency	0.00~Maxmum frequency		Hz	50.00	Y

Section V Parameter Function Table

b14	Motor 2 Rated Current	y09*(50%~100%)	A	★	Y
b15	Motor 2 Rated Voltage	100~1140	V	★	Y
b16	Motor 2 Pole Pairs	1~8	-	2	Y
b17	Motor 2 Rated Speed	500~5000	rpm	1480	Y
b18	Motor 2 N Load Current	0.0~b14	A	★	Y
b19	Motor 2 Stator Resistance	0.000~30.000	ohm	★	Y
b20	Motor 2 Rotator Resistance	0.000~30.000	ohm	★	Y
b21	Motor 2 Stator Inductance	0.0~3200.0	mH	★	Y
b22	Motor 2 Mutual Inductance	0.0~3200.0	mH	★	Y
The 2nd group motor parameters can be set by system. The definition is same with group 1.					

5-2-12. System parameter [SYS]:y00-y17(0x0900-0x0911)

Code	Description / LCD	Setting Range	Unit	Factory Setting	Change Limited	
y00	Reset System Parameter	No action	0	-	0	N
		Reset system parameter with keyboard storage1	1			
		Reset system parameter with keyboard storage 2	2			
		Reset system parameter with keyboard storage 3	3			
		Reset system parameter with keyboard storage 4	4			
		Reset system parameter with factory set value	5			
0 : No action 1 : Reset system parameter with keyboard storage 1 2 : Reset system parameter with keyboard storage 2 3 : Reset system parameter with keyboard storage 3 4 : Reset system parameter with keyboard storage 4 5 : Reset system parameter with factory set value When this parameter set valid, all the function parameter reset to factory setting. The parameters without factory setting will save the previous setting value.						
y01	Parameter Upload To Keyboard	No action	0	-	0	N
		Reset system parameter with keyboard memory area1	1			
		Reset system parameter with keyboard memory area2	2			
		Reset system parameter with keyboard memory area3	3			
		Reset system parameter with keyboard memory area4	4			
		Clear up keyboard memory	5			

		area 1, 2, 3, 4			
0: No action; 1: Reset system parameter with keyboard memory area1; 2: Reset system parameter with keyboard memory area2; 3: Reset system parameter with keyboard memory area3; 4: Reset system parameter with keyboard memory area4; 5: Clear up keyboard memory area 1, 2, 3, 4					
y02	Lastest Fault record	Lastest fault record number	mH	0	Y
y03	Fault Record 1	Press [PRG]and [▲/▼] key the frequency, crrent and running status of fault time can be known.	-	0	Y
y04	Fault Record 2				
y05	Fault Record 3				
y06	Fault Record 4				
y07	Fault Record 5				
These parameters register fault which happen in the last several times, and can inquire about the value of monitor object at the time of fault by '_PRG' and 'plus or minus' key. The monitor object of fault state: 0: Fault type The fault code is expressed as following:					
Serial number	LED display	Fault			
0	E.OCP	System is disturbed or impacted by instant over current			
1	Reserved				
2	E.OC3	Over current or over voltage signal from drive circuit.			
3	Reversed				
4	E.OU	Over voltage			
5	E.LU	Under voltage			
6	E.OL	Over load			
7	E.UL	Under load warm			
8	E.PHI	Power input Phase loss			
9	E.EEP	EEPROM error			
10	E.ntC	Over heat			
11	E.dAt	Time limit fault			
12	E.Set	External fault			
13	Reserved				
14	Reserved				
15	Reserved				
16	E.PID	PID regulate fault			
17	E. OHt	Motor over heat fault			
18	E.OL2	Motor over load fault			
19	E.PG	PG fault			
20	E.Pho	Inverter output phase-lost			

Section V Parameter Function Table

21	E.COA	RS485 communication terminal A failure
22	E.Cob	RS485 communication terminal B failure
23	E.CAL	Parameter identification problems.

- 1: set frequency at the time of fault
The output frequency of the inverter at the time of fault
- 2: output frequency at the time of fault
The output frequency of the inverter at the time of fault
- 3: output current at the time of fault
The actual output current at the time of fault
- 4: output DC voltage at the time of fault
The actual output voltage at the time of fault
- 5: Running state at the time of fault
The running state at the time of fault

LEDdisplay is below:

the first LED tthhte		The second LED		The third LED	the fourth LED	
F	forward command	F	forward status	separator	A	accelerating
R	Reverse command	R	Reverse status		D	decelerating
S	Stop command	S	Stop status		E	running in a even speed
					S	Stop status

- 6: running time at the time of fault
The running time at the time of fault
- 7: Inverter IGBT temperature at the time of fault
Inverter IGBT temperature

y08	Fault Record Reset	No action	0	-	0	Y
		Reset	1			

- 0 : No action, the fault records retains
- 1 : the fault records resets

y09	Rated Output Current	0.1~1000.0	A	★	N
-----	----------------------	------------	---	---	---

Inverter rated output current.

y10	Rated Input Voltage	100~1140	V	★	N
-----	---------------------	----------	---	---	---

The rated input voltage of the inverter. It would be set as per inverter input voltage level before leaving factory.

y11	Product Series	80	0	3	-	★	N
		Family code	Product serial	Input oltage grade 1			

Product series (set according to family code/product serial/voltage grade)

<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>80 0 3</p> <p>family code</p> <p>80: 8000 serial</p> <p>81: 8100 serial</p> </div> <div style="text-align: center;"> <p>series number</p> <p>0: Flow load (F)</p> <p>1: General load (G)</p> <p>2: Middle load (M)</p> <p>3: Heavy load (H)</p> <p>6: TEXDRIVE (S)</p> <p>7: WINDLASS (T)</p> <p>8: JETDRIVE (Z)</p> </div> <div style="text-align: center;"> <p>input voltage level</p> <p>1: single phase 220V</p> <p>2: three phase 220V</p> <p>3: three phase 380V</p> <p>4: three phase 460V</p> <p>5: three phase 575V</p> <p>6: three phase 660V</p> <p>9: three phase 1140V</p> </div> </div>																									
y12	Software Version	-	-	-	N																				
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>A 100</p> <p>A: official version</p> <p>B: specialized version</p> <p>C: beta version</p> </div> <div style="text-align: center;"> <p>version number</p> </div> </div>																									
y13	Product Date-- Year	YYYY	-	-	N																				
y14	Product Date -Month/Day	MMDD	-	-	N																				
y15	User Decode Input	0~9999	Set range	-	-																				
		Record password wrongly input times	Display info			Y																			
<p>In the state of locked parameter, LED displays the times of error input. There are three input limit, if input is wrong in continuous three times, the systems will prohibit input of the password. It can prevent testing password in an illegal way, and need restart the machine to input again.</p> <p>Once the input is right in any time during three times input limit, the parameter is unlocked.</p>																									
y16	User password key-in	0~9999	Set range	-	-																				
		No password or decode input is correct	code			Display info																			
		Parameter lock-in	code																						
<p>The parameter sets the password, and the range is 0 ~ 9999. After setting the password, parameter locks and keyboard displays "eode"; if the password is unlocked or password input is right, the keyboard will display "deco".</p> <p>Set password to 0, reset user password set, after re-electrify status is decode.</p>																									
y17	Parameter Group Protection	Corresponding parameter group protection after set password Set to 0: change is not allowed Set to 1: change is allowed	-	0000	Y																				
<div style="text-align: center;"> <table border="1" style="margin: auto;"> <tr> <td>2⁹</td><td>2⁸</td><td>2⁷</td><td>2⁶</td><td>2⁵</td><td>2⁴</td><td>2³</td><td>2²</td><td>2¹</td><td>2⁰</td> </tr> <tr> <td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> </table> <div style="margin-top: 10px;"> <p>F group</p> <p>A group</p> <p>o group</p> <p>H group</p> <p>U group</p> <p>P group</p> <p>E group</p> <p>C group</p> <p>b group</p> <p>y group</p> </div> </div>						2 ⁹	2 ⁸	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰	9	8	7	6	5	4	3	2	1	0
2 ⁹	2 ⁸	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰																
9	8	7	6	5	4	3	2	1	0																

Section VI. Fault Diagnosis & Solutions

6-1. Problems and solutions

Problems	Possible causes	Solutions
Keyboard can not control	Running control mode setting is wrong	Check F05
	Frequency setting is wrong	Check F03、F04
Potentiometer can't regulate speed	Control mode setting is wrong	Check F05
	Frequency setting is wrong	Check F03、F04
The motor Does not rotate	LED monitor display fault	Press RESET or terminal for fault reset, learn and fix the fault according to the fault info
	No voltage in terminals DC+1 and DC+2	Check the voltage at R, S or T and charging circuit.
	U, V or W terminals produce No output or abnormal output.	Check the control mode and frequency parameter. Check the terminal condition if it is operated by an external terminal.
	Re-start after powering down or free run	Remember the set operating state.
	Too much load on the motor	Check the load condition, and confirm the model selection is right
Over recurrent E.OC	Fault display E.OCP	System is disturbed or instant over current
	Fault display E.OC3	Motor over current, protect action when motor actual current is 3 times over than the motor rated current
	Over current during acceleration	Reset or adjust F09, F20, F21.
	Over current during deceleration	Reset or adjust F10, F22, F23.
	During starting, the low-frequency jitter over-current	Modify F06 setting
	Over current during operation	Check the load change and eliminate it.
	Over current during starting or operation sometime	Check if there is slight short circuit or grounding.
	Disturbance	Check the earthing wire, screened cable grounding and terminals.
Over load E.OL	Too much load	Lower the load.or enlarge b04, b14 in the allowable load range or enlarge A24 to raise the thermal protection level.
	Inappropriate parameter is set	Modify <u>b04</u> 、 <u>b14</u> in case of the motor over -load allowed
Over voltage E.OU	Power voltage exceeds the limit	Check voltage is right or not. Frequency inverter rated voltage setting is Y or N.
	Too fast deceleration	Modify F10.

Section VI Fault Diagnosis & Solutions

	The load has too much inertia	Reduce the load inertia, or raise the capacity of frequency converter, or add a braking resistor.
Low voltage E.LU	Too low power voltage	Checking voltage is normal or not. Frequency inverter rated voltage setting is Y or N.
	Power off transiently	Add options of capacitor boxes.
	The line has too small capacity or great rush current exists on the lines.	Make renovation on power supply system.
Over heat E.OHt	Too high ambient temperature	Improve ambient conditions
	Cooling fans do not work.	Check A27, reduce fan starting temperaturer(when there is fan control)
	The carrier frequency is too high	Check the setting value of function F16

Note:

- ※ Switch off the power supply, and do not touch the PCBs and any parts inside in five minutes after the charging indicator light (! CHARGE) goes off. Ensure the capacitance has been discharged completely by measuring with the instrument before work inside. Otherwise, there is a danger of electric shock.
- ※ Do not touch the PCB or IGBT and other internal parts unless actions have been taken to prevent the static electricity. If not, the components may be damaged.

Section VII Standard Specifications

7-1. Specification

7-1-1. PI8000 Specification

Inverter type	Light Load F		Standard Load G		Medium Load M		Heavy Load H		Structure item
	P _F kW	I _F A	P _G kW	I _G A	P _M kW	I _M A	P _H kW	I _H A	
3 phase voltage 380V 50/60Hz									
PI8000●●●□3	15	32	11	25	7.5	16			8N2
PI8000●●●□3	18.5	38	15	32	11	25	7.5	16	8N2
PI8000●●●□3	22	45	18.5	38	15	32	11	25	8N3
PI8000●●●□3	30	60	22	45	18.5	38	15	32	8N3
PI8000●●●□3	37	75	30	60	22	45	18.5	38	8N4
PI8000●●●□3	45	90	37	75	30	60	22	45	8N4
PI8000●●●□3	55	110	45	90	37	75	30	60	8N5
PI8000●●●□3	75	150	55	110	45	90	37	75	8N5
PI8000●●●□3	93	170	75	150	55	110	45	90	8N6
PI8000●●●□3	110	210	93	170	75	150	55	110	8N6
PI8000●●●□3	132	250	110	210	93	170	75	150	8N7
PI8000●●●□3	160	300	132	250	110	210	93	170	8N7
PI8000●●●□3	187	340	160	300	132	250	110	210	8N8
PI8000●●●□3	200	380	187	340	160	300	132	250	8N8
PI8000●●●□3	220	415	200	380	187	340	160	300	8N9
PI8000●●●□3	250	470	220	415	200	380	187	340	8N9
PI8000●●●□3	280	520	250	470	220	415	200	380	8N9
PI8000●●●□3	200	380	200	380	187	340	160	300	8NA
PI8000●●●□3	220	415	220	415	200	380	187	340	8NA
PI8000●●●□3	250	470	250	470	220	415	220	380	8NA
PI8000●●●□3	315	600	280	520	250	470	220	415	8NB
PI8000●●●□3	355	640	315	600	280	520	250	470	8NB
PI8000●●●□3	400	690	355	640	315	600			8NB
PI8000●●●□3	450	740	400	690					8NB

7-1-2. PI8100 Specification

Inverter type	Light Load F		Standard Load G		Medium Load M		Heavy Load H		Structure item
	P _F kW	I _F A	P _G kW	I _G A	P _Z kW	I _Z A	P _H kW	I _H A	
Single phase voltage 220V 50/60Hz									
PI8100...□1	0.75	4	0.4	2.5					7N2
PI8100...□1	1.5	7	0.75	4	0.4	2.5			7N2
PI8100...□1			1.5	7	0.75	4	0.4	2.5	7N2
PI8100...□1	2.2	10	2.2	10	1.5	7	0.75	4	7N3
PI8100...□1	4	16	4	16	2.2	10	1.5	7	7N3
PI8100...□1	5.5	20	5.5	20	4	16	2.2	10	7N4
3 phase voltage 220V 50/60Hz									
PI8100...□2	0.75	4	0.4	2.5					7N2
PI8100...□2	1.5	7	0.75	4	0.4	2.5			7N2
PI8100...□2			1.5	7	0.75	4	0.4	2.5	7N2
PI8100...□2	2.2	10	2.2	10	1.5	7	0.75	4	7N3
PI8100...□2	4	16	4	16	2.2	10	1.5	7	7N3
PI8100...□2	5.5	20	5.5	20	4	16	2.2	10	7N4
3 phase voltage 380V 50/60Hz									
PI8100...□3	0.75	2.5	0.75	2.5	0.75	2.5	0.75	2.5	7N2
PI8100...□3	1.5	3.7	1.5	3.7	1.5	3.7	1.5	3.7	7N2
PI8100...□3	2.2	5	2.2	5	2.2	5	2.2	5	7N2
PI8100...□3	4	8.5	4	8.5	4	8.5	4	8.5	7N3
PI8100...□3	5.5	13	5.5	13	5.5	13			7N3
PI8100...□3	7.5	16	7.5	16	7.5	16	5.5	13	7N4
PI8100...□3	11	25							7N4

7-1-3. Table of rated current for different specifications

G/F/H/S/Z/T/M						
Voltage	220V 1Φ	220V (240V)	380V (415V)	460V (440V)	575V	660V
Power (kW)	Current (A)	Current (A)	Current (A)	Current (A)	Current (A)	Current (A)
0.4	2.5	2.5	-	-	-	-
0.75	4	4	2.5	2.5	-	-
1.5	7	7	3.7	3.7	-	-
2.2	10	10	5	5	-	-
4	16	16	8.5	8	-	-
5.5	-	20	13	11	-	-
7.5	-	30	16	15	-	-
11	-	42	25	22	17	15
15	-	55	32	27	22	18
18.5	-	70	38	34	26	22
22	-	80	45	40	33	28
30	-	110	60	55	41	35
37	-	130	75	65	52	45
45	-	160	90	80	62	52
55	-	200	110	100	76	63
75	-	260	150	130	104	86
93	-	320	170	147	117	98
110	-	380	210	180	145	121
132	-	420	250	216	173	150
160	-	550	300	259	207	175
187	-	600	340	300	230	198
200	-	660	380	328	263	218
220	-	720	415	358	287	240
250	-	-	470	400	325	270
280	-	-	520	449	360	330
315	-	-	600	516	415	345
355	-	-	640	570	430	370
400	-	-	690	650	520	430
450	-	-	740	700	600	490
500	-	-	860	800	650	540

7-2. Standard specification

Items		Specifications		
Power	Voltage and frequency	Single-phase 200~240V, 50/60Hz Three-phase 200~240V, 50/60Hz Three-phase 380~415V, 50/60Hz Three-phase 440~460V, 50/60Hz Three-phase 575V, 50/60Hz Three-phase 660V, 50/60Hz Three-phase 1140V, 50/60H		
	Allowable Fluctuation range	voltage: $\pm 15\%$ frequency: $\pm 5\%$		
Control	Control system	high performance vector control inverter based on 32 bit DSP		
	Output frequency	G/F/Z/S/T/M type: 0.00~400.0Hz, maximum frequency can be set between 10.00 and 400.0Hz		
	control method	V/Fcontrol	Sensorless vector control	Sensor close loop vector control
	Start torque	0.50Hz 180%	0.25Hz 180%	0.00Hz 180%
	speed adjustable range	1: 100	1: 200	1: 2000
	Speed stabilizing precision	$\pm 0.5\%$	$\pm 0.2\%$	$\pm 0.02\%$
	waveform produce methods	Asynchronous space vector PWM, N-class sub-synchronous space vector PWM, two-phase optimization of space vector PWM.		
	Auto torque boost function	Achieve low frequency (1Hz) and high output torque control under V/F control mode.		
	Accelerate /decelerate control	Sub-set S curve acceleration and deceleration mode, maximum acceleration and deceleration time is 3200 days		
	Long running time control	16 segments speed run, maximum running time is 3200 days		
	frequency setting accuracy	Digit: 0.01Hz(below 300Hz), 0.1Hz(above 300Hz); alalogue: 1% of maximum frequency		
	frequency accuracy	Speed control tolerance 0.01%(25°C \pm 10°C).		
	V/F curve mode	Linear, 1.2 times the power, 1.7 times the power, 2 times power, user-set 8 V / F Curve.		
Over load capability	G / S type: 150% rated current -1 minute, rated current 200% -0.1 second; F: rated current 120% -1 minute 150% of rated current -0.1 second; Z / M / T type: rated current 180% -1 minute 250% rated current -0.1 second; H: rated current 250% -1 minute 300% rated current -0.1 second.			
slip compensation	V / F control can automatically compensate for deterioration.			
Running	Running method	Keyboard/terminal/communication		
	Starting signal	Forward, reverse, jog (parameter control direction), forward jog, and reverse jog.		
	Emergency stop	Interrupt controller output.		

Section VII Standard Specifications


	fault reset	When the protection function is active, you can automatically or manually reset the fault condition.
	Running status	Motor status display, stop, acceleration and deceleration, constant speed, the program running.
	DC brake	Built-in PID regulator brake current flow in the premise, however, to ensure adequate braking torque.
Protection	Inverter protection	Overvoltage protection, undervoltage protection, overcurrent protection, overload protection, over-temperature protection, over the loss of speed protection, over-voltage stall protection, phase protection (optional), external fault, communication error, PID feedback signal abnormalities, PG failure
	IGBT temperature display	Display current IGBT temperature
	Inverter fan control	The fan starting temperature can be set(optional)
	Instant power-down re-start	Less than 15 milliseconds: continuous operation. Greater than 15 milliseconds: Automatic detection of motor speed, instantaneous power-down re-start.
	Speed starting track method	automatically track motor speed when inverter starts
	Parameter protection function	Protect inverter parameters by setting the password and decoding
IO	8 way switch input	Can be customized into 68 kinds of functions, to achieve forward, reverse, forward jog, and reverse jog, emergency stop, reset, speed, acceleration speed, run-time switch, and pulse counting.
	3 way analog inputs	Can be defined as a switch input; To allow for maximum input range-10V ~ +10V, 0 ~ 20mA
	2 way analog output	Can achieve output range 0 ~ +10V, 0 ~ 20mA
	Virtual terminal function	Can be set to a virtual terminal, using communication or keyboard IO port, and with the IO port status display.
Keyboard	Frequency set	In 6 main ways + to 7 kinds of auxiliary to the way of the keyboard, three way analog input, pulse input, digital potentiometers.
	Keyboard cable	8-core cable, in line with EIA T568A, EIA T568B standards.
	Double keyboard port	Supports dual-keyboard, synchronous control, independently of each other.
	Double and multi function keys	MF1, MF2 can be customized as addition and subtraction, forward, reverse, forward jog, and reverse jog, emergency stop, rise and fall, and other 9 kinds of ways.
	4-parameter storages	Control panel can be realized four groups of inverter parameters of upload, download, with manufacturer password to reset factory setting.
	Running info	At most display 3 monitoring parameters. Select by A00, A01, A02
	Fault info	Store 5 groups error messages at most, you can check the type of failure time when failure occurs, set frequency, output frequency, output voltage, output current, running state, running time, IGBT temperature.
Communication	Double RS485 port	Rs485 port and an optional keyboard completely isolated RS485 communication module.

	CAN BUS	Can select can-bus module.
Speed	16-segment speed	At most 16 segments can be set (use multi-functional terminal to shift or program runs).
	8-segment running time	At most 8 segment running time can be set (multi-functional terminal can be used to shift)
	8 segment acceleration speed	At most 8 acceleration speed (can use the multi-functional terminal to switch).
	Seven-Segment Speed Configuration	At most 7 segment speed configuration can be set (multi-functional terminal can be used to switch).
PID	PID feedback signal	Six kinds of ways, keyboard, three way analog input, pulse input, digital potentiometers.
	PID giving signal	Six kinds of ways, keyboard, three way analog input, pulse input, digital potentiometers.
Motor	2 groups of motor parameters	With the motor parameters, parameter can be selected, parameter identification automatic storage.
	3 identification method	Name plate calculation, static measurement, rotation measurements.
	5 name plate parameters	Rated frequency, rated current, rated voltage, the number of pole pairs, rated speed.
	5 identification parameters	N-load current, stator resistance, rotor resistance, stator inductance, mutual inductance.
Environment	Environment temperature	-10℃ ~ 40℃, 40 ~ 50℃ derating between the use is increased by 1℃, rated output current decrease of 1%.
	Store temperature	-40℃ ~ +70℃
	Environment humidity	5~ 95 %, No condensation
	Height-vibration	0 ~ 2000 meters, 1000 meters above derating use, increased by 100 m, rated input decreased%
	Application location	Mounted vertically inside the control cabinet with good ventilation, do not allow the level, or other installation method. The cooling medium is air. Installed in the absence of direct sunlight, N dust, N corrosive and explosive gas, N oil mist, N steam, N drip environment
	Cooling method	Forced air cooling and natural air cooling.

7-3. Sharp Size

7-3-1. PI8000 family (3 phase voltage 380~415V, 50/60Hz)

1. 8N2~8N9



1) 8N2

Type	Power (kW)	Structure item	Shape			Installation dimension		
			L	W	H	a	b	d
F	15~18.5	8N2	380	220	230	360	135	Ø10
G	11~15							
M	7.5~11							
H	7.5							

2) 8N3

Type	Power (kW)	Structure item	Shape			Installation dimension		
			L	W	H	a	b	d
F	22~30	8N3	460	280	245	440	160	Ø10
G	18.5~22							
M	15~18.5							
H	11~15							

3) 8N4

Type	Power (kW)	Structure item	Shape			Installation dimension		
			L	W	H	a	b	d
F	37~45	8N4	500	300	270	480	200	Ø10
G	30~37							

M	22~30							
H	18.5~22							

4) 8N5

Type	Power (kW)	Structure item	Shape			Installation dimension		
			L	W	H	a	b	d
F	55~75	8N5	630	360	297	610	200	Ø10
G	45~55							
M	37~45							
H	30~37							

5) 8N6

Type	Power (kW)	Structure item	Shape			Installation dimension		
			L	W	H	a	b	d
F	93~170	8N6	700	400	297	680	200	Ø10
G	75~93							
M	55~75							
H	45~55							

6) 8N7

Type	Power (kW)	Structure item	Shape			Installation dimension		
			L	W	H	a	b	d
F	132~160	8N7	750	475	320	730	260	Ø10
G	110~132							
M	93~110							
H	75~93							


7) 8N8

Type	Power (kW)	Structure item	Shape			Installation dimension		
			L	W	H	a	b	d
F	187~200	8N8	850	500	320	830	260	Ø10
G	160~187							
M	132~160							
H	110~132							

8) 8N9


Type	Power (kW)	Structure item	Shape			Installation dimension		
			L	W	H	a	b	d
F	220~250~280	8N9	1000	600	380	940	370	Ø14
G	200~220~250							
M	187~200~220							
H	160~187~200							

2. 8NA



Type	Power (kW)	Structure item	Shape			Installation dimension		
			L	W	H	a	b	d
F	200~220~250	8NA	1540	515	443	465	367	Ø13
G	200~220~250							
M	187~200~220							
H	160~187~220							

3. 8NB




Section VII

Type	Power (kW)	Structure item	Shape			Installation dimension		
			L	W	H	a	b	d
F	315~355~400~450	8NB	1700	850	492	640	260	Ø13
G	280~315~355~400							
M	250~280~315							
H	220~250							

7-3-2. PI8100 Family


1. 7N2~7N4

1) 7N2




Power type	Type	Power (kW)
Single phase 220V	F	0.75~1.5
	G	0.4~1.5
	M	0.4~0.75
	H	0.4
3 phase 220V	F	0.75~1.5
	G	0.4~1.5
	M	0.4~0.75
	H	0.4
3 phase 380V	F	0.75~1.5~2.2
	G	0.75~2.2
	M	0.75~2.2
	H	0.75~2.2

2) 7N3



Power type	Type	Power (kW)
Single phase 220V	F	2.2~4
	G	2.2~4
	M	1.5~2.2
	H	0.75~1.5
3 phase 220V	F	2.2~4
	G	2.2~4
	M	1.5~2.2
	H	0.75~1.5
3 phase 380V	F	4~5.5
	G	4~5.5
	M	4~5.5
	H	4


3) 7N4




Power type	Type	Power (kW)
Single phase 220V	F	5.5
	G	5.5
	M	4
	H	2.2
3 phase 220V	F	5.5
	G	5.5
	M	4
	H	2.2
3 phase 380V	F	7.5~11
	G	7.5
	M	7.5
	H	5.5

7-3-3. Keyboard size


JP6C8000:



JP6E8000:



JP6D8000 the dimension of keyboard rabbit:



Section VII

KLINGER BORN

Section VIII. Maintenance

8-1. Inspection and Maintenance

Under normal working conditions, in addition to daily inspection, the frequency converter should be subject to regular inspection (for example inspection for overhaul or as specified but at an interval of six months at most). Please refer to the following table in order to prevent faults.

Check time		Check point	Check item	Check to be done	Method	Criterion
D	R					
√		Display	LED and OLED display	If there is any abnormal display	Visual check	As per use state
√	√	Cooling system	Fan	If abnormal noise or vibration is produced.	Visual and audible check	N abnormal sound or vibration
√		Body	Surrounding conditions	Temperature, humidity, dust content, harmful gas, etc.	Check visually, by smelling and feeling	As per Section 2-1
√		Input/output terminal	Voltage	If input, output voltage is abnormal	Measure at R, S, T and U, V, W terminals	As per standard specifications
	√	Main circuit	Overall conditions	If the fastenings come loose, if any signs show overheat, discharging, or too high dust content, or the air piping is blocked	Check visually, tighten the fastenings, and clean the related parts	N abnormal conditions
			Electrolytic capacitance	If there is abnormal appearance	Check visually	N abnormal condition
			Current-conducting leads or blocks	If the parts come loose	Check visually	N abnormal condition
			Terminals	If the screws or bolts come loose	Tighten the loose screws or bolts	N abnormal condition

—D means daily check and —R” means regularly check.

—√” means need daily check or regularly check

For inspection, do not disassemble or shake the parts without reason, and still less pull off the plug-in-parts at random. Otherwise, the unit will not operate normally, or can not enter the mode of fault display, or causes faults of components or even parts of the main switch components IGBT module is damaged.

If measuring is necessary, the user should note that much different results will be gained possibly if the measuring is performed with different instruments. It is recommended that the input voltage be measured with pointer-type voltmeter, output voltage with rectification voltmeter, input and output current with tong-test ammeter, and power with electrically-driven wattmeter.

8-2. Periodically-Replaced Parts

In order to ensure the operation reliability of the frequency converter, in addition to regular maintenance and inspection, all the parts suffering long-term mechanical wear should be replaced at a regular interval, which includes all cooling fans and the filtering capacitors of main circuits for energy buffer and interchange and PCBs. For continuous use under normal conditions, these parts can be replaced according to the following table and the operating environment, loads and the current state of frequency converter.

Part name	Interval for replacement
Cooling fan	1~3 years
Filtering capacitor	4~5 years
PCB (printed circuit board)	5~8 years

8-3. Storage

The following actions must be taken if the frequency converter is not put into use immediately after delivery to the user and need to keep well for the time being or stored for a long time:


- ※ Stored in a dry and adequately-ventilated place without dust and metal powder at the temperature specified in the specifications.
- ※ If the frequency converter is not put into use after one year, a charge test should be made, so as to resume the performance of the filtering capacitor of main circuit in it. For charging, a voltage regulator should be used to slowly increase the input voltage of the frequency converter until it reaches the rating, and the charge should last more than 1~2 hours. This test should be made at least once a year.
- ※ Don't perform breakdown test at random, for this test will cause shorter life of the frequency converter. The insulation test must be performed after the insulation resistance is measured with a 500-volt megaohm and this value must not be less than 4MΩ.

8-4. Measuring and Judgment

- ※ If the current is measured with the general instrument, imbalance will exist for the current at the input terminal. Generally, differing by not more than 10% is normal. If it differs by 30%, inform the factory to replace the rectification bridge, or check if the error of three-phase input voltage is above 5V.
- ※ If the three-phase output voltage is measured with a general multi-meter, the reading is not accurate due to the interference of carrier frequency and only for reference.

Section IX. Options

The series can acquire the peripheral equipment by user because of the different using condition and requirement. See the wiring diagram as below:



9-1. MCCB OR ELCB

As power switch of the inverter, MCCB or ELCB can protect supply power, but can't control inverter to run or stop.


9-2. AC reactance

AC reactance is able to restrain the high harmonic wave of converter input current and improve converter's power factor obviously. It's recommended that AC reactance will be used in the following condition:

Section IX Options

- ※ The capacity of power source is ten times more than the capacity of converter.
- ※ SCR load or power factor compensated device with ON/OFF is connected with the same power supply.
- ※ Unbalanced 3-phase voltage is bigger (more than 3%).

The common size of AC input reactance:



Sharp size:

Inverter standard		Size (mm)						Gross Weight (kg)
Voltage	Capacity (kW)	A	B	C	D	E	F	
200V 230V	0.75	155	125	95	7	89	60	3.0
	1.5	155	125	95	7	89	60	3.0
	2.2	155	125	95	7	89	60	3.0
	4	155	125	95	7	89	60	3.5
	5.5	155	125	100	7	89	60	3.5
	7.5	155	125	112	7	89	70	4.0
	11	155	125	112	7	89	70	6.0
	15	180	140	112	8	90	80	8.0
	18.5	180	140	112	8	90	90	8.0
	22	180	140	112	8	90	90	8.0
	30	230	175	122	10	160	90	12.0
	37	230	175	132	10	160	100	15.0
	45	230	175	150	10	160	110	23.0
	55	230	175	160	10	160	120	23.0
75	285	220	230	14	180	130	30.0	
380V 460V	0.75	155	125	95	7	89	60	3.0
	1.5	155	125	95	7	89	60	3.0
	2.2	155	125	95	7	89	60	3.0
	4	155	125	95	7	89	60	3.5

5.5	155	125	100	7	89	60	3.5
7.5	155	125	112	7	89	70	4.0
11	155	125	112	7	89	70	6.0
15	180	140	112	8	90	80	8.0
18.5	180	140	112	8	90	90	8.0
22	180	140	112	8	90	90	8.0
30	230	175	122	10	160	90	12.0
37	230	175	132	10	160	100	15.0
45	230	175	150	10	160	110	23.0
55	230	175	160	10	160	120	23.0
75	285	220	230	14	180	130	30.0
110	285	250	230	14	210	140	33.0
160	360	260	230	14	210	140	40.0
200	360	270	230	14	210	140	45.0
250	400	330	240	14	240	140	55.0
315	400	350	285	14	270	160	90.0

9-3. Noise filter

The filter is used to restrain the conduction of electrical magnetic wave interference noise produced by the converter or shock the interferential form radio or momentary concussion. The common size of 3-phase EMI noise filter is shown as following: confirm the power supply is 3-phase three lines or 3-phase four lines or single phase. Earthing wire is as short as possible, try to place the filter near the converter.

Please choose EMI filter when the converter is used in residential area, commercial area, science area or other. Please need to prevent magnetic interference, or need meet CE, UL, and CSA standard.

Note: If needed the filter, please contact with our company.

9-4. Connector

It can cut off the supply power in action of the system protection function, to prohibit fault enlarging. But can't control the motor start or stop by connector.

9-5. Braking Unit & braking resistor

There is braking unit inside when using -B" type frequency converter, the maximum braking torque is 50%. Please choose braking resistor according to the following table:

Type	Converter power (kW)	Braking resistor (Ω)	Braking resistor Power (W)
220V	0.75	200	120
	1.5	100	300
	2.2	70	300
	4	40	500
	5.5	30	500
	7.5	20	780

	11	13.6	2000
	15	10	3000
	18	8	4000
	22	6.8	4500
380V	0.75	750	120
	1.5	400	300
	2.2	250	300
	4	150	500
	5.5	100	500
	7.5	75	780
	11	50	1000
	15	40	1500

Please choose BRAKING UNIT if you need more braking torque. Please refer to the catalog of braking unit.

There is N braking unit inside the large capacity frequency converter. Please choose BRAKING UNIT if you need braking.

9-6. Output EMI filter

The fittings can restrain the disturbance noise and lead leak current produced in the output side.

9-7. AC output reactor

When the line from inverter to motor is longer than 20 meters, it can restrain the over-current caused by the distributing current and the wireless disturbance of the inverter.

Section X Quality Assurance

The product quality assurance is in accordance with the following regulations:

1. The manufacturer should take responsibility for below specific elements:
 - 1-1. In domestic use (as calculated from the date of shipment)
 - ※ shipped within one month should accept refund, replacement and repair.
 - ※ shipped within three months should accept replacement and repair.
 - ※ ship packages within 15 months should accept repair.
 - 1-2. Goods exported overseas (excluding China) and shipped within six months, the local seller is responsible for repair.
2. Regardless of when and where to use branded products are paid to enjoy lie-long service.
3. All the distributors, agency or production place of in whole China can provide after-sales service for powtarn product, their conditions of service as follows:
 - 3-1. We provide a 3-level inspection service on the local selling place (including troubleshooting).
 - 3-2. All services comply with the related after-sale service terms and conditions stated on the agency agreement between distributors.
 - 3-3. Buyers can pay to any agent if need any after-sales services (whether or not the warranty).
4. If this product has some quality problem or product liability accidents, we will take the responsibility to terms 1-1 or 1-2 at most. if users need more liability guarantee, please apply for insurance company in advance to insure your own property insurance.
5. The product's warranty period is one year from the date of shipment.
6. In the case of the following causes of failure, even in the warranty period is also a paid repair:
 - 6-1. Incorrect operation (depending on the use of manual), or modified without permission to repair the problems caused.
 - 6-2. The problems caused by using the inverters beyond its standard specifications requirement.
 - 6-3. Damage caused by drop down or improper handling.
 - 6-4. Inverters components aged or failure caused by improper environment.
 - 6-5. Due to an earthquake, fire, wind and water disasters, lightning, abnormal voltage or other natural disasters and disasters, accompanied by the damage caused.
 - 6-6. The damage during transport (Note: The mode of transport designated by the customer, the company's help on behalf of the procedures for handling the transfer of goods).
 - 6-7. When the manufacture's brand, trademark, serial number, nameplate and other damage or can not be recognized.
 - 6-8. If the buyer has not paid full money according to purchase agreement.
 - 6-9. The installation, wiring, operation, maintenance or other use of objective reality can not be described to the company's service office.
7. Concerning refund, replacement and repair services, goods shall be returned to the company, after confirmed the attribution of responsibility then they are allowed to be returned or repaired.

Appendix I. RS485 Communication Protocol

I-1. Use introduce

This chapter introduces something about the install and handle of RS485 communication between inverter and PLC, PC, factory computer.

RS485 standard interface

- Can communicate with all computer
- Using multi-drop link system, can link more to 127 inverters
- Completely isolated, and noise shield
- The user would use all types of RS232-485 inverter, if only the inverter had "automatic RTS control" function inside.

I-2. Specification

Communication function


Items	Specification
Communication baud rate	38400/19200/9600/4800/2400/1200 bps is selectable.
Communication Protocol	Modbus protocol, RTU format
Interface methods	Asynchronism communication methods, semi-duplex, the previous high byte, low byte in the post, and low-effective-bit pre-emptive.
Data fumula	1 start bit, 8 data bits, 1 stop bit, invalid parity bit.
Slave address	Slave addresses can be set up 1~ 127 0 for broadcast address, host address 128 for the proportion of linkage, other addresses are reserved.
Communication port A	Isolated RS485 Communication Card, Terminals SG+, SG- RS232 communication card, terminals TX232, RX232 Shield SH, Default 19200bps.
Communication port B	RJ45, 8-core shielded cable, fixed 19200bps.

I-3. Communication connection


I-3-1. Definition for Communication port A:

- RS485 communication module installation

8K-RS485_S connect to 8KLCB control board




8K-RS485_S connect to 8KSCB control board



- Link RS485 communication cables to inverter control terminals (SG+), (SG-).
- When using RS232-485 transform, connect Inverter -SG+” to RS485 -T+” , Inverter -SG-” to RS485 -T-”.
- After Confirming connection again, turn on inverter power.
- If connection is right, set communication parameters as following:
- A29 baud rate 0: 1200, 1: 2400, 2: 4800, 3: 9600, 4: 19200, 5: 38400


- A28 current inverter communication address 1~127 (If there are more than 1 inverters, don't use the same number);
- When using RS485 running control methods, set F04=0/1/2, choice RS485 running control method



Appendix I

I-3-2. Definition for Communication port B:

Communication port B pins	1	2	3	4	5	6	7	8
Communication B port signal	GND	+5V	485+	485-	485+	485-	+5V	GND
EIA/TIA T568A	White green	green	White orange	blue	white Blue	orange	White Brown	brown
EIA/TIA T568B	White Orange	Orange	White Green	Blue	White Blue	green	White Brown	brown




I-3-3. Data safety and reliability

- The number of inverter can be connected is no more than 127.
- Though the length of communication cable can add up to 1300m, considering the stability, the length limit within 800m.
- All the control signal cable use the shield cable, and is linked to the signal terminal –SH’ of RS485.
- Data packet using CRC (vertical lengthy test) frame detection to ensure data reliability.
- Completely isolated RS485 communication module to ensure reliable communications, support hot-swappable, after modular access, you can enter the work.
- The system is tested in 6 kinds of baud rate: 0:1200, 1:2400, 2:4800, 3:9600, 4:19200, 5:38400
- However, if under deteriorating environmental conditions, lowering the baud rate can improve the communication quality.
- Interval time of sending from frame to frame is more than 50 bytes.

I-4. Communication Protocol

Communication architecture is inverter as a slave, the computer as a host.

MODBUS protocol defines a simple protocol data unit (PDU) which has nothing to do with a basic communication layer, Specific bus or network MODBUS protocol mapping can introduce some additional domain from application data unit (ADU).



The basic format description

I-4-1: Start of frame, End of frame
Interval ≥ 3.5 bytes,

I-4-2: Slave Address

From the machine's local address, through the A28 parameter settings, one network can only one local address uniquely identified.

Setting range 1 ~ 127.

00H = 0 ID address is broadcast mailing address, 128 ~ 255 reserved.

I-4-3: Function Code

Host send commands, slave response.

- Function Code Categories

0x03 = read inverter's multiple function codes, at most can read 16 registers(register pair of byte)

Host command

Frame start address	Slave address	Function code	Registers address	Register number	CRC checksum	frame end address
Interval ≥ 3.5 bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes	Interval ≥ 3.5 bytes

Slave response

Frame start address	Slave address	Function code	Read byte	Read content	CRC checksum	frame end address
Interval ≥ 3.5 bytes	1 byte	1 byte	1 byte	2 bytes * register number	2 bytes	Interval ≥ 3.5 bytes

Note: Read content = 2 bytes x register number

0x06 = write inverter 1 function code

Host command

Frame start address	Slave address	Function code	Registers address	Register data	CRC checksum	frame end address
Interval ≥ 3.5 bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes	Interval ≥ 3.5 bytes

Slave response

Appendix I Rs485 Communication Protocol

Frame start address	Slave address	Function code	Registers address	Register data	CRC checksum	frame end address
Interval \geq 3.5bytes	1 byte	1 bytes	2 bytes	2 bytes	2 bytes	Interval \geq 3.5 bytes

0x10=Write multiple function in inverter, at most can be written in 16 registers(register pair of byte)

Host command

Frame start address	Slave address	Function code	Register address	Register number	Register content byte	Register content	CRC checksum	frame end address
Interval \geq 3.5bytes	1 byte	1 byte	2 bytes	2 bytes	1 byte	2bytes*register number	2 bytes	Interval \geq 3.5bytes

Slave response

Frame start address	Slave address	Function code	Register address	Register number	CRC checksum	frame end address
Interval \geq 3.5bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes	Interval \geq 3.5bytes

0x01=Read multiple switch status

Host Command

Frame start address	Slave address	Function code	address	Switch number	CRC checksum	frame end address
Interval \geq 3.5bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes	Interval \geq 3.5bytes

Slave response

Frame start address	Slave address	Function code	Read byte number	switch state	CRC checksum	frame end address
Interval \geq 3.5bytes	1 byte	1 byte	1 byte(data N)	N bytes	2 bytes	Interval \geq 3.5bytes

Note: read byte number N=output quantity/8, if the remainder is not 0, read byte number is N=N+1

0x05=Write single switch status

Host Command

Frame start address	Slave address	Function code	Output address	Output value	CRC checksum	frame end address
Interval \geq 3.5bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes	Interval \geq 3.5bytes

Note: output value 0xFF00, switch ON; output value 0x0000, switch OFF. Other values are illegal, the switch does not work.

Slave response

Frame start address	Slave address	Function code	Output address	Output value	CRC checksum	frame end address
Interval \geq 3.5bytes	1 byte	1 byte	2 bytes	2 bytes	2 bytes	Interval \geq 3.5bytes

If slave response and get back to below function code, it means communications abnormal.

0xA0 = 0x80+0x20= Invalid operation, setting under this state is invalid

0xA1 = 0x80+0x21= function code is invalid

0xA2 = 0x80+0x22= Fault record is empty

0xA3 = 0x80+0x23= register address is invalid

0xA4 = 0x80+0x24= slave is busy, EEPROM delay.

0xA5 = 0x80+0x25= administrator restricted

0xA6 = 0x80+0x26= set value is beyond limit.

0xA7 = 0x80+0x27= CRC checksum error

0xA8 = 0x80+0x28= frame format error

I-4-4: Register Address:

The register address includes two bytes, data setting is constituted by a two-byte.

Function code	Register Address high byte		Register Address low byte	
0x03.read inverter multiple function.code parameter	Parameter group		Parameter serial number	
	F	0x00	0~63	
	A	0x01	0~63	
	o	0x02	0~71	
	H	0x03	0~55	
	U	0x04	0~15	
	P	0x05	0~15	
	E	0x06	0~23	
	C	0x07	0~47	
	b	0x08	0~23	
y NOTE 1	0x09	0~23		
S	0x0B	0~15		
0x03.read inverter status	Status		Status number	
	R	0x10	0x00	Running status NOTE 2
			0x01	Reserved status 1
			0x02	Reserved status 2
			0x03	Reserved status 3
0x03.read inverter.fault history record	Fault record		Fault status history record content	
	Fault history record 1 Fault history record 2 Fault history record 3 Fault history record 4 Fault history record 5	0x20 0x21 0x22 0x23 0x24	0x00	Fault type NOTE 4
			0x01	Set frequency
			0x02	Actual frequency
			0x03	Actual current
			0x04	DC voltage
			0x05	Running status NOTE 5
			0x06	Running time
0x07	IGBT temperature			
0x06.write inverter.single	Register Address high byte		Register Address low byte	
	Parameter group	High byte	Parameter serial number	

function.code parameter, only write RAM 0x10.write inverter multiple function.code parameter, only write RAM		data				
	F	0x00	0~63			
	A	0x01	0~63			
	o	0x02	0~71			
	H	0x03	0~55			
	U	0x04	0~15			
	P	0x05	0~15			
	E	0x06	0~23			
	C	0x07	0~47			
	b	0x08	0~23			
y NOTE 1	0x09	0~23				
0x06.write inverter command	Command		Command number			
	R	0x10	0x00	Running command NOTE 3		
			0x01	Reserved command 1		
			0x02	Reserved command 2		
			0x03	Reserved command 3		
Function parameter write EEPROM, register address high byte=original register address high byte+0x80						
0x06.write inverter.single function.code parameter 0x10.write inverter multiple function code parameter	Register address high byte		Register address low byte			
	parameter		Parameter serial number			
	F	0x80	0~63			
	A	0x81	0~63			
	o	0x82	0~71			
	H	0x83	0~55			
	U	0x84	0~15			
	P	0x85	0~15			
	E	0x86	0~23			
	C	0x87	0~47			
b	0x88	0~23				
y NOTE 1	0x89	0~23				
0x01.read multiple switch status 0x05.Write single.switch status	Register address high byte		Register address low byte			
	Switch classify	address	Parameter value			
	Running status	0x00	0	Control method	0	V/F control
				1	SV control	
			1	reserved		
				2	Running status	0
			1		run	
			3	Direction status	0	reverse
				1	forward	
			5,4	Speed up status	00	stop
01					acceleration	
10					deceleration	
6	upper	0	Upper frequency			

				frequency		not arrive
				1	Arrive	
			7	Lower frequency	0	lower frequency
					1	Arrive
			8	JOG running	0	No JOG running
					1	JOG running
			9	Reserved		
			10	Reserved		
			11	Reserved		
			12	Fault confirm	0	Confirmed fault
					1	Unconfirmed fault
			13	Direction status	0	No fault
					1	alarming fault
			14	JOG status	0	No fault
					1	Deceleration stop fault
	15	Fault status	0	No fault		
			1	Urgent stop fault		
	Input terminal function	0x01	0	DI1 input	0	Invalid
				1	Valid	
			1	DI2 input	0	Invalid
					1	Valid
			2	DI3 input	0	Invalid
					1	Valid
			3	DI4 input	0	Invalid
1					Valid	
4			DI5 input	0	Invalid	
				1	Valid	
5			DI6 input	0	Invalid	
				1	Valid	
6			DI7 input	0	Invalid	
				1	Valid	
7			DI8 input	0	Invalid	
				1	Valid	
8			AI1 input	0	Invalid	
				1	Valid	
9			AI2 input	0	Invalid	
				1	Valid	
10			AI3 input	0	Invalid	
	1	Valid				

Output.terminal function	0x02	0	O1 input	0	Invalid		
				1	Valid		
		1	O2 input	0	Invalid		
				1	Valid		
		2	O3 input	0	Invalid		
				1	Valid		
		3	O4 input	0	Invalid		
				1	Valid		
		Fault type	0x03	0	E.OCP	System is disturbed or impacted by instant over current,over current signal from current inspected circuit or drive circuit	
				1	reserved		
				2	E.OC3	Inverter output current exceeded 3times the motor rated current	
				3	reserved		
	4			E.OU	Over voltage		
	5			E.LU	Under voltage		
	6			E.OL	Over load		
	7			E.UL	Under load warming		
	8			E.PHI	Phase loss		
	9			E.EEP	EEPROM error		
	10			E.ntC	Over heat		
	11			E.dAt	Time limit fault		
	12			E.Set	External fault		
	13	reserved					
	14	reserved					
	15	reserved					
16	E.PId	PID regulation fault					
17	E.OHt	Motor over heat fault					
18	E.OL2	Motor over load fault					
19	E.PG	PG error					
20	E.PHo	Inverter output phase loss					
21	E.COa	Rs485.communication port A fault					
22	E.COb	Rs485.communication port B fault					
23	E.CAL	Parameter identification fault					
Register address high byte		Register address low byte					
Switch classify	address	Parameter number					
Running status	0x00	0	Run command	0	stop		
				1	run		

			1	reserved		
			2	Direction command	0	reverse
					1	forward
			3	reserved		
			4	reserved		
			5	JOG command	0	reverse
					1	forward
			6	reserved		
			7	Free stop	0	reverse
					1	forward
			8	reserved		
			9	reserved		
			10	reserved		
			11	reserved		
			12	reserved		
13	reserved					
14	reserved					
15	reserved					
Input terminal function	0x01	0	DI1 input	0	invalid	
				1	valid	
		1	DI2 input	0	invalid	
				1	valid	
		2	DI3 input	0	invalid	
				1	valid	
		3	DI4 input	0	invalid	
				1	valid	
		4	DI5 input	0	invalid	
				1	valid	
		5	DI6 input	0	invalid	
1	valid					
6	DI7 input	0	invalid			
		1	valid			
7	DI8 input	0	invalid			
		1	valid			
8	AI1 input	0	invalid			
		1	valid			
9	AI2 input	0	invalid			
		1	valid			
10	AI3 input	0	invalid			
		1	valid			
Output terminal function	0x02	0	O1 output	0	invalid	
				1	valid	
			1	O2 output	0	invalid

			2	O3 output	1	valid
					0	invalid
			3	O4 output	1	valid
					0	invalid

NOTE 1:

Function	0x03 reading operation			0x06/0x10 writing operation
y00 reset the factory setting	Return 0			Only can write into 5
y01 upload parameter onto keyboard	Return 0			Invalid operation
y02 latest fault record	Valid operation			Invalid operation
y03~y07 fault history record	Empty record	00H		Invalid operation
	New record	01H		
	Confirmed record	02H		
y08reset fault record	Return 0			Valid operation
y09 rated output current	Valid operation			Invalid operation
y10 rated output voltage	Valid operation			Invalid operation
y11 products series	80	0	3	Invalid operation
	Family serial	products series	Input voltage level	
	The number should be decimalization.			
y12 soft ware version	Valid operation			Invalid operation
y13 product date –year	Valid operation			Invalid operation
y14 product month–date	Valid operation			Invalid operation
y15 user decode input	Valid operation			Invalid operation
y16 user input password	Valid operation			Valid operation
y17 parameter group protection	Valid operation			Valid operation

NOTE 2: running status byte

BIT	15 BIT	14 BIT	13 BIT	12 BIT
meaning	0: No fault 1: urgent stopping fault	0: No fault 1: decelerating fault	0: No fault 1: alarming fault	0: confirmed fault 1: unconfirmed fault
bit	11 BIT	10 BIT、	9 BIT	8 BIT
meaning	reserved	reserved	reserved	0: No JOG 1: JOG running
bit	7 BIT	6 BIT	5 BIT 、 4 BIT	
meaning	0: lower frequency not arriving 1: arrive lower	0: upper frequency not arriving 1: arrive upper	00: stopping 10: decelerating 11: running in a even speed	01: accelerating

	frequency	frequency		
bit	3 BIT	2 BIT	1 BIT	0 BIT
meaning	0: running reverse 1: running forward	0: stopping 1: running	reserve	0: V/F control 1: SV control

NOTE 3: running command

bit	15 BIT	14 BIT	13 BIT	12 BIT
meaning	reserve	reserve	reserve	reserve
Bit	11 BIT	10 BIT	9 BIT	8 BIT
meaning	reserve	reserve	reserve	reserve
bit	7 BIT	6 BIT	5 BIT	4 BIT
meaning	0: No free-stop 1: free-stop command	reserve	0: JOG stopping 1: JOG running	reserve
bit	3 BIT	2 BIT	1 BIT	0 BIT
meaning	reserve	0: reverse command 1: forward command	reserve	0: stop command 1: run command

NOTE 4: fault code

Serial number	LED display	Fault message
0	E.OCP	System is disturbed or impacted by instant over current, over current signal from current inspected circuit or drive circuit
1	reserve	
2	E.OC3	Inverter output current exceeded 3 times of motor rated current
3	reserve	
4	E.OU	Over voltage
5	E.LU	Under voltage
6	E.OL	Over load
7	E.UL	Under load warm
8	E.PHI	Input phase loss
9	E.EEP	EEPROM error
10	E.ntC	Over heat
11	E.dAt	Time limit fault
12	E.Set	External fault
13	reserve	
14	reserve	
15	reserve	
16	E.PId	PID regulation fault
17	E.OHt	Motor over heat fault

18	E.OL2	Motor over load fault
19	E.PG	PG error
20	E.PHo	Inverter output loss phase
21	E.COA	Rs485 communication port A fault
22	E.CO _B	Rs485 communication port B fault
23	E.CAL	Parameter identification fault

NOTE 5: fault running status

LED first position			LED second position			LED third position			LED fourth position		
Bit15-Bit12			Bit11-Bit8			Bit7-Bit4			Bit3-Bit0		
F	0	Forward	F	0	Forward status	-	0	Separative sign	A	1	Accelerating
R	1	Reverse	R	1	Reverse status				D	2	Decelerating
S	2	Stop command	S	2	Stop status				E	3	running in a even
									S	0	stop

E.g. keyboard display FF-A (return data 0001), said when fault occurs the inverter state: forward command、forward state、accelerating running

I-4-5: CRC checkup sum

Data meaning: data frame CRC checkup sum, using 2 bytes.

Checksum sum = address + function code + data

Enclose: CRC computation program:

Unsigned int cal_crc16 (unsigned char *data, unsigned int length)

```

{
unsigned int i,crc_result=0xffff;
while(length--)
{
    crc_result^=*data++;
    for(i=0;i<8;i++)
    {
        if(crc_result&0x01)
            crc_result=(crc_result>>1)^0xa001;
        else
            crc_result=crc_result>>1;
    }
}
crc_result=((crc_result&0xff)<<8)|(crc_result>>8);
return(crc_result);

```

I-5 Example of communication protocol:

Valid setup and communications under normal circumstances, the host command and slave responses are as follows:

0x03= read inverter multiple function code, at most can read 16 registers (register 2bytes)

Host command read inverter **F01 keyboard set frequency**, **F02 frequency set up method**

Slave address	Function code	Register address	Register number	CRC checksum
0x08	0x03	0x0001	0x0002	0x9552

Slave response inverter **F01 keyboard set frequency** to 50.00Hz, **F02 frequency set up method** to 0 (keyboard set frequency or RS485)

Slave address	Function code	Read byte number	Read content	CRC checksum
0x08	0x03	0x04	0x1388,0x0000	0xE79D

Read byte number=2byte*register number

0x06=write inverter single function code

Host command set up inverter **F01 keyboard set frequency inverter** to 50.00Hz

Slave address	Function code	Register address	Register data	CRC checksum
0x08	0x06	0x0001	0x1388	0xD5C5

Slave response inverter **F01 keyboard set frequency** to 50.00Hz

Slave address	Function code	Register address	Register data	CRC checksum
0x08	0x06	0x0001	0x1388	0xD5C5

0x10=write inverter multiple function code, at most can write 16 registers(register 2bytes)

Host command inverter **F01 keyboard set frequency** to 50.00Hz, **F02 frequency set up method** to 0 (keyboard set frequency or RS485)

Slave address	Function code	Register address	Register number	Register content byte number	Register content	CRC checksum
0x08	0x10	0x0001	0x0002	0x04	0x1388,0x0000	0x9851

Register content byte number=2 bytes * register number

Slave response

Slave address	Function code	Register address	Register number	CRC checksum
0x08	0x10	0x0001	0x0002	0x1091

0x01=read multiple switch status

Host command read inverter whether arrive lower frequency, or arrive upper frequency

Slave address	Function code	Starter to end address	Switch number	CRC checksum
0x08	0x01	0x0006	0x0002	0x5D53

Slave response inverter not arrive lower frequency nor upper frequency

Slave address	Function code	Read byte number	Switch state	CRC checksum
0x08	0x01	0x01	0x40	0x53E4

Host command read inverter fault

Slave address	Function code	Starter to end address	Switch number	CRC checksum
0x08	0x01	0x0300	0x0020	0x3D0F

Slave response inverter low voltage (E.LU switch address 0x0305)

Slave address	Function code	Read byte number	Switch state	CRC checksum
0x08	0x01	0x04	0x20,0x00,0x00,0x00	0x6911

Note : return byte : 4 bytes;

Return date in order: bit7-bit0, bit15-bit8, bit23-bit16, bit31-bit24

0x05= write single switch status

Host command control inverter running

Slave address	Function code	Output address	Output value	CRC checksum
0x08	0x05	0x0000	0xFF00	0x8CA3

Slave response

Slave address	Function code	Output address	Output value	CRC checksum
0x08	0x05	0x0000	0xFF00	0x8CA3

Host command control inverter stop

Slave address	Function code	Output address	Output value	CRC checksum
0x08	0x05	0x0000	0x0000	0xCD53

Slave response

Slave address	Function code	Output address	Output value	CRC checksum
0x08	0x05	0x0000	0x0000	0xCD53

Note: set switch to 1,output value is 0xFF00;set switch to 0,output value is 0x0000.

Appendix II Instruction of the Proportional Linkage Function

II-1. proportional linkage function:

The proportion interaction host computer:

Communication address = 128,

Communications port A is the communication port of host computer.

Communication port B can be used as the keyboard interface, or a PC host computer interface.

There is only one host inverter in one proportional linkage.

The host inverter control the running state, the slave inverter follow the host's running state.

The proportion interaction slave computer:

Communication Address = 1 ~ 127,

Both communication port A and communication port B can be the communication port of slave inverter.

In the slave inverter follow the host running and it can realize forced stopping by terminal or keyboard if need.

For this function, the host computer should be set with the following parameters:

A28	Local communication address	128
-----	-----------------------------	-----

For this function, the slave computer should be set with the following parameters:

F01	Keyboard set the frequency / Rs485	Command from proportion linkage Host	
F02	Frequency main set mode	Keyboard setting frequency or RS485	0
		AI1 the external analog setting	1
		AI2 the external analog setting	2
		AI3 the external analog setting	3
		Keyboard potentiometer setting	4
		Multi-segment digital voltage set	5
		Digital Pulse Setting	6
F03	Auxiliary setting mode of frequency set	Keyboard setting frequency or RS485	0
		AI1 the external analog setting	1
		AI2 the external analog setting	2
		AI3 the external analog setting	3
		Keyboard potentiometer setting	4
		Multi-segment digital voltage setting	5
		Digital Pulse Set	6
		PID regulation mode	7
F04	relationship between main and auxiliary frequencies	The main setting individual control	0
		The auxiliary setting individual control	1
		main + auxiliary	2
		main -auxiliary	3

		(main *auxiliary)/maximum frequency	4
		Maximum { main, auxiliary }	5
		Minimum { main, auxiliary }	6
F05	Running control mode	Proportional linkage control	4
<p>Select this function, the slave inverter will follow the command of host inverter to run. After select this function, it can also use keyboard, terminal and RS485 to control the slave inverter's running. In the proportion of linkage during operation, if control by the keyboard, terminal,RS485 control, once the slave inverter stopped, the slave will N longer respond to the host command, if need the slave once again to respond to host commands, it should control through the keyboard, terminal and RS485, or after the host sends cease and desist commands then the slave will respond the command again to run.</p>			
A28	communication address	1~127	
A29	Baud rate	Same as host	
A30	Communication format	Same as host	
A55	Proportional linkage factor	0.10~10.00	

During the proportional of linkage, the running state of slave inverter is controlled by the host inverter.

Slave inverter F01 = proportional factor*the actual set frequency of host inverter of proportion linkage.

Slaver S00 actual set frequency = slave F01 + frequency give and secondary amend +ascend/descend adjusting.

II-2. Proportion linkage application Cases:

Features of proportional function:

- 1: the host inverter using the potentiometer to control the system speed and use the terminals to control the forward/reverse running.
- 2: the slave follows the host running, the proportional linkage factor is 1.00
- 3: after get the running speed command from host inverter, the slave will store this command into to F01.
- 4: the slave actual frequency is set through the keyboard or through terminal ascend/descend adjusting.
- 5: the slave actual frequency is set through potentiometer adjusting.
- 6: the slave actual frequency = F01 + slave potentiometer adjusting + A40

The proportional linkage host settings:


F02	Frequency main set mode	A11 external analog setting
A28	Communication address	Host 128
A29	Baud rate	3: 9600bps
A30	Communication format	0
o36	DI1 input terminal function select	1:forward running
o37	DI2 input terminal function select	2:reverse running

The proportional linkage slave settings:

F02	Frequency main set	keyboard set the frequency or Rs485	0
F03	Auxiliary setting mode of	A11 external analog setting	1

	frequency set		
F04	relationship between main and auxiliary frequencies	main+Auxiliary	2
F05	Running control mode	Proportional linkage control	4
A28	Communication address	1~127	
A29	Baud rate	Same as host inverter	
A30	Communication format	Same as host inverter	
o36	DI1 input terminal function select	39:free stopping	
o37	DI2 input terminal function select	40:Up command	
o38	DI3 input terminal function select	41:Down command	
A43	Multi-function key MF1	8:MF key is appointed to be Up command	
A44	Multi-function key MF2	9:MFkey is appointed to be Down command	

System wire connections:



Appendix III. RS485 PG Card Instruction

III-1. PI8000 PG can use arrange

type	Encoder output method
1	+5V LINE DRIVER output
2	OPEN COLLECTOR output
3	Push-pull output type (complementary)
4	Voltage output type VOLTAGE

III-2. terminal function instruction

terminal	Terminal function
A+ A- , B+ B-	<p>PG signal input</p> <p>Encoder output method:</p> <p>1:+5V LINE DRIVER output; JP1/JP2 jump to LD; connect method: A->A+ , B->B+ A- ->A-, B- ->B- R16/R17/R18/R19 disconnect.</p> <p>2:OPEN COLLECTOR output; JP1/JP2 jump tp OC; Connect method: A ->A+ , B ->B+ R2/R4/R10/R11/R13/R15 disconnect</p> <p>3:Push-pull output type (complementary); JP1/JP2 jump tp OC; Connect method: A ->A+ , B ->B+ R2/R4/R10/R11/R13/R15 disconnect</p> <p>4:VOLTAGE output; JP1/JP2 jump to OC; Connect method: A ->A+ , B ->B+ R2/R4/R10/R11/R13/R15 disconnect</p> <p>the adjustment of resistance associated with the output voltage: V+ =5V, R16/R17/R28/R29=200Ω V+ =12V, R16/R17/R28/R29=1KΩ V+ =24V, R16/R17/R28/R29=2KΩ V+encoder power, through JP3 to select</p>
Aout,Bout	<p>PG signal output</p> <p>Voltage output, voltage level determined by the encoder power supply</p>
V+	<p>Encoder power, through JP3 to select:</p> <p>JP3</p> <p> </p>


Appendix III

	<p>JP3</p> <p>⊙+5V</p> <p>⊙V+</p> <p>⊙+12V } Internal+12V power supply</p> <p>JP3</p> <p>⊙+5V</p> <p>⊙V+</p> <p>⊙+12V } External+5V ~ 24V power supply</p>
PGND	encoder

Encoder PG pulses range 300~9999

maximum pulses frequency receiver 1MHz, when PG pulses=2500, maximum speed=400Hz

III-3. terminal connection:



Appendix IV Converter Water Supply Controller Instruction

number	E00 function	Parameter setting	definition	Reference page
1	Special power supply	8	Inverter power	172
		13	Stable voltage power	172
		14	Constant current power	-
2	Constant pressure water supply	9	Pump constant pressure water supply	173
3	Extruding machine	15	Extruding machine	-

IV-1. Extend functions supplement

IV-1-1. E00=8: variable frequency power

P03 PID given signal selection, you can set through the keyboard, analog AI1, pulse and other means to set a given voltage.

Given voltage is calculated as follows:

Given voltage:220VAC

Given voltage setting = $220 * 1.414 / 500 * 100\% = 62.2\%$

Frequency Power specific parameters:

No.	name	scope	unit	meanings	Factory setting
E16	User parameter 1	0~9999	-	Voltage increasing time	0
E17	User parameter 2	0~9999	-	Voltage decreasing time	0
<p>In regulated power supply mode, the output and input voltage are both adjustable. The increasing time and decreasing time of output voltage is adjusted by F09 and F10. E16 is the voltage increasing time, the definition of the output voltage increasing time is from9999 corresponds to 999.9 seconds. E17 is the voltage decreasing time, the definition of the output voltage decreasing time is from9999 corresponds to 999.9 seconds. Voltage increasing/decreasing time just used to adjust the accelerate/decelerate time of output frequency when the inverter running. After the stopping command issued, the controller will stop the frequency output when the output frequency decelerate to 0hz.</p>					
E18	User parameter 3	0~9999	-	The max output voltage	0
<p>For safety and reliability to ensure that the output voltage to bear the load within the system, we need to define the maximum output voltage of the system. If the system highest withstand voltage 250VAC, then a maximum outout voltage= 250; E18=250.</p>					

IV-1-2. E00=13: Voltage regulation power

In this mode,connect AI2,AI3 to Hall,then measure the output voltage and use2Halls to do redundant work to ensure the output voltage will not exceed the Hall voltage limitation.

In this mode, the following parameters should be adjusted:

PID function group, P02 PID feedback signal selection.

AI2 is detected by analog and AI3 works as a redundant configuration to ensure the output voltage safe and reliable.

When Feedback voltage is 100%, the corresponding Hall voltage is 500VAC, Hall output voltage is 5V.

Set o03=50%, o05=50%.

P03 PID given signal selection, you can set through the keyboard, analog AI1, pulse and other means to set a given voltage.

Given voltage is calculates as follows:

When the given voltage =220VAC, given voltage setting = $220 \times 1.414 / 500 \times 100\% = 62.2\%$

Other PID parameters are adjusted according to the site.

Under PID regulated power supply mode, the voltage acceleration and deceleration time is controlled by PID parameters, it won't affect by voltage acceleration and deceleration time.

Voltage regulation power specific parameters:

No.	name	Range	unit	Description	Factory setting
E16	User parameter 1	0~9999	-	Voltage increasing time	0
E17	User parameter 2	0~9999	-	Voltage decreasing time	0
<p>In Voltage regulation power mode, the output and input voltage are both adjustable. The increasing time and decreasing time of output voltage is adjusted by F09 and F10. E16 is the voltage increasing time, the definition of the output voltage increasing time is from 9999 corresponds to 999.9 seconds. E17 is the voltage decreasing time, the definition of the output voltage decreasing time is from 9999 corresponds to 999.9 seconds. Voltage increasing/decreasing time just used to adjust the accelerate/decelerate time of output frequency when the inverter running. After the stopping command sent, the controller will stop the frequency output when the output frequency decelerate to 0 hz.</p>					
E18	User parameter 3	0~9999	-	Max output voltage	0
<p>For safety and reliability to ensure that the output voltage to bear the load within system,we need to define the maximum output voltage of the system. If the System highest withstand voltage 250VAC; Then E18=250VAC.</p>					

IV-1-3. Converter water supply controller instruction

IV-2-1. Constant water supply system parameters:

(1) loading types with constant water supply function:

Parameter	Keyboard display	setting	Meaning
E00	Load type	9	E12 set to be single pump, no need the constant pressure water supply interface board
			E12 set to multi-pump, need constant pressure water supply interface board,while realize 4-pumps constant pressure water supply function.

(2) PID adjusting in constant water supply system

Parameter	Keyboard Display	Setting	Meanings
F01	Keyboard set frequency	0	Keyboard set the frequency 0hz

F02	Frequency main set mode	0	Keyboard set frequency or RS485 set frequency.
F03	Frequency auxiliary set mode	7	PID adjusting mode
F04	main and auxiliary frequencies set	2	main+ auxiliary set mode
P00	PID configure	0000	single-way,the negative regulator, failure is not action
P02	Feedback signal select	1~3	External analog feedback signal given by the AI1 / AI2 / AI3
P03	Given signal select	0~6	Given signal can select the keyboard/Rs485,potentiometers, digital voltage, digital pulse, etc.
P05	PID integration time	★	Setting according the site.
P06	PID differential time	★	Setting according the site.
P07	PID proportional gain	★	Setting according the site.
P09	Deviation Limit	★	Setting according the site.
P12	PID Display Range	★	Setting according the site.

(3) Constant pressure water supply special parameters

Parameter	Keyboard Display	Setting	Meanings
E01	Starting pressure deviation	10%	Starting pressure deviation is 10%
E02	Starting time delay	2.0	Starting delay time is second.
E03	Stop frequency	15.00	stop at frequency 15HZ.
E04	stop time delay	2.0	Stop time is 2 second.
E05	High pressure arrival value	80%	feedback pressure reach and exceed the value of this parameter, the I / O output terminal select 25, then it will output arrival signal.
E06	Low pressure arrival	60%	when feedback pressure less than the low pressure reached value of this parameter, the I / O output terminal select 26, then it will output arrival signal.
E07	Timing to water supply	0000	Timing to water supply function invalid

(4) Multi-function constant pressure water supply pump specific parameters

Parameter	Keyboard Display	Setting	Meaning
E08	Timing shift alternation time	0.25	According to first start first stop principles to control pump rotation,rotation time of 0.25 hours
E09	electromagnetic switching action delay	0.500	When set up a station pump (drive motor) to switch from variable frequency industry frequency, or from industry frequency to variable frequency, and set its electromagnetic switching action delay time is 0.5 seconds.
E10	Pumps shift judging time	100	To set the determine time 100 seconds from inverter output frequency reaches the upper limit frequencies until increase pump (drive motor); or from inverter output frequency reaches the lower limit frequencies until decrease pump (drive motor).

E11	Constant Pressure Water Supply Configuration	0000	Decelerating stop: When the inverter failure, the rotation switching way is from variable frequency pump to industry frequency and the pump maintain the status.
E12	Multi-pump configuration	1111	N. 1 ~ 4 pumps are frequency controlled pump
E13	Multi-pumps status	★	Multi-pump control mode, displays the status of each pump
E14	Soft-start Pump Control	0000	Multi-pump control mode, set the control mode of each pump, currently set to Full Stop

(5) constant pressure water supply IO parameter:

Parameter	Keyboard Display	Setting	Meanings
o21~o24	Output signal select	25	High pressure arrival
o21~o24	Output signal select	26	Low pressure arrival
o36~o46	Input terminal function select	51	Pump 1 soft start
o36~o46	Input terminal function select	52	Pump 1 stop
o36~o46	Input terminal function select	53	Pump 2 soft starter
o36~o46	Input terminal function select	54	Pump 2 stop
o36~o46	Input terminal function select	55	Pump 3 soft starter
o36~o46	Input terminal function select	56	Pump 3 stop
o36~o46	Input terminal function select	57	Pump 4 soft state
o36~o46	Input terminal function select	58	Pump 4 stop
o36~o46	Input terminal function select	59	Manual shift command
o36~o46	Input terminal function select	60	Timing of water supply time-zero

IV-2-2. Application


It is special appendix for multiple pumps, which run with PI7000 family inverter to control the multiple pumps water supply system effectively.

IV-2-3. Operation and connection notice:


- ◇ If it is power frequency motor, probable thermal relay must be used to protect motor.
- ◇ AC contactor with machinery chain equipment should be used between the power frequency bypass and inverter output of aside the motor, lock logically on the electric control circuit to avoid the short circuit of the power frequency and inverter output which damage the inverter and equipments.
- ◇ The phase order of the power frequency to the motor should be the same with the phase order of the inverter output to avoid the motor reverse. Please confirm the phase order and operate.
- ◇ When wiring the control signal of the inverter, please leave it away with the driving line, and do not make them in the same wire, otherwise it will lead wrong action.
- ◇ Screen cable is used for Pressure set signal and pressure feedback signal.

IV-2-4. Dimension

- (1) Dimension of water supply control card




(2) Dimension of water supply controller




Note: The fixed plate can be fixed by any mounting hole in the figure.

IV-2-5. IV-2-5. Frequency of water supply connection to the drive controller

Connection of water supply controller with inverter, the communication cable and power cable are connected as below:



IV-2-6. System diagram



Remarks: ZK air switch KM contactor
JR thermo-relay M motor

IV-2-7. Water supply control mode

When several pumps supply water meanwhile, because of the different time(daytime and night), different season(winter and summer), the variation of the water flow is great. To save energy and protect the equipment, please run pumps as many as you need and stop pumps as many as you do not need.

Inverter will confirm the number of the running pumps according to the requirement of the pressure close loop control. In the set range, only one pump is controlled by the inverter at the same time.

If the timing shift interval time is set 0.05~100.00, when the related running time is stable, inverter inverter will shift up the pumps according to stop first or open first to ensure each pump has the chance to run and avoid the pump rusted because of long time N use.

After the pumps run to the upper and lower, arrive the adding pumps or reducing pumps time, inverter will add or reduce the pumps according to stop first or open first to ensure each pump can run and avoid the pump rusted because of long time N use.

IV-2-8. Soft-start pump control mode

Set the soft start pump by E12 and through the input terminals o36 ~ o46, respectively controlled soft-start pump start and stop.


Soft-start pump terminal control, stop first.

Soft-start pump is not controlled by constant pressure water supply system.Soft-start pump can be used as sewage pumps and fire pumps.

IV-2-9. Application Guide

3 Pumps constant pressure water supply + sewage pump

- (1) pump configurations: variable frequency pump 3 units, 15kW, 1 unit sewage pump, 15kW.
- (2) The set pressure 0.8Mpa.
- (3) pressure gauge options: pressure transmitter, DC 4 ~ 20mA output, 1.6Mpa.
- (4) Inverter choice: PI8000 015F3 and WSC_RS485 water supply board.
- (5) Hardware Connection.
- (6) Parameter setting



① loading types with a constant pressure water supply function:

Parameter	Keyboard Display	Setting	Meanings
E00	Loading type	9	Multi-pump constant pressure water supply, need constant pressure water supply interface board, while realize 4 pump constant pressure water supply pump function.

② PID adjust in constant pressure water supply

Parameter	Keyboard Display	Setting	Meanings
F01	Keyboard set frequency	0	Keyboard set the frequency 0hz
F02	Frequency main set mode	0	Keyboard set frequency or RS485 set frequency.
F03	Frequency secondary set mode	7	PID adjusting mode
F04	relationship between main and auxiliary frequencies given	2	main+ auxiliary set mode
F05	Running control mode	3	Terminal control
A29	baud rate	3	baud rate 9600
P00	PID configure	0000	single-way, the negative regulator, failure is not action
P02	Feedback signal select	3	External analog feedback signal given by the AI3
P03	Give signal select	2	External analog given by AI2
P05	PID integration time	0.250	Setting according the site.
P06	PID differential time	0	Setting according the site.
P07	PID proportional gain	100.0	Setting according the site.
P09	Deviation Limit	5.0	Setting according the site.
P12	PID Display Range	1.6	adjust according actual requirement, display the actual pressure value is 160.0, it means 1.6Mpa.

③ Constant pressure water supply specific parameters

Parameter	Keyboard Display	Setting	Meanings
E01	Starting pressure deviation	10%	Starting pressure deviation is 10%
E02	Starting time delay	2.0	Starting delay time is second.
E03	shutdown frequency	15.00	shutdown at frequency 15HZ.
E04	Shutdown time delay	2.0	shutdown time is 2 second.
E05	High pressure arrival	80%	when feedback pressure reach and exceed the high pressure reached value of this parameter, the I / O output terminal select 25, then it will output arrival signal.
E06	Low pressure arrival	60%	when feedback pressure less than the low pressure reached value of this parameter, the I / O output terminal select 26, then it will output arrival signal.

E07	Regular time water supply	0000	Regular time water supply function invalid
-----	---------------------------	------	--

④ Multi-function constant pressure water supply pump specific parameters

Parameter	Keyboard Display	Setting	Meaning
E08	E08 regular rotation interval	0.25	According first start first stop principles to control pump rotation, rotation time of 0.25 hours
E09	Electromagnetic switching action delay	0.500	When set up a station pump (drive motor) to switch from variable frequency industry frequency, or from industry frequency to variable frequency, and set its electromagnetic switching action delay time is 0.5 seconds.
E10	Pump switch to judge the time	100	To set the determine time 100 seconds from inverter output frequency reaches the upper limit frequencies until increase pump (drive motor); or from inverter output frequency reaches the lower limit frequencies until decrease pump (drive motor).
E11	Constant Pressure Water Supply Configuration	0	Shutdown: When the inverter failure, the rotation switching way is from variable frequency pump to industry frequency and the pump maintain the status.
E12	Multi-pump configuration	2111	N. 1 ~ 3 pumps are frequency controlled pump, pump 4 is soft-starter controlled pump.
E13	Multi-pump status	1112	Multi-pump control mode, displays the status of each pump
E14	Soft-start Pump Control	★	Multi-pump control mode, set the control mode of each pump, i currently set to Full Stop

⑤ constant pressure water supply IO parameters:

Parameter	Value read On Keyboard Display	Setting Value	Meanings
o21	o1 input signal select 1	25	High pressure arrival
o22	o2 input signal select 2	26	Low pressure arrival
o23	o3 input signal select 3	1	Fault input alarm
o36	(DI1) input terminal function selection	1	FWD
o37	(DI2) input terminal function selection	39	Free parking
o38	(DI3) input terminal function selection	59	Manual rotation command
o39	(DI4) input terminal function selection	60	Timing of water supply time-zero
o40	(DI5) input terminal function selection	55	Pump 3 soft starting
o41	(DI6) input terminal function selection	56	Pump 3 stopping


KLINGER BORN

Product Feedback

Dear users:

Thank you for your interest and purchase the products! In order to provide better service for you, we hope to be able to timely access to your personal information and your purchased products information .we hope to learn about your present and future demand for products and also your valuable feedback on our products. In order to help you get our service faster and more convenient, please visit our company web site refer to column "technologies and services" and "Download" for feedback. 1) download the updated manual for your products.

- 2) read and download various of product technical information, such as operation instruction, product specification and features, FAQ, etc.
- 3) application case sharing.
- 4) technical consult, on-line feedback
- 5) feedback product information and customer requirement information through e-mail.
- 6) inquiry for the latest products, obtain various types of additional services such as warranty and extended.